

Part Number	Alternate Part Number	Cond	Qty	Part Description
382		NS	8	LAMP
415	MODEL415	SV	2	DB SYSTEMS AMP, AUDIO CTL
647.7820		NE	1	CROSS BRACKET AFT
904	SFENA	OH	1	INDICATOR, HORI
1172	11729LW	SV	1	NAV IND
1550		NS	1	SWITCH
1638		NS	1	ANNUNCIATOR HOIST
2342		SV	4	SWITCH
2772		NS	31	GROMMET
2790		SV	2	GPS, GYPSI/LESS HANDHELD
2793		SV	2	GYPSI 406 WITH GPS
2820		SV	8	PRESSURE SWITCH
3641		NE	8	HEATING CARTRIDGE ASSY
3641		SV	1	HEATING CARTRIDGE ASSY
5039	6615-99-712-8802	OH	4	VERTICAL GYRO
5039	NDN5039	OH	4	VERTICAL GYRO
5420		SV	1	LABEM UNIT
6920	63405	SV	1	SOLENOID VALVE
7030		SV	1	VSI
8047		OH	1	ALTIMETER
8047		OH	1	ALTIMETER
8695		SV	1	TEMP POTENTIOMETER
9560		OH	1	TURN AND BANK
10401		SV	1	ANTENNA
10706		SV	2	ANTENNA, GPS, UNS-1D
12800		OH	1	FIRE EXTINGUISHER
15625		SV	1	TRIP & DATE ENCODER
16101		AR	1	AREA MIC
16305		AR	1	STATIC WICK
020706		SV	1	JUNCTION BOX
24918		AR	1	FUEL PUMP POWER DRIVEN
026953	S0085-101	SV	2	FAN
30510		SV	1	STATIC DEFECT CORRECTION MOD
31483		OH	1	ADF INDICATOR
32734		SV	1	FUEL FLOW IND
033203	BC407/332	OH	1	AMETEK ROTRON INVERTER
37100		SV	1	VHF GUARD RX
37462		SV	2	V-H-F ANT-FEED UNIT
38194		SV	1	VHF HOMER IND-
45900		OH	1	LIGHT BEACON
48165	1560-055-1616	NE	2	REELS SHOULDER HARNESS
2033-1-1		SV	1	RF/IR REMOTE CONTROLLER
050026		AR	1	TIMER

56108		SV	1 RMI
61148.100		SV	1 ELECTRONIC UNIT
66501		SV	1 VDO INDICATOR
71428		SV	1 BRAKE MANIFOLD
76803		NE	3 CONTROL HANDLE
76955		SV	2 SARBE BEACON
78340		SV	1 SARBE BEACON
81021		NE	10 MICROPHONE COCKPIT RCRDR
81835	81835AOIA	SV	1 RACAL SATFONE FAX
90073	CMA-1100	NS	1 I/O CABLE ASSY
97167	704A44820006	OH	1 RELAY, BREAKING CURCUIT
99400	SAC69	SV	1 AUTO ANT TUNER
99897	SCU10	SV	1 HF CONTROL
99912		AR	2 TRANCEIVER
100140		SV	1 D1000 MODEM UNIT
100160		SV	1 CONTROL HEAD
102138		OH	1 FREE AIR TEMP IND
105145		AR	2 SPEAKER
106183		SV	1 TRANSFORMER
111302		OH	1 H-S-I-
115412		OH	1 CARB AIR TEMP IND
118600	214-075-231-7	OH	3 INDICATOR, COURSE SELECTOR
125780		OH	1 GYRO INDICATOR
125810		OH	1 GYRO INDICATOR
129222	222-375-041-1	SV	2 H-S-I-
129920		OH	1 ATTITUDE INDICATOR
132890		OH	1 HORIZONTAL SITUATION INDICATOR
133640		OH	2 H-S-I-
137783	5998-00-337-5820	SV	1 CIRCUIT CARD ASSEMBLY
137896	5998-00-337-5821	SV	1 CIRCUIT CARD ASSEMBLY
137902	5998-00-339-6967	SV	1 DECODER CIRCUIT A5
137908	5998-00-339-6969	SV	1 CIRCUIT CARD ASSEMBLY
137914	5998-00-337-5822	SV	1 CIRCUIT CARD ASSEMBLY
137944	5998-00-337-5832	SV	1 CIRCUIT CARD ASSEMBLY
138614	5998-00-337-5928	SV	2 BUILT IN TEST CIRCUIT CARD
138644	5998-00-337-6018	SV	1 CIRCUIT CARD ASSEMBLY
139658	5998-00-339-7006	SV	1 CIRCUIT CARD ASSEMBLY
139837	5998-00-335-7385	SV	1 CIRCUIT CARD ASSEMBLY
143224	MS28004-1	OH	1 INDICATOR TEMP
150615	5998-00-558-5864	SV	1 CIRCUIT CARD ASSEMBLY
150630	5998-00-558-5865	SV	1 CIRCUIT CARD ASSEMBLY
150638	5998-00-558-5851	SV	1 CIRCUIT CARD ASSEMBLY
160154		NE	1 LOCK DOOR
176188		SV	3 ACTUATOR, LINEAR

180806		SV	1 AMP ASSY
196716	5826-00-952-3709	OH	1 ID-1103/ARN INDICATOR
213565	213723	SV	1 ENGINE SYNC UNIT
213778	213787	SV	1 ENGINE SYNC UNIT
215544	213723	SV	1 ENGINE SYNC UNIT
260128		OH	1 WINCH LOAD INDICATOR
271927	271927	NS	17 IGNITERS
280701		NE	1 50 WATT LAMP
306023		NE	1 GASKET
310102		NS	1 SWX INSERT
310140		NS	1 BUTTON
311601		NE	100 CABLE
320562		NS	100 SPLICE
400331	704A49430068	SV	1 IHM RS422/485 JVN
407240		SV	1 CONTROL UNIT, SIGNAL DEICING
416159		NE	1 CELL EXTRACTION TOOL
3040-05-02		SV	2 COCKPIT DISPLAY COMPUTER
3040-06-02		SV	1 APPLICATION SERVER UNIT
450004		SV	2 REMOTE
7-3133		SV	1 ACTUATOR, ROTARY
508534	1159SCAV381-3	SV	3 FAN MODULE
508617		SV	3 FAN MODULE
521645		NE	3 INDICATOR
521645		OH	1 INDICATOR
522246		SV	1 POWER SUPPLY
536834	A141936	NE	2 SLEEVE
3402-1-1		SV	1 VIDEO RECORDER MULTI SYSTEM
550986		NE	1 RAD ANGULAR BALL BEARING
610000	1666955	SV	1 7" BLOWER ASSEMBLY DC BRUSHL
616042		NS	1 CONNECTOR INSERT
618050		NS	14 CONTACT
656520		SV	3 FLUX VALVE
707395		NE	1 BURIN
707718	222-375-012-101	SV	1 DIMMER POWER SUPPLY
710104		OH	1 MOTOR
725222		SV	1 HOMING UNIT, VHF
728221		SV	1 RECEIVER VHF/AM
744619		NE	1 CONNECTOR
749823	704A47653101	SV	1 UNIT, FUEL INDICATORS
764591	7050C4284022	SV	1 GAGE, LOWER FUEL TANK
782013		NE	1 WHEEL WITH COMPONENT
794166	704A47651046	NE	1 FUEL GUAGE
800567		NE	1 STATIC SHIELDING
843772	76550-01001-103	SV	1 MASTER CAUTION/ADVISORY PANE

902205		SV	1 CABIN DISTRIBUTION BUS RPT
912000		SV	4 AIRSHOW VIDEO SWITCH
912001		NE	1 AIRSHOW VIDEO SWITCH
914026		SV	1 AIRSHOW MOUNT
938012		SV	1 LAB TOP CABLE
962600		NE	1 ICG KIT
962601		NE	2 ICG KIT
1007783	3009514	SV	1 ANTENNA CONTROL UNIT
1122505		SV	1 TEMP PROBE
1242346		NS	1 GASKET
6001-1-1		SV	1 DISPLAY SWITCHING UNIT
1510113		NE	1 EXTERIOR MIRROR
6123-1-1		SV	4 COMM CTL
1741394		NE	1 BRACKET ASSY
1775143		SV	2 POWER SUPPLY
1775277		SV	4 FLUX VALVE
7-8159		NS	1 RECEIVER DRYER
7-8159		SV	1 RECEIVER DRYER
2593379		OH	1 DUAL REMOTE COMPENSATOR
3020800	PT6A-34AB	SV	1 ENGINE ASSY
3022375		NS	2 SEAL
3039305		NE	1 SENSOR
3039310		SV	1 LOW FUEL PRESSURE SWITCH
3043013		OH	1 BLEED VALVE
3066671		NE	1 RESISTOR
3071434		AR	1 CHIP DETECTOR
3073728		NS	1 TUBE
3201104		SV	2 JUNCTION BOX
3202311		NE	1 FLIR KIT
3202315		NE	1 FLIR KIT
3205495	3205495K	NE	2 FLIR KIT
3205581		NE	2 FLIR CONNECTOR KIT
3322412	5340-01-179-3507	NS	10 BUMPER
3322577	5845-01-178-9418	NS	10 COVER
3322599	5315-01-102-0448	NS	10 PIN
3329802		NS	30 CAP
3329806	8330-01-179-1455	NS	20 GASKET
4002001		SV	1 AP05VC-032-01
4002001		OH	1 AP05VC-032-01
4012566		FN	1 BRUSH ASSY
4016636		NS	1 LENS
4103052		NE	1 RECEIVER DRYER
4171072	704A46820007	OH	1 LANDING LIGHT
4202104		OH	5 LIGHT, LANDING

4217212	704A46820022	SV	1 LIGHT RETRACTABLE
4217228		OH	4 LANDING LIGHT
4361646	L334M3820101A003	SV	1 LANDING LIGHT
5006052	6150-01-103-1066	NE	3 CABLE ASSY
6004137		SV	1 BRAKE TEMP MONITOR IND
6020277		NE	1 LOCKING BARREL CATCH
6815120		SV	1 PHASE DETECTOR TORQUEMETER
6896482		NS	1 PLUG
7001483	412-001-304-101	OH	1 ACTUATOR ASSY
7024317		NS	1 SCREW CAP
7513260		NE	1 FILTER
7583740		NE	1 FILTER ELEMENT
7672892		NE	1 FILTER ELEMENT
8002826		NS	50 HLDR
8002827	5365-01-280-9564	NS	2 HSG
8011899	5365-01-358-1238	NS	5 RETAINER DISC
8014053	5365-01-336-0136	NS	20 RETAINER
8014054	5365-01-371-5993	NS	20 RETAINER
8014055	5365-01-335-4173	NS	20 STRAP
8015238		SV	3 TDL-711 RCU
8032705		SV	1 ALLIED SIGNAL TEST BOX
9535061		NS	4 SEAL
9543973		NS	6 PLATE
9550904		OH	1 MLG BRAKE
30300014	IFR-485-05-1	SV	1 AUDIO INTL
30300038	BBK-2AH	SV	1 AUDIO MODULE
30300051	VA-400-1	SV	1 AUDIO INTL PANEL
30300078	AI-PS13-5-3	SV	1 AUDIO INTL MODULE
30300257	AI-PS12-3	SV	1 POWER SUPPLY
30300542	AI-VC-202-1	SV	3 AUDIO INTL PANEL
30500007	MDC-102-CH-1	SV	1 MULTI CD CHANGER
30500042	MCD-104-01-1	SV	1 CD PLAYER
30803829		SV	1 CONTROL PANEL
42623001		SV	2 CO2 CYLINDER
73844911		SV	1 UNIT CONTROL
75003298	64869-75003298	NE	1 LASER INTERLOCK REV B
83303139		NE	1 CONNECTOR
91000132		SV	1 NAV DATA LOADER
93400012		SV	1 TNL561 PLUS SYNCRO
0164247810		NE	1 COMPLETE FILTER
164548610		NE	3 FUEL CONTROL UNIT
174128150		AR	1 BLEED VALVE
177555120	6790623827	SV	1 OVERSPEED UNIT
0177987120		NE	2 CARD ASSY

0292117300		SV	1 FRONT SUPPORT
292687250	0292687250	NE	2 VALVE ASSY
319307840		SV	1 IGNITION INJECTOR
0319727970		NE	1 DRAIN PLUG
319738330		SV	4 HALF MANIFOLD, RIGHT INJECTOR
319739400		SV	1 RIGHT HALF FUEL MANIFOLD
319739560		AR	1 HALF MANIFOLD ASSY
0319850750		SV	1 VALVE PUMP AND METERING ASSY
390242411		NE	1 WISCHERMOTOR
401287200		SV	1 REAR PLATE
616785024		NS	20 RADIAL CONN INSERT
619051001		NS	10 COAXIAL CONTACT
619054001		NS	4 COAXIAL CONTACT
620022001		NS	5 RADIAL CONN INSERT
620075011		NS	7 COAXIAL CONTACT
639493002		NE	2 DRAIN OIL
750133040		NE	1 FREEWHEEL UNIT
4107201222		NE	5 02 REPAIR KIT - BEACON MEDAS
4619002005		SV	1 INTERMEDIATE GEAR
4619002005		AR	3 INTERMEDIATE GEARBOX
4619003003		SV	3 TAIL ROTOR TRANSMISSION
4619003003		SV	3 TAIL ROTOR GEARBOX
4619003005		SV	1 TAIL ROTOR TRANSMISSION
4619003005		NE	1 TAIL ROTOR GEARBOX
4619003005		AR	1 TAIL ROTOR GEARBOX
4619208044		NE	2 DRAIN HOSE
4619303081		NE	1 ROLLER BEARING
4619310070		NE	1 ROLLER BEARING
4619310072		NE	3 ROLLER BEARING
4619311033		NE	2 ROLLER BEARING
4638202007		NE	3 FREEWHEEL-CLUTCH
4638302013		SV	1 FREEWHEEL UNIT SHAFT
4638302093		NE	6 FREEWHEEL WAVE
4639001006		SV	1 MAIN TRANSMISSION
4639002001		AR	1 TAIL ROTOR GEARBOX
4639002001		OH	1 TAIL ROTOR GEARBOX
4639002005		OH	1 TAIL ROTOR GEARBOX
4639003001		NE	1 TAIL ROTOR GEARBOX
4639003007		OH	2 TAIL ROTOR TRANSMISSION
4639205007		NE	1 SPACER TUBE
4639302052		NE	1 FREEWHEEL SHAFT
4639306032		NE	8 RING
4639310005		NE	5 BEARING
4639310039		NE	1 OIL SIGHT GLASS

4649199001		NE	1 HARDWARE
4649208024		NE	1 OIL PUMP
6700516000		SV	1 INDICATOR, PRESSURE MB
6720004203		SV	2 ELECTROVALVE
6787300603		SV	1 VOLTAGE REGULATOR
6790623827		SV	1 OVERSPEED UNIT
8527400997		NE	1 OIL FILTER
8818457000		NE	1 POCKET ORESSURE GAUDE ASSY
8819329000		NE	1 ENGINE FRAME
9550166110		NE	1 OIL PRESSURE SWITCH
9550166160		SV	1 IGNITER BOX
9550171420		SV	1 TRANSMITTER P3
9550172970		NE	1 SPEED SENSOR (N1,N2) 1 NT
9560150490		SV	1 CLOGGING INDICATOR
9560170580		NE	1 MAGNETIC SEAL
9560176640		NE	1 HYDRODYNAMIC MAGNETIC SEAL
9580111170		SV	1 CLOGGING INDICATOR
9580114120		SV	1 ELECTRO VALVE
9580115210		NE	1 GENERATOR 1 NT
013020280010	7050A4331006	SV	1 POWER SUPPLY BLOCK
25000010010	704A46814115	SV	1 LIGHT PANEL
35093370700		SV	1 TOOL
70393000001		SV	1 WRENCH, SOCKET
526800163610		NS	3 SEAT BELT
864441835040		NE	1 RUBBER SEAL
56680016360012		NS	2 SEAT BELT
149E30	MS28006-1	SV	1 INDICATOR, TEMP
1945E245		SV	1 ROD END
000-8796-6		NE	2 SEAT COVERS
00-200-1050		NS	1 FILTER
005002-501	FERNO-12-2-AL16G	NS	2 STRETCHER
0100-002		SV	1 RECEPTICLE
010-00176-01		NS	3 GPS 500 black receiver w/rack
010-00286-01	GNS430A	NE	1 GNS430A NVG MOD.
010-01217-01		FN	1 GTX-345R ADS-B In/OUT Transpond
010-10201-06		NE	2 DATACARD
01-0770028-05		AR	3 POWER SUPPLY
01-0770062-03		AR	2 POWER STROBE
01-0770285		SV	1 STROBE LIGHT
01-0770946-01		SV	1 LIGHT STROBE GRN LED
011-00412-00	GPS155XL	SV	1 GPS
011-00582-00	GTX330	NE	1 BACKPLATE ASSY
011-00676-00	GNS430	NE	5 BACKPLATE ASSY
011-00676-01	GNS430	NE	1 BACKPLATE ASSY

011-00677-01		NE	2 BACKPLATE ASSY
011-00678-00		NE	1 BACKPLATE ASSY
011-00836-00		SV	1 GNS430A GPS/COMM/NAV
011-00870-00		AR	1 MAGNETOMETER
011-00882-00		OH	1 GDU74A ADC
011-00979-03		NE	1 CONFIG MODULE
011-01060-00	010-00412-01	NE	5 GNS430W WITH INSTALL KITS
011-02278-01		SV	1 ARHS
011-02977-00	GTX335	NE	1 CONNECTOR KIT
011-03301-00	GTX335R	AR	1 TRANSPONDER
011-04340-02	GTX345	SV	1 BACK PLATE W/ SCREWS
013-00049-11	GI-106A	SV	1 INDICATOR W COURSE DATUM
0130-2002-0010	1552644	SV	1 UNIT POWER SUPPLY
013-1885-010		SV	2 ANTENNA
0132NE		NE	1 OAT-SENSOR
017500-11	SX-16	SV	1 SEARCHLIGHT ASSY
01-768230		NS	1 GALLEY SWITCH
018-1394-010		NE	2 SHIELDING GASKET
01-P24481F001	PTRA-200	SV	1 MOTOROLA CONTROL PANEL
01R43129D02		SV	1 MOTOROLA CONTROL PANEL
0201992-001		OH	1 SEARCHLIGHT ASSY
0202644-005		SV	1 LANDING LIGHT AW139
02-0350034-00	A506	NE	2 STROBE BEACON
0204-0001		OH	1 HYDRAULIC RESERVOIR
0204-001		SV	1 HYDRO RESERVIOR
020-969-018	1159SCP460-18	SV	1 TANK UNIT FUEL QTY
02-1104-0006		NE	2 CABLE
02289-5600-S938		SV	1 RELAY, TIME DELAY
022TA1101	704A47723068	SV	1 FAILURE WARNING PANEL
0230191-001		SV	1 SEARCH LIGHT
0231102-004		SV	1 SEARCH LIGHT
023-138-842		NE	1 DTRESSCOVER MANGAN
024711-41	SX5	SV	1 SEARCHLIGHT ASSY
024711-41	030040	SV	1 SEARCHLIGHT W GIMBAL ASSY
024918-107		AR	1 PUMP ROTARY POWER DRIVEN
025234-11	SX5	SV	1 JUNCTION BOX ASSY
025323-150		AR	1 FUEL PUMP
02W101633		SV	1 FILTER
030-01184-0011		NS	3 PIN
030-02070-0005		NS	3 CONNECTOR
030-02250-0000		NS	1 CONNECTOR
030-02350-0062		NS	1 CONNECTOR
030-02351-0004		NS	1 HOOD/LVR-ASSY
0300-402		SV	1 ROSEN PANEL

03024473-0002		NS	1 CONNECTOR KIT
03024473-0003		NS	1 CONNECTOR KIT
030-600-002		SV	1 PLINTH
030611-15-72	W8-2P2	NS	1 NIGHTSUN CABLE
030752-34-25		AR	1 CABLE ASSY SX-5
031-00785-0505		NS	3 ANNUCIATOR
03-1100-0002		NE	1 LAMP
03-12-1062		NS	20 CONNECTOR
033002-1		SV	1 PENDANT, NIGHTSUN XP
038-220-2800-H	MSA00552323PSMOHGAS	SV	6 ACCORDIA WINDOW SHADE
038-220-3100-A	MSA00552323	SV	6 ACCORDIA WINDOW SHADE
03-9002-0004		NE	5 LED POSITION LIGHT GREEN
03972-2496-1B		SV	6 OVERSPEED CONTROL
03G10S		NS	2 LOCK WASHER
04-1120-0028		AR	2 POWER SUPPLY
04-327W001	04-327F001	SV	1 EGPWS RELAY/FUSE BOX
047-06054-0001		NS	1 SPACER
047-07531-0000	047-7531-00	NS	1 TRAY
0476-A-00364	AMT50	SV	1 LNA/DIPLEXER
0476-F-00364	AS100500-01-180	SV	1 LNA/DIPLEXER
050-01854-0000	KI229	NE	1 INSTALL KIT
050-01855-0001	KTU709	NE	1 INSTALL KIT
050-01864-0002	KTS156	NE	1 INSTALL KIT
050-02121-0001	KTR993	NE	1 INSTALL KIT KTR993 CRIMP
050-02251-0000	KA676/KA678	NE	1 INSTALL KIT
050-03044-0001	KA90	NE	1 INSTALL KIT
050-03392-0000		NS	1 INSTAL KIT (26)
0501002A	DEFT-1	SV	1 ELT
050-160-0248		SV	1 UNIT, PDR60 WARNING
0501-786-954		NS	3 INSTALL KIT
050-3111-00	KA670	NS	1 KA670
0511-781-954		NS	6 INSTALL KIT
0514-901-954		NS	3 INSTALL KIT
052-00009-0004		NS	4 SHOCKMOUNT
0520-110-1085		NE	1 SEAT 180/260
0520-514B-102		NE	1 CUSHION
055-1800-001		SV	2 TRANSMITTER
057-0719-002		NS	4 BACKSHELL
060-0013-01	KSG105	OH	2 DIRECTIONAL GYRO
060-0015-00	KG-102A	SV	1 DIRECTIONAL GYRO
06076-90G001-01		NE	4 RAD ALT INSTALL KITS
062-0004-00	KU193	SV	1 COMM
064-01047-0001		NE	2 RECEIVER
064-01083-0101	ITU-100	SV	1 AIRSAT 1 TRANSCEIVER

064-1009-00	KTR905	AR	2 COMM TRANSCEIVER
064-1047-01	3614001-4002	NE	2 RECEIVER
064-1047-12	064-01047-0012	SV	1 VHF TRANSCEIVER
065-00063-0006		FN	4 Annunciator Panel Blk.
065-00157-0200	KLA570	AR	1 SERVO ACTUATOR
065-00157-0300	KLA570	AR	1 SERVO ACTUATOR
065-00157-0400	KLA570	AR	1 SERVO ACTUATOR
065-00158-0102	KCP520	SV	2 FLIGHT COMPUTER
065-00158-0202	KCP520	SV	1 FLIGHT COMPUTER
065-00159-0402	KMS-540	SV	2 MODE SELECT PANEL
065-00162-0100	KSA572	SV	1 SERVO ACTUATOR
065-00162-0200	KSA572	SV	1 SERVO ACTUATOR
065-00165-0100	KSM575	OH	1 PITCH ACTUATOR ASSY
065-00165-0200	KSM575	OH	1 ROLL ACTUATOR ASSY
065-00165-0300	KSM575	SV	1 ACTUATOR ASSY YAW
065-00167-0200	KSM575	OH	1 YAW ACTUATOR ASSY
065-00167-0800	KSM575	NE	3 ROLL LINEAR ACTUATOR
065-00167-0900	KSM575	NE	3 PITCH LINEAR ACTUATOR
065-0064-08	KCP220	SV	1 FLIGHT COMPUTER
066-01066-0002	066-1066-02	SV	1 KING KDM 706
066-01069-0002		SV	1 KDI 573
066-01078-0004		SV	1 RECEIVER (KNR634)
066-01143-0201	MST67A	SV	1 MODE S TRANSPONDER
066-01143-0601	MST67A	SV	1 TRANSPONDER
066-01153-0101	KRA405B	OH	1 RADIO ALTIMETER RCVR
066-01153-2001	KRA405B	SV	1 RADIO ALTIMETER RT
066-01153-4001	KRA405B	OH	1 RADIO ALTIMETER RT
066-01164-0101	KT73	SV	1 MODE S ATC WITH NVIS MOD
066-01171-2304	IVA81D	SV	1 TCAS DISPLAY
066-01198-0102		FN	4 KXP-2290A Mode "S" Diversity Trans
066-01201-0105		FN	4 GPS Receiver (WAAS)
066-03031-0004	066-3031-04	NE	1 KNI 415 RAD ALT INF NVG
066-03044-0000	KNI416	NE	1 RAD ALT INDICATOR
066-03046-0013	066-3046-13	NE	1 KI525A H.S.I. NVG
066-03062-0008	066-3062-08	OH	1 KEA346 ENCODING ALTIMETER
066-03062-0009	066-3062-09	OH	1 KEA346 ENCODING ALTIMETER
066-03062-0010	066-3062-10	OH	1 KEA346 ENCODING ALTIMETER
066-03062-0011	066-3062-11	OH	1 KEA346 ENCODING ALTIMETER
066-03123-1500	ED-461	AR	1 EFIS INDICATOR
066-03123-1600		SV	1 EHSI
066-03125-2600	ED462	NE	3 DISPLAY
066-03125-2600		SV	1 EHSI/EADI
066-04031-1122	KLN90B	SV	1 GPS
066-1024-03		AR	1 AUDIO CONTROL

066-1045-00	KDD693	SV	1 DME RANGE CONVERTER
066-1061-03	KRA10A	SV	1 RAD ALT RCVR
066-1061-03	KRA10A	AR	2 RAD ALT RCVR
066-1069-00	KDI572	SV	1 DME IND
066-1070-01	KN63	SV	5 DME RCVR
066-1072-00	KR87	AR	3 ADF RCVR
066-1091-04	KDI573B	SV	2 NAV INDICATOR
066-1101-00	3614004-4101	SV	1 NAV RCVR
066-1105-00	DF431B	SV	1 ADF RCVR
066-1107-01	DM441B	SV	1 DM-441B DME TRANSCEIVER
066-1107-12	DM441B	SV	1 DME RT
066-3024-09	KPI552	OH	1 PICTORIAL NAV IND
066-3024-17	KPI552	OH	1 PICTORIAL NAV IND
066-3024-40	KPI552	SV	1 PICTORIAL NAV INDICATOR
066-3027-14	KPI553	OH	1 PICTORIAL NAV IND
066-3032-10	KDI571	AR	1 INDICATOR
066-3034-02	KI204	SV	1 VOR LOC GS IND
066-3034-24	KI206	SV	1 IND
066-3044-01	KNI416	OH	1 RAD ALT IND KNI 416
066-3045-14	KPI553A	OH	1 PICTORIAL NAV INDICATOR
066-3048-07	KI525A	SV	1 H.S.I. INDICATOR
066-3054-01	KI-250	SV	1 RAD ALT INDICATOR
066-3054-01	KI250	AR	1 RAD ALT INDICATOR
066-3056-00	KI208	AR	1 VOR/LOC/GS INDICATOR
066-3060-00	066-03060-0000	OH	1 RMI INDICATOR
066-3063-01	KI227	SV	1 ADF IND
066-3069-09	KPI553B	OH	2 PICTORIAL NAV IND
066-3077-25	KAV485	OH	1 ALT/VS IND
066-3096-00	IU-2023B	SV	1 REMOTE COMP UNIT
066-4004-00	KN77	SV	1 VOR/LOC CONVERTER
066-4006-01	KNR665	SV	1 NAV RCVR
066-4007-02	KNR632	SV	1 NAV RCVR
066-4009-00		SV	1 NAV CONVERTER
069-01037-0102		FN	4 KTR-2280 MULTI-MODE DIGITAL RAI
069-1026-01		SV	1 KX99 RECEIVER
070-0900-001		SV	3 CPT900 ADELTA BEACON-
071-0006-00		SV	1 DME CODE CONVERTER
071-00158-0211	KAC502	AR	3 EGPWS MODULE
071-00166-0411	KAC504	SV	1 TRAFFIC MODULE
071-00168-0311	KAC504	SV	1 TRAFFIC MODULE
071-0025-00	CA308	SV	1 TDR94A TEST SET/MODULE
071-0031-00	KDL569R	SV	1 TEST BOX
071-01283-0012	071-1283-12	SV	1 CONTROL UNIT
071-01283-0012	071-1283-12	NE	1 CONTROL UNIT(KFS564A)

071-01315-0000		OH	1 RS181A Radar R/T Unit
071-01505-0203	GC-362A	SV	1 GRAPHICS ADAPTER
071-01507-5202		FN	1 KFS-578A TCAS CONTROL HEAD
071-01508-0201	KA90	AR	1 H-S-I- APAPTER
071-01511-0101	CP469A	AR	1 CONTROL PANEL
071-01542-0401	CD671C	NE	7 TCAS-II DUAL BLK
071-01545-0100	KA91	SV	1 GPS ANTENNA
071-01546-0101	KFS599A	SV	1 UHF COMMUNICATION CONTROL
071-01596-0201		FN	4 Primary Flight Display (PFD) Control
071-01598-0901		FN	2 Multi-Function Display (MFD)
071-01618-0105		SV	1 PS-578A Control Panel
071-01619-0022		SV	1 PS-550 Control head
071-04025-0001	071-4025-01	NE	6 MTG RACK w/ SHOCKMOUNTS
071-04030-0001	071-4030-01	NS	7 MTG RACK
071-04051-0000	071-4051-00	NE	1 NC104B MOUNTING TRAY
071-04054-0000		SV	1 MOUNTING TRAY
071-1033-00	KFS580	SV	2 CONTROL ADF
071-1034-00	KA36	SV	1 ANTENNA
071-1052-00		AR	1 FLUX VALVE
071-1059-00	DMPN3-3A	AR	1 KA54 ANT-
071-1066-00		SV	1 ADF CTL
071-1073-00		SV	1 SUPER FLAG ADAPTER
071-1148-00		SV	1 MATCHING ASSY
071-1215-70	KFS598	AR	3 COMM CONTROL
071-1216-12	KFS564	AR	1 NAV CONTROL
071-1242-01	KA51B	SV	2 SLAVING ACCY
071-1242-06		AR	1 SLAVING ACCY
071-1271-00	KA161	AR	1 EXTERNAL CAPACITOR
071-1272-00		NE	1 KAC992 WHIP ANTENNA
071-1274-01	KFS594	SV	2 HF CONTROL UNIT
071-1279-01	KA68A	NS	2 PROGRAMMER
071-1313-31		SV	1 GC-360A Radar Graphics Unit
071-1316-00	3614165-5510	SV	1 10IN ANTENNA ARRAY
071-1316-00	3614165-5510	SV	1 10IN ANTENNA ARRAY
071-1335-00	CP103D	SV	1 CONTROL
071-1377-01	8095444-4102	SV	4 NAV CONTROL CD413B
071-1446-00	8095635-1001	SV	1 EFIS CONTROL PANEL
071-1523-03	071-01523-0003	SV	1 KLN90B DATA BASE
071-2007-00	KAA455	SV	2 AUDIO CONTROL SYSTEM
071-22000-01		SV	1 ANNUNCIATOR ASSY
071-4002-00		SV	1 MOUNTING TRAY
071-4004-00		SV	1 MOUNTING TRAY
071-4022-01		SV	1 MOUNTING TRAY
071-4025-01		SV	1 KG102A MOUNT

07148-11126-2	214-075-186-1	SV	1 CONTROL UNIT TEMP
073-00044-0001		SV	1 PLATE
073-00045-0000		SV	1 PLATE
073-00866-0002		NS	2 KNOB
075-1800-005A		SV	1 HEADSET
0811-A-0001	AMT-50	SV	1 ANTENNA CONTROL UNIT
081252-3-10	TDFM-136B	SV	1 VHF FM TRANSCEIVER
0851GE		SV	1 PITOT TUBE
0871GA1		NE	1 ICE DETECTOR
089-06159-0003		NS	6 SCREW
089-06200-0002		NS	10 SCREW
089-06592-0003		NS	4 SCREW
08GSW		NS	3 BEARING
090-00499-0003		NS	1 RING
090-00540-999		SV	1 SHEPHERD VIGILANT
090-00556-900		SV	1 SHEPHERD VIGILANT
09168P-18		NE	1 MICROPHONE
096-2100-030	SCORPIO2000	SV	2 MICROCONTROLLER MODULE
099-114-101	BHT407	SV	2 MODULE
1000670-1-006	3050087-04	SV	1 CONTROL ELECTRONIC ENGINE
100-0701-01	SECURAPLANE	SV	1 CDU
100-1057-01	SECURAPLANE	NS	1 CAMERA
100-1088-01	SLA3000	SV	1 BATTERY EMERGENCY
1-002-0102-1605	4B3500-3E-NB-CM-1605	SV	1 CONVERTER, FREQUENCY, STATIC
1002-033	USA-2	SV	1 UNIVERSAL SWITCHING UNIT
100-43677		SV	1 SELF SEALING COUPLING
100-43686M4		SV	1 VALVE
100-601260-002		AR	1 GROUNDSPED DRIFTANGLE INDIC
100-601600-504		SV	2 GNSSU CMA-3012 TSO C-129
100-601721-001		AR	1 CMA 3000
10062-1-B		SV	1 TRANSMITTER
10067146-103		NE	1 CIRCUIT BOARD
10-0815-5		SV	1 DOME LIGHT
100CC01A		SV	1 RELAY
100CC01A		NE	2 RELAY
101001-10	DEI01-10	SV	1 AUDIO SELECTOR PANEL
101-00153	1811FER	SV	1 PITOT STATIC TEST SET
101-00167A0A	1811HA0A	SV	1 PITOT STATIC TEST BOX
1010-1	UNS1	SV	1 CDU
10102-0000		SV	1 ADAPTER PLATE
10-102-3C		SV	1 ANTENNA
10-104-6		SV	1 ANTENNA
1012ZH	MODEL010012	NS	2 EFIS BLOWER
101-331-45-100		SV	1 COMM CONTROL

101-380027-1		AR	1 REG VALVE
101-380031-1	70002-0131	OH	1 TURN AND SLIP INDICATOR
101-380094-3	43-206-1	OH	1 TORQUE INDICATOR
101-389025-3	424-1	SV	1 FUEL SHUTOFF VALVE
101420-11968E	102220-11886	OH	2 ALTIMETER, PRESSURE ALT REP
101435-11263	101435	OH	1 ALTIMETER
1014744-0001		NS	1 PHONE
1015-1-11		SV	2 EFIS / RADAR PANEL
1016-1-110	UNS1	AR	1 CONTROL DISPLAY UNIT
1016-2-21		SV	1 CONTROL DISPLAY UNIT
101635-11839	8140B-S20-LW5V	OH	1 ENCODING ALTIMETER
101641-6		SV	1 DESICCATOR, PRESSURE EQUAL
101-641-C		SV	1 DESICCATOR
10167N01W00		SV	2 TORQUE INDICATOR
101730-01467		OH	1 ALTIMETER
101735-01455		OH	1 ALTIMETER
1018-2-213		FN	1 5" FPCDU Black HI-Resolution
1018-2-610	UNS-1	US	2 CONTROL DISPLAY UNIT
102-0053-02	RCA26AK-1	OH	1 ATTITUDE GYRO
102-0060-02	RCA26BK-9	OH	1 ATTITUDE GYRO
102006-1		SV	1 MODULE
102008-1		SV	1 MODULE
1020-1-3	AIRSHOW	SV	2 COMPACT AUDIO DISTRIBUTOR
102013-1		SV	2 MODULE
102089-22410001		AR	1 HEAD OF PROPELLER
1021-1-1	AIRSHOW	SV	3 VIDEO MODULE
102220-11886		OH	3 ALTIMETER
102264NVG		SV	1 DISPLAY, OXYGEN MINDER
10238-0011		NE	1 CAPACITOR
1025-1-6	AIRSHOW	SV	1 AUDIO/VIDEO MODULE
1029-1-1	AIRSHOW	SV	1 AUDIO MULTIPLEXER
102AUICK	102	SV	1 SENSOR, TOTAL TEMPERATURE
103-0023-01	RCA15BK-2	OH	1 DIRECTIONAL GYRO
103006-1		SV	1 MODULE
1-030-069-01	5365-00-784-3994	OH	1 SPACER
1030-1-2	AIRSHOW	SV	2 INFRARED INTERPRETOR
10312N01T00	76450-01076-111	OH	1 TURB TEMP IND
10313N01R00	76450-01076-112	OH	2 TRIPLE TACH INDICATOR
1033-1-1	AIRSHOW	SV	1 RF/IR REMOTE INTERPRETER
103-5	27908-1	OH	1 AIRSPEED
103500-103	7901-01A	SV	1 AUTO DATA ENTRY UNIT
10355N04T00	212-075-067-119	OH	1 ITT INDICATOR
10379-11-01		SV	1 ALTITUDE ALERTER
10406-12600		SV	1 FLIR LCU, LAP TOP CONTROL

10406-66110		SV	1 FLIR, QWIP 640X480 PIXEL FPA-
1041-020	9200-0102-430	SV	1 DISPLAY MONITOR
10420-11968E		NE	2 ALTIMETER
104500A9		AR	1 POWER TURBINE GOVERNOR
10-4804-359		NE	1 FLOOD LIGHT PLATE
10-4804-364		NE	7 FLOOD LIGHT PANEL
105-00001		NE	1 TAIL FLOODLIGHT KIT
10-501TA		SV	1 LIGHT ASSY
105-10101W4		NE	1 CENTERING DEVICE
105-101511.07		NE	1 TENSION ROD
105-10158		NE	1 TRANSM. STAND ASSY RH
105-101731		NE	2 STRUT
1051-1-3		SV	4 CABIN MANAGEMENT MODULE
1051-1-6		SV	1 CABIN MANAGEMENT MODULE
105-131035		NE	1 SAFETY LEAVER ASSY
105-13122		NE	1 PITCH LINK ASSY
105-13221		AR	1 DRIVING LINK ASSY
105-13221.08		NE	1 SPACER
105-13241		AR	1 FORK LINK ASSY
105-14101 W1		NE	1 ABZIEHVORRICHTUNG
105-14101.12		SV	1 MAIN ROTOR STAR
105-14101.91		NE	1 HEX BOLT
105-14102W1		NE	1 SUPPORT ASSY -M/R HUB
105-141081		SV	1 MAIN ROTOR HEAD
105-141081		AR	5 ROTOR HEAD
105-141091		SV	2 MAIN ROTOR HEAD
105-141091		AR	3 ROTOR HEAD
105-14181.01		SV	8 INNER SLEEVE ASSY
105-14181.03.5		NS	8 BUSHING
105-14181001		NE	1 ASSY FIX NEEDLE BEARING
105-14183		NE	3 INNER SLEEVE ASSY
105-15103W2		NE	1 BENDING FIXTURE
105-151091		AR	1 ROTOR HEAD
105-15181-001		NE	1 EROSION PROTEC W.PEEL TEST
105-15853		NE	30 BLADE FITTING ASSY
105-20161-001		NE	1 FRAME9BEH
105-20301.55		NE	1 GUSSET
105-20402		NE	1 LUG ASSY
105-20501.55		NE	1 GUSSET PLATE
105-21301		SV	1 NOSE DOOR CONTROL LINKAGE
105-21706		NE	1 MOD ENGINE FLOOR
105-21721.115		NE	1 STIFFENER
105-21801-77		NE	1 ANGLE LH
105-21831-100.26		NE	1 SIDE PLATE LH

105-21841-002		NE	1 REAPIR SHEET FRAME
105-21924		NE	1 CABINROOF F SANDFILTER MOD
105-22209		NE	1 GLASS PANE UPPER RH
105-231151		NE	1 REAR DOOR SUPPORT
105-23151		NE	1 REAR DOOR SUPPORT LH
105-23401.10		NE	1 LEVER RH
105-23587		NE	1 LINK UPPER
105-30591		SV	1 VERTICAL STABILIZER ASSY
105-30591		NE	1 VERTICAL STABILIZER ASSY
105-31702		AR	2 TAIL ROTOR HEAD
105-31702-20		NS	1 NUT
105-31702W12		NE	1 PUSHING OUT TOOL
105-31711 W1		NE	1 PULLER TAIL ROD PITCH BEARING
105-31711W5	105-31711	SV	1 MOUNTING TOOL
105-31711W5		NE	1 MOUNTING TOOL
105-31714		SV	1 TAIL ROTOR HEAD
105-31729W2		NE	1 MOUNTING SLEEVE
105-31734		AR	8 BLADE MOUNTING FORK ASSY
105-31734W1	105-31734	SV	1 EXTRACTOR
105-31734W2		NE	1 BONDING TOOL
105-317385		NE	1 CONTROL LEVER ASSY BLACK
105-317395		SV	1 TAIL ROTOR HEAD
105-31743W15		NE	2 CONTROL DEVICE
105-31754W7		NE	1 MASTER GAUGE
105-31762		AR	1 SLIDING SLEEVE ASSY
105-31784		NE	1 TAIL ROTOR HEAD
105-31796		NE	8 TAIL ROTOR BLADE PAINTED
105-31802-001		AR	3 REAR ROTOR WAVE
105-31803-01		SV	1 TAIL ROTOR SHAFT
105-31810		NE	16 TAIL ROTOR BLADE
105-40118		NE	1 BELLOWS STICK RH
105-40151		NE	1 LONGITUDINAL CONTROL LINK
105-40213		NE	1 BELLOWS
105-40213		NE	1 BELLOWS
105-41027		NE	1 LATERAL TRIMMER
105-41041		NE	1 TUBE
105-41043		NE	1 HOUSING
105-41045		NE	1 TUBE
105-41081.01.5		NE	1 ADAPTER
1054-1-1	AIRSHOW	SV	4 8 CKT 5A AC/DC MODULE
105-411091		NE	1 TRANSDUCER
105-41221		NE	1 PITCH SHAFT
105-41227		NE	1 BRAKE BOXQ
105-41230		AR	1 COVER ASSY

105-41235		NE	1 BELLOWS ASSY
105-41237		NE	1 COLLECTIVE PITCH STICK ASSY
105-41238		NE	1 COLLECTIVE PITCH STICK ASSY
105-41247		NE	1 HANDLE
105-414661		NE	1 ACTUATOR LATERAL ASSY
105-414661		AR	2 ACTUATOR ASSY
105-414691		NE	1 CONTROL ROD ASSY
105-42122W2		NE	1 MOUNTING TOOL
105-42123		NE	1 LAGERBOCK
105-42123W4		NE	1 PUSHING OUT TOOL
105-42124		NE	1 ADJUSTABLE SUPPORT
105-42221.36		NE	1 FITTING
105-42310		SV	3 TORSION BAR ASSY LONGITUDINAL
105-43011		SV	1 BELLCRANK ASSY
105-44001V001		NE	5 KIT
105-450121		SV	1 HYDRAULIC PACK
105-450121		NE	1 HYDRAULIC PACK
105-45021.63		NE	1 ADAPTER
105-45023		SV	1 TANDEM HYDRAULIC UNIT 7VE
105-45023		SV	1 TANDEM HYDRAULIC UNIT 7VE
105-45028		SV	1 TANDEM HYDRAULIC UNIT 7VE
105-45028		AR	1 TANDEM HYDRAULIC UNIT
105-45028V004		SV	1 TANDEM HYDRAULIC UNIT 7VE
105-450391		SV	1 TANDEM HYDRAULIC UNIT
105-45041W19		NE	1 ASSY TOOL
105-45041W30		NE	1 ASSY TOOL
105-45046		NE	2 3-AXIS ACTUATOR
105-45047		OH	1 ACTUATOR
105-45051W3		NE	2 SOCKET WRENCH
105-45054	105-45054B	NE	1 3-AXIS ACTUATOR
105-45055	105-45054	OH	1 ACTUATOR
105-45067	105-45054	OH	1 ACTUATOR
105-45077	105-45054	OH	1 ACTUATOR
105-450811		NE	1 RESERVOIR SYSTÉM I
105-450861		NE	1 RESERVOIR SYSTÉM ii
105-45353		NE	3 PRESSURE TRANSFER VALVE
105-466071	S4-3010180	NE	1 3-AXIS ACTUATOR
105-466071B	S4-3010180	NE	1 3-AXIS ACTUATOR
105-46621B		OH	1 ACTUATOR
105-46631		NE	1 VALVE BODY MANIFOLD
105-46636		OH	1 VALVE BODY MANIFOLD
105-46648.01		NE	1 CONTROL SPOOL
105-46649	105-46649B	OH	1 VALVE BODY MANIFOLD
105-46661011	105-45054	OH	1 VALVE BODY MANIFOLD

105-46668		NE	18 CONE BYPASS
105-46671.01		NE	1 SPACER SLEEVE
105-46683		NE	5 SERVO - VALVE I
105-46686		NE	1 SERVO-VALVE ii
105-46741.10	E2-2100440	NE	1 PISTON ROD
105-46743		SV	1 HYDRAULIC RESERVOIR
105-46744		NE	1 HYDRAULIC RESERVOIR
105-46753		SV	1 TRANSFER VALVE
105-50101-22		NS	1 NUT
105-51523.12		NE	1 SKID CUP
1055-80237		AR	1 PANEL
1055-80238		AR	1 PANEL
105-60001W2		NE	1 TOOL
105-60186		NE	1 EXHAUST PIPE LH INSIDE
105-60354		NE	2 ENGINE MOUNT ASSY RH
105-60593		NE	2 ADJUSTABLE LEVER ASSY
105-60611		NE	2 TELEFLEX-TUBE
105-612711		NE	1 OIL TRIP TRAY
105-614061		NE	1 FIRE DETECTOR ASSY
105-61704		AR	1 OIL TANK
105-61704		NE	2 OIL TANK
105-61761		NE	1 TUBE
105-61781		NE	1 FLANSCH
105-61802		NE	1 COOLER INTAKE ASSY
105-619011		NE	1 LUBRICATION TANK ASSY
105-619031		NE	1 LUBRICATION TANK ASSY
105-62456		NE	2 PANEL ASSY RH OUTSIDE
105-62457		NE	1 BACK WALL LH ASSY
105-62458 "B"		NE	1 RUCKWAND RECHTS VOLLST.
105-62458 B		NE	1 WALL RIGHT COMPLETELY
105-62461 "B"		NE	1 MITTERWAND VOLLST.
105-62464		NE	1 CASING ASSY
105-62464 "A"		NE	1 SCHACHT VOLLST.
105-625206		NE	1 ICE PROTECTOR
105-62720V001		NE	1 VENTILATING DUCT MONTAGE
105-62725		NE	1 COOLER COVER
105-62741		NE	1 LUBRIC COOLING SYSTEM
105-62741.28		NE	1 ELBOW
105-62747		NE	1 MOD DRAIN LINE FUSELAGE
105-62904		NE	1 MUFF
105-70221		NE	1 SEAT
105-70221GRAU		NE	2 BACK CUSHION COVER
105-70322		NE	1 REWORK SHOULDER HARNESS
105-70501.08		NE	1 LAP BELT FITTING

105-71286	AR	1 SITPOLSTER
105-71286GRAU	NE	1 SEAT CUSHIONING GRAY
105-72321.01	NE	1 FLOOR PANEL
105-73205	NE	1 CABIN STRUCTURE PANELLING
105-73207	NE	1 CABIN STRUCTURE PANELLING
105-73212	NE	1 CABIN STRUCTURE PANELLING
105-73215	NE	2 ROOF PANELLING LH
105-73216	NE	1 ROOF PANELLING RH
105-73248	NE	1 PANELLING, CABIN REAR WALL
105-73511	NE	1 ACTUATING DEVICE LH
105-79511.87	NE	1 SCHEDULE
105-80032	NE	2 RETRO BO15CBS
105-800390	NE	1 MODIFIC HYDRAULIC
105-80097	NE	2 INST. HEAT. A. VENT. SYSTÉM
105-80171	NE	1 NOZZLE LH
105-80239	AR	1 PANEL
105-80240	AR	1 PANEL
105-80329	NE	1 RETR. CYC. PITCH STICK RH ASSY
105-80335	NE	1 LOAD HOOK DETACHABLE FIX
105-80335	SV	1 LOAD HOOK DETACHABLE FIX
105-80335	AR	2 LOAD HOOK DETACHABLE FIX
105-80337	NE	1 LOAD HOOK DETACHABLE FIX
105-803441	NE	1 CARGO HOOK PERM. FIXTURE
105-80351	NE	1 MOUNTING
105-80428	NE	1 KIT
105-807214	AR	1 TURBINEN EINLASS
105-81022	SV	1 VIBRATION ABSORBER
105-81022	NE	1 VIBRATION ABSORBER
105-81022.04	NE	1 SHAFT
105-81022.12	NE	2 PART BY WEIGHT
105-81110	AR	1 RESCUE WINCH DETACHABLE PART
105-81112W2	NE	1 RITZELADAPTER
105-81210	NE	1 BUMPER UNIT INSTAL
105-81511	NE	1 REVERSED COPILOT SEAT ASYY
105-81511.09	NE	2 SHEET
105-81931	NE	2 PANEL
105-81936	NE	2 PANEL
105-82101	NE	4 INST. AUXILIAR TANK. AIRCR. SIDE
105-82102	NE	1 LONG RANGE FUEL TANK FIX. PROV
105-82151	NE	1 SWITCH ASSEMBLY
105-82206	SV	1 AUXILIARY FUEL TANK ASSY RH
105-82216	NE	1 TUBE
105-82226	NE	1 BELLOWS ASSY
105-82503	NE	3 PASSENGER SEAT

105-82521	NE	1 TUBE ASSY, SHORT
105-82761	NE	2 ARM
105-83011	SV	1 TANDEM HYDRAULIC UNIT 7VE
105-83011	AR	1 TANDEM HYDRAULIC UNIT
105-83101	NE	1 PARTIAL COVER
105-83111	NE	1 REAR ROTOR GEAR COVER
105-83116	NE	1 REAR ROTOR BLADE COVER
105-83121	NE	1 COVER ROTOR HEAD
105-83196	NE	1 ENGINE COVER
105-832061	NE	1 COVER ENGINE INTAKE
105-832111	NE	1 COVER ENGINE OUTLET
105-83216	NE	1 COVER EXHAUST AND AIR INTAKE
105-83221	NE	1 TIE-DOWN FOR MAIN ROTO
105-83231	NE	1 SACK AND BELT
105-83516	NE	1 DRAINING TANK
105-83591	NE	1 FAD FILTER
105-83869	NE	1 EXT LOUDST PERM FIXED
105-83956	NE	2 MEDICAL EQUIP WALL ARMAN
105-84002	NE	1 STR RAIL LH FIXED PT
105-84007	NE	1 STR RAIL RH FIXED PT
105-84115	NE	1 YUBE PIPE
105-84717.05	NE	1 SKID PROTECTIVE PLATE
105-84931	NE	1 SIDE SECTION LH
105-84932	NE	1 SIDE SECTION RH
105-84935	NE	1 U-PROFILE
105-853056	NE	1 ENG COWLING FWD LH MOD
105-853066	NE	1 ENG COWLING FWD RH MOD
105-853076	NE	1 CAB ROOF F PART SEPER MOD
105-85327	NE	1 COVER
105-853336	AR	3 SANDFILTER DETACH FIXTURE
105-853346	NE	1 INSTAL PART SEPARATOR FOR SANI
105-853521.01	NE	2 SHROUD
105-85354	NE	1 SEALS ROTOR MAST CONTROL ROD
105-85502	NE	1 ENG COWLING FWD RH REWOEK
105-85503	NE	1 ENG COWLING FWD RH REWOEK
105-86490	NE	1 KIT
105-86559	NE	1 SWITCH PANEL ASSY
105-880068	NE	1 Konsole GA56
105-88921	SV	1 CONTROL UNIT
105-895666	NE	1 INSTAL HEADREST
105-899926	NE	1 SNOW SKID RH MOD
105-90986	NE	1 FRAME ASSY
105-90996	NE	1 GROUNDING CABLE
1059-1-1	Q	6 CKT MODULE

AIRSHOW

105-91106	NE	1 REL BOX
105-911151	NE	1 P/C BOARD GEN INTERLOCK
105-912021	NE	1 RELAIKASTEN 10VE
105-93975	NE	1 DRUCKSCHALTER VOLLST
105-93975	NE	1 PRESSURE SWITCH ASSY
105-94020	NE	2 WIRING HARNESS 2VB
105-94104	AR	1 IOVE PANEL
105-94107	AR	1 RELAY BOX
105-943101	NE	1 WIRE HARNESS
105-94563	SV	1 MAST MOVEMENT INSTALLATION
105-94563	SV	1 MM-SYSTÉM ASSY
105-94563	AR	1 SP. P MM INSTALATION
		S.P.-MAST MOMENT
105-94563	NE	1 INSTALLATION
105-94564	AR	1 MM INDICATOR
105-945657	NE	1 S P MAST MOMENT INSTALLAT
105-94575	NE	1 MM-DREHUEBERTRAGER
105-94641	NE	2 WIRING HARNESS 19VB
105-96273	OH	2 GH-14 WITH NVG MOD
105-98036	NE	1 CONTROL UNIT FERRANTI 29VE
105-98041	NE	1 CONTROL ROD LONGITUDINAL
105-98043	NE	1 SERVO ACTUATOR
105-980624	SV	1 CSAS CONTROL UNIT
105-98224	NE	1 FOLLOW UP TRIM
105-98301.01	AR	1 LANDING LIGHT
105-983121	NE	1 ELT SYSTÉM STROBE LIGHTS
105-98328	NE	3 WIRING HARNESS
105-98328	NE	1 WIRING HARNESS 22VB
105-98334	NE	1 BLEED AIR HEATING
105-98341	AR	1 CONTROL UNIT
105-98341.06	AR	1 APPARATUS
105-98342	SV	1 CONTROL DEVICE
105-98359	NE	1 CONTROL UNIT, LONG RANGE FUEL
105-98359-1	NE	1 PANEL RANGE TANK
105-98359-9	NE	1 PANEL RANGE TANK
105-98380	NE	1 CONTROL UNIT
105-98383	NE	1 P/C BOARD SWITCHING AMPL
105-98385	NE	1 PIC BD PWR SUP
105-984041	NE	1 LANDING LIGHT
105-98407.01	NE	1 SWITCH PANEL
105-98502	NE	3 WINDSHIELD WIPER SYSTÉM
105-985386	NE	1 INSTL ELT PARTS SANDFILTER
105-985396	NE	1 INSTL EL. SYSTÉM PART SEP. DET. (S
105-98706	AR	1 BOX

105-98751		NE	1 HG. WIRING PLATE MOD.
105A103-1		NE	2 PETR CONTROL BOX ASSY
105-E0006-6		NE	1 BRACKET ASSY
105H213-1		NE	1 PETR VALUE. MOD
105H522-2		NE	1 COMPRESOR
105H535-1		AR	1 COMPRESSOR
105-SB10-35-3.1		NE	1 KIT
105-SB30-105-3.1		NE	1 SB KIT
105-SB60-40/3.1		NE	1 KIT
105-SB80-69-3.1		NE	1 KIT
105V202-1		NE	1 HEAT PUMP FILTER DRIER
1060-1-1	AIRSHOW	SV	1 MODULE
1060-1-3	AIRSHOW	SV	2 DIGITAL POTENTIOMETER MODULE
10-60207-18	5985-01-633-1120	NS	1 WAVEGUIDE
106075-1		SV	1 AC POWER CONTROLLER
10-60897-69		SV	1 WAVEGUIDE
106090-3		NS	4 OUTLET ASSY
106096-1		NS	1 OUTLET ASSY
106096-2		NS	2 OUTLET ASSY
1061-1-1	AIRSHOW	SV	2 CALL MODULE
10-614950-1		AR	1 EXCITER ASSY
10-614950-1C		SV	1 EXCITER ASSY
1062-1-1	AIRSHOW	SV	1 MODULE
106272-1		SV	1 AV PORT
106354-1	106354-1MODB	SV	1 AC POWER CONTROLLER
106356-2		SV	1 OUTLET
1075L26CEW0BFC-QMT05	1075L26CEW0BFC	SV	1 HANDSET
107CDC20		SV	1 PUMP-VACUUM
1080-01	GPS-1200	SV	1 GPS
10811-12		NE	1 CABLE ASSY
108-1249-001		SV	1 10IN TRACK INTERFACE
109-0010-09-103		NE	5 BEARING
109-0011-03-105		NE	10 TORQUE TUBE ASSY
109-0011-76-109		SV	1 CONTROL STICK ASSY
109-0020-06-1		SV	1 TORQUE TUBE AND LEVER ASY
109-0020-51-3		NE	1 BUSHING SLEEVE
109-0020-86-3		OH	1 CONNECTING LINK RIGID
109-0020-87-1		NE	1 ROD END ASSY
109-0020-88-1		NE	1 COUPLING
109-0020-89-1		NE	2 NUT
109-0021-17-1	L108BDM	SV	1 TRIM AND FORCE GRADIENT ACTUA
109-0030-05-1		SV	1 LEVER
109-0030-05-3		SV	1 LEVER
109-0030-17-103		SV	1 SUPPORT

109-0030-19-1		SV	1 BELLCRANK ASSY
109-0030-19-5		SV	2 BELLCRANK ASSY
109-0030-20-5		SV	1 BELLCRANK ASSY
109-0030-26-1		SV	1 SLIDING RACK ASSY
109-0030-28-1		SV	1 BELLCRANK ASSY
109-0032-01-13		SV	1 CONNECTING LINK RIGID
109-0032-01-29		SV	1 CONNECTING LINK RIGID
109-0032-01-61		SV	1 CONNECTING LINK RIGID
109-0032-01-69		NE	1 CONNECTING LINK RIGID
109-0032-02-25		SV	1 CONNECTING LINK RIGID
109-0032-02-41		NE	1 CONNECTING LINK RIGID
109-0032-02-57		SV	1 CONNECTING LINK RIGID
109-0032-07-1		SV	1 CONNECTING LINK RIGID
109-0033-02-103		SV	1 SUPPORT
109-0040-33-1		SV	1 LEVER BELLCRANK ASSY
109-0040-49-5		OH	1 SUPPORT ASSY
109-0040-49-5		SV	1 SUPPORT ASSY
109-0101-11-7		NE	2 SHIM
109-0101-61-1		NE	1 RING
109-0101-62-107		NE	25 BOLT MAIN ROTOR LOCKING
109-0104-04-1		NE	2 WASHER
109-0110-53-1		SV	1 SUPPORT ASSY
109-0110-70-3		NE	5 BUSHING
109-0110-70-3		NE	5 BUSHING
109-0111-09-103		NE	1 SLIDING RING ASSY
109-0111-25-101		NE	4 PITCH CONTROL LEVER BUSHING
109-0111-28-107		NE	1 PIN DROP STOP ASSY
109-0111-32-103		NE	16 SLEEVE BUSHING
109-0111-34-101		NE	1 UPPER FLAPPING LIMITER
109-0111-42-109		NE	4 FIXED SUPPORT
109-0112-05-107		SV	8 MAIN ROTOR LAG DAMPER
109-0130-91-105		SV	1 PITCH CHANGE SLIDER ASSY
109-0131-34-107		NE	8 SHIM TR TRUNNOIN
109-0135-03-101		SV	1 LEVER TR ASSY
109-0135-07-101		NE	10 BUSHING
109-0135-07-103		NE	14 BUSHING
109-0135-09-101		NE	7 BALANCING PLUG
109-0135-16-101		NE	9 LINER ASSY BEARING
109-0135-17-101		NE	2 BOOT BELLOW AFT
109-0210-29-103		NE	12 WASHER LAMINATED
109-0210-31-208M01	109-0210-31-208	NE	1 RH AFT FAIRING
109-0301-26-149	109-0301-26-149M01	NE	1 PANEL ASSY LEFT
109-0301-26-150		NE	1 PANEL ASSY
109-0301-27-129		NE	2 BRACKET ANGLE

109-0310-02-102		NE	1 BRACKET
109-0310-02-124		NE	6 SHIM
109-0310-02-139		NE	20 FRAME OUTSIDE LH
109-0310-02-140		NE	14 FRAME OUTSIDE RH
109-0310-02-206		NE	1 DOUBLER OUTSIDE RH
109-0310-02-207		NE	6 DOUBLER LH
109-0310-02-212		NE	5 BRACKET RH
109-0310-02-319		NE	4 DOUBLER
109-0310-03-2		NE	2 LATCH HOUSING RH
109-0310-27-13		NE	1 RETAINER
109-0310-27-15		NE	1 RETAINER
109-0310-27-16		NE	1 RETAINER
109-0310-27-195		NE	2 DOUBLER LH
109-0310-27-196		NE	1 RETAINER
109-0310-27-197		NE	2 RETAINER LH
109-0310-27-198		NE	1 STRIP RETAINER
109-0310-27-31		NE	1 RETAINER
109-0310-47-101		NE	1 HINGE ASSY REAR
109-0310-94-104M01	109-0310-94-104	NE	1 WINDSHIELD RETAINER RH
109-0310-94-105	109-0310-94-105M01	NE	2 CENTRAL RETAINER
109-0310-94-108		NE	1 RETAINER SUP RIGHT
109-0310-94-108		NE	1 RETAINER
109-0310-97-109M01		NE	1 RETAINER LOWER LH
109-0310-97-115M01		NE	1 LATERAL RETAINER PORT
109-0310-97-116M01		NE	1 LATERAL RETAINER RH
109-0310-97-121M01		NE	1 WINDOW RETAINER
109-0313-03-141		NE	4 SUPPORT
109-0313-58-113		NE	1 LH LWR NOSE COVER
109-0313-61-113		NE	3 GASKET
109-0313-88-107		NE	1 PEELING SHIM
109-0313-88-111		NE	1 PEELING SHIM
109-0313-89-125A1		NE	1 DOOR ASSY
109-0313-90-105		NE	1 FWD HINGE ASSY
109-0313-91-101		NE	1 HINGE ASSY AFT
109-0315-22-101		NS	2 MACHINED DOUBLER
109-0320-05-127M01	109-0320-05-127	NE	1 FIREWALL ASSY
109-0320-26-15		NE	1 UPPER FRAME RIB
109-0320-48-311		NE	1 ANGLE
109-0322-10-507		NE	1 BRACKET ANGLE INTERNAL LH
109-0322-76-111		SV	1 DOOR ASSY
109-0322-76-111		SV	1 PANEL ASSY
109-0322-76-203		NE	1 PANEL ASSY
109-0323-33-3		NE	14 PIN STRAIGHT HEADED
109-0324-35-101		NE	1 SLIDING DOOR HOUSING ASSY

109-0324-35-102		NE	1 ASSY HOUSING PIN
109-0324-35-103		NE	1 HOUSING PIN
109-0324-35-104		NE	1 PIN HOUSING ASSY
109-0324-73-119		NE	1 TRAILING
109-0325-08-1		NE	1 BRACKET
109-0325-08-1		SV	1 BRACKET ASSY
109-0325-08-111		NE	1 LOWER FITTING
109-0325-19-205		NE	1 ASSY LOCK
109-0325-34-109		SV	2 CATCH SAFETY
109-0326-47-107M01		NE	1 CHANNEL SEAL LH
109-0326-47-108	109-0326-47-108M01	NE	4 CHANNEL SEAL RH
109-0330-12-7		NE	1 ANGLE
109-0342-43-203M01	109-0342-43-203	NE	1 PANEL COVER UP
109-0360-05-1		NE	1 FORK
109-0360-06-101		NE	1 BRACE DRAG
109-0360-07-103		NE	1 BELLCRANK LH
109-0360-07-104		NE	1 BELLCRANK RH
109-0360-26-101		NE	1 THREADED BUSHING
109-0360-28-102		NE	1 LOWER CARRIAGE ASSY RH
109-0360-46-125		NE	1 EDGE LH
109-0360-49-217		NE	2 STRAP
109-0360-49-402		SV	1 DOOR ASSEMBLY COCKPIT RH
109-0360-49-402		AR	1 COCKPIT DOOR ASSY RH
109-0360-60-103		NE	1 DOOR ROD
109-0360-74-123		NE	2 WINDOW ASSY
109-0360-74-124		NE	2 WINDOW ASSY
109-0361-09-101		NE	3 LATCH DOOR HOOK LH
109-0361-09-102		NE	6 HOOK RH OPP
109-0361-29-103		NE	1 SHIM PEELING
109-0361-41-104		NE	2 LEVER ASSY
109-0361-45-101		NE	4 PIN ASSY
109-0361-66-101		NE	12 LATCH SEAT
109-0361-66-101		NE	8 SEAT LATCH
109-0361-78-117		NE	10 SEAL BASKET
109-0361-78-117		NE	7 SEAL BASKET
109-0361-82-103		NE	1 HANDLE PIVOT
109-0361-86-101		NE	1 HANDLE
109-0361-93-103		NE	21 WELDED MOUNTING ASSY
109-0361-93-103		NE	15 WELDED MOUNTING ASSY
109-0361-93-109		NE	2 PEELABLE SHIM
109-0361-93-111		NE	9 PLATE
109-0361-93-111		NE	6 EXTERNAL PLATE
109-0361-93-117		NE	2 PEELABLE SHIM
109-0362-05-105		NE	2 CONNECTING LINK DOOR

109-0362-11-104	NE	1 SHAFT
109-0362-20-103	NE	1 SHAFT
109-0362-20-103	SV	1 SHAFT
109-0362-20-103	NE	1 SHAFT
109-0362-23-207	NE	1 DOOR LATCH CONTROL ROD RH
109-0362-23-208	NE	1 DOOR LATCH CONTROL ROD RH
109-0362-24-103	NE	3 SHAFT ASSY
109-0362-24-103	NE	3 SHAFT
109-0362-24-105	NE	1 SHAFT
109-0362-25-107	NE	1 HOUSING
109-0370-50-103	NE	1 SUPPORT TR SHAFT
109-0370-59-107	NE	1 ANGLE AFT LH
109-0370-59-203M01	NE	1 RIGHT ANGLE
109-0370-59-219	NE	1 ANGLE DETAIL
109-0371-28-1	NE	1 SUPPORT
109-0371-32-3	NE	1 SHIM
109-0371-32-4	NE	1 SHIM
109-0371-33-13	NE	2 COVER ACCESS
109-0372-24-101	NE	1 PANEL ASSY
109-0372-34-101M01	NE	1 ANGLE LH PROFILE
109-0372-34-103	NE	1 ANGLE LH
109-0372-53-205	NE	1 BRACKET
109-0372-57-105	NE	1 SKID ASSY TAIL
109-0372-94-107	NE	1 STRIP RETAINER
109-0373-21-107	NE	2 SHIM
109-0373-21-109	NE	1 SHIM
109-0400-03-109	AR	1 A109 TRANSMISSION ASSY
109-0400-03-109	SV	1 A109 TRANSMISSION ASSY
109-0405-13-1	NE	1 NUT RING STOP
109-0405-94-103	NE	1 WASHER
109-0406-52-1	NE	1 SPRING
109-0406-52-103	NE	1 SPRING
109-0406-53-1	NE	1 SCREW REGULATOR
109-0407-41-101	NE	3 RING
109-0407-43-103	NE	3 RING LOCK
109-0407-43-105	NE	1 RING LOCK
109-0407-72-103	NE	1 SHIM UPPER
109-0407-80-101	NE	1 THERMOSWITCH
109-0424L02-101	NE	1 BEARING BALL
109-0425-06-5	NE	2 PTR DRIVESHAFT PIN
109-0425-38-1	NE	1 BUSHING SLEEVE
109-0425-45-105	NE	1 PIN
109-0425-45-107	NE	1 PIN CHECKING
109-0425-49-101	NE	1 ADAPTER SLIDING

109-0425-70-103	SV	1 RING NUT
109-0425-72-101	NE	5 RETAINING RING
109-0435-15-1	NE	2 SPACER
109-0435-15-103	NE	1 SEAL SPACER
109-0435-17-3	NE	1 PIN
109-0435-24-3	SV	2 OIL INDICATOR
109-0435-24-3	NE	3 OIL INDICATOR
109-0435-24-3	NE	3 INDICATOR OIL
109-0440-06-105	SV	3 TAIL GEARBOX ASSY 90 DEG
109-0445-15-103	NE	1 SEAL
109-0445-50-101	NE	1 SEAL TR GB INPUT
109-0445-52-101	NE	3 SEAL
109-0501-11-1	NE	2 PIN BEARING
109-0501-20-1	NE	3 BUSH
109-0501-21-3	NE	2 BOLT MACHINE
109-0504-24-1	NE	4 WASHER NONMETALLIC
109-0506-11-1	NE	1 SPRING BRACKET
109-0506-99-101	NE	1 ROTOR BRAKE CONT CABLE
109-0512-14-105	NE	1 PIVOT
109-0518-45-103	NE	1 TUBE ASSY METAL
109-0570-03-110	NE	1 ASSEMBLY SKID RH
109-0570-06-104	SV	1 LANDING GEAR SADDLE RH
109-0570-09-103	NE	1 LOWER SUPPORT AFT CROSS BEAM
109-0570-10-103	NE	1 BULLONE SPECIALE
109-0570-23-106	NE	1 SHOE ANTIABRASION PROOF REAR
109-0570-32-107	SV	3 LANDING SKID DAMPER
109-0600-37-105	NE	2 SPACER
109-0601-47-107	SV	1 OIL BREATHER TUBE ASSY
109-0601-47-141	NE	1 OIL BREATHER PIPE ASSY
109-0601-66-111	NE	24 GASKET
109-0601-66-111	NE	24 GASKET
109-0601-81-119	AR	1 EXHAUST TUBE
109-0601-81-143	SV	1 EXHAUST DUCT ASSY LH
109-0601-83-109	NE	1 AIR INTAKE DUCT ASSY
109-0602-17-105	SV	1 ASSY LH SUPPORT
109-0602-17-106	SV	1 ASSY RH SUPPORT
109-0605-50-105	NE	1 LINK SUPPORT ASSY
109-0605-53-101	SV	2 BRACKET AFT
109-0605-63-109	SV	1 ENGINE MOUNT TRIPOD ASSY AFT F
109-0605-69-103	SV	1 BIPOD ASSY ENGINE MOUNTS
109-0605-74-103	NE	2 ENGINE BRACKET
109-0610-19-5	NE	1 RUBBER TUBE
109-0610-20-1	NE	2 PLATE
109-0610-20-3	NE	2 PLATE

NSCM A-126

109-0610-48-1		SV	2 DRAIN DISH
109-0612-23-1		SV	2 GUARD ASSY DRAIN
109-0613-93-101		NE	1 FLEX HOSE
109-0614-18-101		NE	2 FILLER
109-0619-06-1		NE	6 SEAL
109-0620-88-101		NE	1 LINK STRAP ASSY
109-0621-31-101		NE	1 METALLIC TUBE ASSY
109-0630-70-103		NE	1 CABLE ASSY
109-0630-70-105	65761-1	SV	2 GEARBOX ASSY W RVDT OPTION
109-0641-43-167		NE	1 DOOR ASSY
109-0641-46-134		NE	1 SEAL
109-0641-71-301		NE	1 LEFT DOOR ASSY
109-0641-90-303		NE	1 LEFT DOOR COWLING
109-0641-90-304		NE	1 RIGHT DOOR COWLING
109-0680-11-101		NE	1 DUCT
109-0702-97-103		NE	1 FERMO
109-0702-97-105		NE	1 STOP
109-0710-31-111		NE	1 AIR DUCT ASSY
109-0711-08-1	109-0711-08-3	NE	1 CONTROL AIR TEMP SYSTEMS
109-0712-10-109		NE	1 CUSHION SEAT BACK ASSY
109-0712-10-111		NE	1 HEAD CUSHION
109-0714-82-102		NE	2 DUCT ASSY AIR CONDITIONING RH
109-0714-82-201		NE	1 DISTRIBUTION BOX ASSY
109-0716-79-119		SV	1 SUPPORT ASSY
109-0718-77-101		NE	2 HANDLE SLIDING DOOR
109-0722-10-101		NE	2 BUSHING
109-0729-08-111	15DA01U	OH	1 INDICATOR, TACH
109-0729-08-5	15DA01-TYP1201	OH	1 INDICATOR, TACH
109-0729-13-3	5021-3048	OH	1 INDICATOR, TURB OUT TEMP
109-0729-19-1	AG-06-1	SV	1 COMMUNICATION CONTROL UNIT
109-0729-19-3	AG-06-1-A	SV	1 PANEL, POWER DISTRIBUTION
109-0729-20-107	PAL-12-7	OH	1 CONTROL SIGNAL
109-0729-21-105	PGI-12-3	OH	1 PANEL ALARM
109-0729-22-113	RBE25-11	OH	1 DETECTOR, RPM LIMIT
109-0729-22-5	RBE15-5	OH	1 DETECTOR, RPM LIMIT
109-0729-23-103	04DB04A-TYP1857	OH	1 INDICATOR LIQUID LEVEL
109-0729-26-3	14DB01G-TYP1360	OH	1 INDICATOR, OIL TEMP AND PRESS
109-0729-27-109	14DB01F	OH	1 INDICATOR, OIL TEMP
109-0729-27-113	14DB24	OH	1 INDICATOR, OIL TEMP
109-0729-27-3	14DB01F-TYP1359	OH	1 INDICATOR, OIL TEMP
109-0729-28-1	4344-3022	OH	1 INDICATOR, FUEL PRESSURE
109-0729-28-3	124-003	OH	1 INDICATOR, FUEL PRESSURE
109-0729-29-1	4344-3021	OH	1 INDICATOR, HYD PRESS
109-0729-29-109	14DB01F	OH	1 INDICATOR, OIL TEMP

109-0729-29-3	124-419-1	OH	1 INDICATOR, HYDRAULIC PRESS
109-0729-30-109	13DC02B-TYP1350	OH	1 INDICATOR, DUAL TORQUE
109-0729-31-21	PAL19-21	OH	1 PANEL ALARM
109-0729-31-5	PAL19-5	OH	1 PANEL ALARM
109-0729-32-1	124-486	OH	1 TOT INDICATOR
109-0729-32-115	08DC06G	OH	1 INDICATOR
109-0729-32-117	08DC06N	OH	1 INDICATOR, ITT
109-0729-33-1		SV	2 VSI
109-0729-34-1	16034	OH	1 ALTIMETER
109-0729-38-1	124-487	OH	1 INDICATOR, DUAL VOLTMETER
109-0729-38-3	124-488	OH	1 INDICATOR, DUAL VOLTMETER
109-0729-46-1		SV	1 BOX, AMPLIFIER
109-0729-50-1	PMB20-1	SV	1 PANEL, CONTROL
109-0729-51-1	PMA10-1	SV	1 PANEL ASSY
109-0729-87-101	06DB43	OH	1 INDICATOR, DUAL PRESSURE
109-0729-96-103		SV	1 AUDIO GENERATOR
109-0729-99-105	DCEB37V-1	SV	4 ELECTRICAL BOX
109-0730-16-113	15DA03B-TYP1487	OH	1 INDICATOR TACH
109-0749-93-101		NE	1 VNL PANEL
109-0760-03-34		SV	1 TANK ASSY WELDED
109-0760-42-107	4212403	SV	1 PUMP HYDRAULIC AP1.5V-01-03
109-0760-53-101		AR	1 PUMP ROTOR BRAKE
109-0763-86-101		NE	1 TUBE ASSY METAL
109-0784-82-209		NE	1 EXTENSION TNC/TPS
109-0810-79-123		NE	2 BRACKET AIR COND
109-0811-76-153		NE	4 DECAL PLACARD
109-0821-47-101		NE	37 ROLLER
109-0822-68-113		SV	1 SLIDING WINDOW
109-0822-68-113		NE	1 SLIDING WINDOW
109-0822-68-113		NE	1 WINDOW ASSY
109-0822-75-132		SV	1 ROD TUNING
109-0822-75-137		NE	4 WASHER
109-0822-75-139		NE	4 WASHER
109-0823-29-113		NE	2 BOLT
109-0823-29-117		NE	5 WASHER
109-0823-31-105		NE	1 SUPPORT
109-0823V36-101		NE	1 HOSE INSULATED ASSY
109-0859-90-103M01	109-0859-90-103	NE	1 DOUBLER
109-0881-33-210		NE	1 SUPPORT ASSY RH OPP
109-0881-33-316		NE	1 FITTING RH SLIDING DOOR
109-0881-34-103		NE	1 RIB
109-0881-34-109		NE	1 ANGLE LH
109-0881-34-111		NE	1 COVERING
109-0881-34-113		NE	1 SHIM SPACER

109-0881-34-121		NE	1 ANGLE
109-0881-34-123		NE	1 COVER
109-0881-34-129		NE	1 ANGLE LH
109-0882-29-121		NE	1 ANGLE PLATE
109-0900-08-109	EAP12-15	SV	1 WARNING LIGHT PANEL
109-0900-21-107		NE	2 CUP
109-0900-38-101		SV	1 CONTROL PANEL COMPASS
109-0900-42-2A08	10563D02M13	AR	1 AGUSTA DISPLAY
109-0900-49-107		SV	1 PANEL ASSY FUEL CONTROL
109-0900-54-211		NE	1 FUEL PROBE TRANSMITTER
109-0900-54-211		SV	2 FUEL PROBE TRANSMITTER
109-0900-54-211		SV	1 FUEL PROBE TRANSMITTER
109-0900-66-3A01	193860-11	SV	1 INTEGRATED DISPLAY SYSTEM
109-0900-66-3A02	193860-13	SV	2 INTEGRATED DISPLAY SYSTEM
109-0952-84-107		NE	1 DOUBLER
1092T100MBB	105-93921	OH	1 ANTI ICE ACTUATOR
10933001-1		NE	1 LITE ASSY KIT LEFT
109-3900-30-1		NE	1 PIN STRAIGHT HEADED
109-3900-37-1		NE	7 PIN TOW
109-3900-51-1		NE	1 CLEVIS FOR TOW BAR
109-4160-19-101		OH	1 MIDDLE LEVER ASSY
109-4160-21-101		NE	2 BUSSOLA
109-8131-22-111		NE	12 WEIGHT, STATIC BALANCE T/R
109-8131-22-115		NE	24 MASS BALANCING
109-8131-22-117		NE	8 MASS BALANCING
109-8131-22-117		NE	16 WEIGHT COUNTER BALANCE
109-8131-30-109		NE	2 BUSHING
109-8131-38-117		NE	8 SHIM
109-8131-38-119		NE	4 SHIM
109-8131-38-121		NE	10 SHIM 2.685-2.695
109-8131-38-123		NE	10 SHIM 2.705-2.715
109-8131-38-125		NE	8 SHIM 2.725 - 2.735
109-8131-38-127		NE	12 SHIM 2.745-2.755
109-8131-38-129		NE	14 SHIM 2.765 - 2.775
109-8131-38-131		NE	10 SHIM 2.785-2.795
109-910106-33		NE	14 WASHER
109-A816-03-126-1		NE	1 BRACKET ASSY
109-A816-04-119		AR	1 AFT LITER BOARD MOUNT
109-A816-05-117-1		NE	1 LITER SUPPORT GUARD
109-A816-09-111-1		NE	2 AFT SEAT BOTTOM
109A816-20-113-1		NE	5 LITTER LATCH DISC ASSY
109-A816-50-116-2		NE	1 POUCH RH
1-10-015223REVC		NE	1 RESTRAINT 3PT BOLT ON REEL LH
1100-A-2500	DBA-1160MR	SV	1 ASSY SATELLITE ANT RCVG FLTD

1-10-175301BCR		NE	1 3 POINT AUTOM HARNESS
110-323		NE	1 ANTENNA KIT
110-328-0		SV	1 406 BLADE ANTENNA
110-337		SV	1 ANTENNA
110-338		SV	1 ANTENNA ARTEX
110-338		AR	1 ANTENNA
1-1041-144		NS	2 COMPONENT
11097-1		SV	1 SWITCH IMPACT
1-10-E50301	1-10-E50301/AGU080	SV	1 SEAT BELT AND HARNESS ASSY
110PN01Y01	704A47621035	OH	1 TACHOMETER IND
1110-A-0501-10	CNX-100	SV	1 CABIN NETWORK XCELERATOR
1110-A-0501-20	CNX-200	OH	2 ACCELERATOR, NETWORK
111-11111-0000	TS10B	NS	1 HARNESS
1-1118ZG		SV	2 PRESSURE XMTR
111302-5		OH	2 H-S-I-
111303-4		SV	1 ADI
1114-039480		NE	1 HARNESS
1120-81024		SV	1 VIB ABSORBER
1121-10151W1		NE	E GUIDE SLEEVE
1121-21451		NE	1 HOLDER
1121-31508		AR	1 ROTOR WAVE
1121-31566		NE	1 SHAFT
11213AL		SV	1 PRESSURE SWITCH
1121-41903.24		NE	2 BELLOWS
1121-41903.24		NE	1 BELLOWS
1121-51002		NE	1 SKID SHOE
1121-62671		NE	1 HOUSING ASSY
1121-70561		NE	3 HEADREST
1121-70651.71		AR	1 TUBE
1121-70651.75		AR	1 TUBE
1121-70651.89		AR	1 TUBE
1121-71124		NE	1 COVER PLATE ASSY
113300-03A1		AR	5 FUEL PUMP
11336AA		OH	1 VACUUM GAUGE
1135K5-1		NE	3 KIT FDC BARRIER FILTER EC135
1138PGCP1-15		SV	1 SWITCH LOW PRESS OIL
114-049		OH	1 IND, FAN SPEED
115-01771-01	GTX345	SV	1 RACK
1151324-1M218		SV	2 ELT - GERMANY CODED
115-201-3		SV	1 PRESSURE INDICATOR
115-201-4		SV	1 DUAL PRESS IND
115-201-4		NE	1 SIGNALCONDITIONER
115-230NVG	AC410047-NVG	OH	1 AIR TEMP IND
1152394-1		SV	1 ELT BRACKET

1152394-2		SV	1 ELT BRACKET
1152572-2	PC-251-123J2	SV	1 STATIC INVERTER
115-810034		NE	4 SHIM ACTUATOR LANDING GEAR
1159AV50723-1	W50723	NS	2 HARNESS
1159C20080-23		NE	1 CABLE
1159H47440-1		AR	2 PULSATION DAMPER
1159SB40396-11		NE	1 BRACKET
1159SB40588-3		SV	1 NOSE WHEEL PANEL
1159SB47807-13		NS	1 BRACKET
1159SB49016-1		FN	1 APU WIRING HARNESS
1159SCAV462-5	700-D36409A-008	SV	1 NAV CONTROL
1159SCAV462-7	700-D36411A-008	SV	1 ADF CONTROL
1159SCAV462-9	700-D36415A-004	SV	2 MRK CONTROL
1159SCF208-1	DRA45C-26	SV	1 OVERSPEED WARNING SWITCH
1159SCF412-11	523273	OH	1 ENGINE MONITOR
1159SCF426-2	128-413	SV	3 EL INDICATOR
1159SCF427-3	128-406	SV	2 ELPU
1159SCF452-5	3A1320A	AR	1 FDR POSITION SENSOR
1159SCF578-5		SV	1 LIGHTPLATE REV D
1159SEAV40123		SV	1 APU TEST BOX
115-MA1-132		NE	4 FAN ASSEMBLY
116012-0000	5935011959995CW	NS	3 CONNECTOR
1161-21-140		FN	2 NAVIGATION COMPUTER UNIT
117-0550-2		AR	1 KLIMA
117-0550-3	117-0550-3-2	NE	1 AIR CONDITIONING UNIT
117-10521		NE	1 BRAKE HAND LEVER
117-1111-01.00		NE	1 TANK COMPL INSTALL
117-11123.06		NE	1 HEX BOLT
117-11137		NE	1 TORQUE STRAP
117-11203-01		NE	1 ROD ASSY
117-11203-01		SV	1 ROD ASSY
117-12001W3		NE	1 OIL DRAIN HOSE
117-12010W11		NE	1 WRENCH SET
117-12010W15		NE	2 PULLER
117-12010W19		NE	2 HOLDER
117-12010W2		NE	1 PUSHER
117-12010W28		SV	1 MOUNT
117-12010W29		NE	1 PULLER
117-12010W3		NE	1 PUSHER
117-12010W40		NE	1 GUIDE SET
117-12010W43		NE	1 PULLER
117-12010W44		NE	1 PULLER
117-12010W45		NE	1 PULLER
117-12010W56		NE	1 GUARD

117-12010W63	SV	1 PUSHER
117-12010W63	NE	1 PUSHER
117-12010W68	NE	1 PUSHER
117-12010W70	NE	1 MOUNT
117-12010W70	NE	1 MOUNT
117-12010W72	NE	1 WORKING STAND
117-12010W75	NE	1 REACTION ARM
117-12020W2	NE	1 PUSHER
117-12020W4	NE	1 Montagewerkzeug
117-12020W7	NE	2 PUSHER
117-12060W5	NE	1 PUSHER
117-12110W6	NE	1 PUSHER SET
117-12140-01	NE	1 ACC. GEARBOX ASSY LH
117-12140W2	NE	1 PUSHER
117-12140W7	NE	1 PULLER
117-12150W1	NE	1 PUSHER
117-12150W2	NE	1 PUSHER
117-12170W1	NE	1 PUSHER SET
117-12250W16	SV	1 PUSHER
117-12250W19	NE	1 IMPRESSIVE TOOL
117-12250W6	NE	1 PUSHER
117-12256-01	NE	1 SEAL RING
117-12300W5	NE	2 PUSHER
117-12300W7	NE	1 PUSHER
117-12303-01	FN	1 SEAL SPACER
117-12303-01	NE	1 SPACER
117-12415-01	SV	1 MOUNT ASSY
117-12601-01	NE	2 BALL BEARING
117-12602-01	NE	8 BALL BEARING
117-12603-01	NE	10 ROLLER BEARING
117-12605-01	NE	5 ROLLER BEARING
117-12606-01	NE	6 ROLLER BEARING
117-12607-01	NE	10 ROLLER BEARING
117-12609-01	NE	10 BALL BEARING
117-12610-01	NE	4 ROLLER BEARING
117-12610-01	NE	2 ROLLER BEARING
117-12612-01	NE	6 ROLLER BEARING
117-12614-01	NE	8 ROLLER BEARING
117-12615-01	NE	6 ROLLER BEARING
117-12616-03	NE	8 BALL BEARING
117-12617-01	NE	6 ROLLER BEARING
117-12619-01	NE	4 BALL BEARING
117-12621-01	NE	8 ROLLER BEARING
117-12622-01	NE	12 BALL BEARING

117-12623-01	NE	7 BALL BEARING
117-12645-05	SV	5 LUBE PUMP ASSY LH
117-12645-05	SV	1 SCHMIEROLPUMPE
117-12645-07	SV	2 LUBE PUMP ASSY RH
117-13901.01	NE	1 HUB CAP
117-141081	NE	2 MAIN ROTOR HEAD
117-141081	AR	1 HEAD OF PROPELLER
117-141831	SV	7 INNER SLEEVE ASSY
117-141831	AR	4 INNER SLEEVE ASSY
117-152111	NE	1 TYP CAP ASSY
117-15856 C	NE	1 ELASTIC BUSHING
117-15860	SV	10 CONNECTION FITTING
117-16010-01	SV	2 MAIN DRIVE SHAFT
117-21181-01	NE	3 WINDOW ASSY LH
117-21197-04	NE	1 GUSS SET
117-21199-52	SV	1 WINDSHIELD ASSY RH
117-21199-52	NE	1 WINDSHIELD ASSY RH
117-22462-01	NE	2 STAY
117-22581-01	SV	4 SIDE WINDOW ASSY LH
117-22953-21	SV	2 COVER ASSY
117-23392-08	NE	1 BLANKET ASSY RH
117-24101-18	NE	2 COCKPIT DOOR ASSY RH
117-24202-13	NE	1 CABIN DOOR ASSY LH
117-24234-02	NE	1 STOPPER RH
117-24253-01	NE	4 SHIM
117-24261-03	NS	2 SEAL
117-24261-07	FN	1 SEAL
117-24261-09	FN	1 SEAL
117-24261-09	NE	1 SEAL
117-24261-11	NE	1 SEAL
117-24283-08	NE	1 RAIL RH
117-24285-01	NE	2 SPACER
117-24292-13	NE	1 EMERG. RELEASE MECH. ASSY L
117-24292-13	NE	1 EMERG. RELEASE MECH. ASSY LH
117-24302-02 "H17"	NE	2 CARGO DOOR
117-24612-01	NE	1 HINGE ASSY
117-24627-01	FN	1 SHIM
117-24627-01	NE	1 SHIM
117-24646-05	SV	1 DOOR LOCKING CYLINDER
117-30640	AR	1 RETROF. HORIZ. STAB FIN ASSY
117-31547	NE	1 SHAFT
117-315671	NE	1 SHAFT
117-31714	NE	1 TAIL ROTOR HEAD
117-31714	NE	1 TAIL ROTOR HEAD

117-317391		SV	1 TAIL ROTOR HEAD
117-317411		SV	2 TAIL ROTOR BLADE ASSY
117-31742		AR	8 TAIL ROTOR BLADE
117-31748		SV	1 TAIL ROTOR BLADE BONDED
117-384031-1	20B380-5	OH	1 TURN AND BANK INDICATOR
117-410271		NE	1 LATERAL TRIMMER
117-41110-02		NE	1 COVER ASSY
117-41111-01		NE	1 BOOT ASSY
117-41201-01		NE	4 TORQUE TUBE ASSY
117-41201-01		NE	4 TORQUE TUBE ASSY
117-412581		NE	1 GRIP ASSY
117-41308-05		NS	1 BUSHING
117-41314-01		NE	1 BOOT ASSY
117-41340-01		NE	1 HOUSING ASSY
117-41634		NE	1 PEDAL ASSY RH
117-41904-07		SV	1 CARDANRING, TWO PART
117-42185-25		NE	1 CONTROL ROD
117-42185-25		NE	1 CONTROL ROD ASSY
117-44001W5.06		NE	1 WEDGE
117-44001W5.07		NE	1 WEDGE
117440-1		SV	1 BASE, RADIO BEACON
117-44115W3		NE	1 PUSHING OUT TOOL
117459-2		SV	1 ADELTA BEACON
117-467531		NE	1 TRANSFER VALVE
117-5000211		NE	1 SKID PROTECTIVE PLATE
117-601131		SV	1 FIRE WALL AFT LOWER LH
117-601141		SV	1 FIRE WALL AFT LOWER RH
117-61268-01		NE	1 FITTING
117-61311-01		NE	3 PRESS SWITCH
117-62616-01		NS	1 BOLT
117-63518-01		NS	1 BUSHING
117-64134-01		NE	1 SEAL
117-64141-21		NE	1 FILLER ASSY
117-64141-21		NE	1 FILLER ASSY
117-64151-03		NE	12 BOOSTER PUMP
117-64151-03		SV	4 BOOSTER PUMP
117-64152-01		SV	1 FUEL QUANTITY TRANSMITTER
117-64155-01		NE	2 SEAL
117-64159-01		NE	1 METAL O SEAL
117-64159-01		NE	1 SEAL
117-64172-03		SV	6 SUPPLY FUEL CELL ASSY
117-64173-01		SV	1 REAR FUEL CELL ASSY
117-64173-01		NE	3 REAR FUEL CELL ASSY
117-64174-01		SV	1 FWD FUEL CELL ASSY

117-64174-01		SV	3 FWD FUEL CELL ASSY
117-64174-01		SV	2 FWD FUEL CELL ASSY
117-64569-03		NE	1 PRESS SWITCH FUEL
117-64664-11		NE	1 CONNECTOR ASSY
117-66260-01		NE	1 FIRE WALL ASSY AFT LH
117-67122-01		NE	1 STRAINER ASSY
117-67172-01		NE	1 OIL TANK LH
117-67172-02		NE	1 OEL TANK RH
117-68101-01		SV	1 SCROLL ASSY
117-68121-01		NE	1 HOUTTING
117-68132-01		NE	6 SHIM
117-69005-03		OH	1 INDICATOR, TORQUEMETER
117-712261		NE	1 COVER SEAT PAN
117-712271		NE	1 COVER BACK REST
117-71305-01		NE	3 WIPER CONVERTOR
117-71305-01		AR	1 CONVERTER
117-72150-01		NE	2 NOZZLE ASSY LH
117-72150-02		NE	2 NOZZLE ASSY RH
117-72461-01		SV	1 SENSOR
117-725021		NE	1 REWORK BLEED AIR HEATING
117-725041.08		NE	1 COUPLING SLEEVE
117-72582-03		SV	1 MIXING VALVE
117-72582-05		NE	2 MIXING VALVE
117-72582-05		NE	1 MIXING VALVE
117-72623-01		NE	1 COVER
117-770051		NE	1 COVER ENGINE INLET
117-770071		NE	1 COVER ENGINE OUTLET
117-80023		NE	1 SUPPORT ASSY
117-80036		NE	1 INST. RAILS
117-80044		NE	2 FUEL VENT AND DRAIN LINES
117-80047		NE	1 PROV FLOOR
117-80064		NE	1 ASSEMBLY
117-80070		AR	1 DECKEL
117-80078		NE	1 MOD OF INTERIOR PANEL UP RH
117-80094		NE	1 SCOOP
117-80127		SV	1 LOAD HOOK DETACH. PART
117-80156		NE	1 STRUT
117-80168		SV	1 VIBRATION ABSORBER
117-80170		SV	1 VIBRATION ABSORBER
117-80170V001		SV	2 VIB ABSORBER REPAIR
117-80175	117-80175B2	NE	3 TANK
117-80180		SV	1 VIBRATION ABSORBER
117-80180		NE	1 VIBRATION ABSORBER
117-80284.09		NE	1 FITTING

117-80355	AR	1 VIP FIXED PROVISION
117-80356	NE	1 MOD SET VIP-LRFT
117-804181	NE	1 ANTI STATIC CABLE
117-804251.10	NE	1 CONSOLE
117-81104-01	NE	1 COVER ASSY
117-81353-01	NE	1 WIRING HARNESS
117-83617-01	NE	2 PROTECTOR ASSY
117-83617-01	AR	2 PROTECTOR ASSY
117-83617-03	AR	1 PROTECTOR ASSY
117-84045	NE	1 SKID PROTECTIVE PLATE
117-841014	NE	1 SCAVENGE OIL FILTER SYSTÉM
117-84109	NE	2 SETTLING PROTECTOR
117-84113	NE	1 SETTLING PROTECTOR ASSY
117-84271	NE	12 WEIGHT ASSY LH
117-84271	NE	1 WEIGHT ASSY LH
117-84272	NE	2 WEIGHT ASSY RH
117-84272	NE	7 WEIGHT ASSY RH
117-84292	NE	1 WEIGHT RH ASSY
117-84338	NE	1 CARDS BAG
117-84442	NE	1 STOP
117-84624	NE	1 WATER CONDUCTORS
117-847054	SV	1 SETTLING PROTECTOR
117-85111-01	AR	1 SEAT BANK
117-85171-03	NE	3 CO-PILOTEN SEAT
117-85171-03	AR	1 SEAT
117-85194-23	NE	1 INT. PANEL CARGO WHITE ASSY - K
117-860024	NE	1 PEDAL COVER ASSEMBLY
117-86061	NE	1 COVER F PASS SEATS
117-86111	NE	1 HIGH DEFIT. SEAT
117-86119	NE	1 HOSE ASSY
117-86138	NE	1 FLAP ABOVE
117-86146	NE	1 FITTING BELOW
117-86214	NE	1 INST JUCTION BOX
117-86249	NE	2 SEARCHLIGHT SX16
117-86307	NE	1 OUTB. L. SP. PERM. FIXT. VA
117-879111	NE	1 INSTALATION KIT
117-88024	NE	1 PLATE ASSY
117-883541	SV	1 MOTHER BOARD
117-884311	SV	1 SIGNAL PROCESSING SPAS
117-88659	SV	1 BELLCRANK ASSY
117-88814	NE	5 TRANSDUCER
117-897321	NE	1 LAMP
117-89783-01	NE	2 FUEL PUMP FAIL DETECTOR
117-89783-01	NE	1 FUEL PUMP FAIL DETECTOR

117-902011		OH	1 TRIPLE INDICATOR RPM
117-902011		SV	1 TRIPLE TACH INDICATOR
117-902031	124T499-7	SV	2 TOT INDICATOR
117-902041		OH	2 ENG. OIL T/P INDICATOR
117-902061	124L507-6	SV	1 DUAL AMMETER 200A
117-902061		NE	1 DUAL AMMETER INDICATOR
117-902141		AR	1 CSAS
117-902141		SV	1 CONTROL UNIT CSAS
117-91034-03		SV	1 DETECTOR
117-92031-03		NE	1 CONTROL UNIT
117-92031-03		OH	2 CONTROL UNIT
117-92031-07		SV	2 CONTROL UNIT
117-92031-07		NE	1 CONTROL UNIT
117-92040-03		SV	1 LIGHT EMERGENCY EXIT SIGN
117-92042-01		SV	1 IMPACT SWITCH
117-92049-01		NE	3 POWER SUPPLY
117-94035-03		SV	1 TEMPERATURE INDICATOR
117-94035-05	124-500-3	NE	1 IND. XMSN OIL PRESS. DUAL
117-94035-05		SV	2 INDICATOR XMSN OIL TEMP
117-94036-05		OH	2 DUAL OIL PRESS INDICATOR
117-940471		NE	1 INDICATOR-AIRSPED
117-940481		SV	1 AIRSPED INDICATOR
117-94051-05	124-499-4	SV	1 TOT INDICATOR
117-94051-05		SV	1 INDICATOR-TOT
117-94051-05		OH	1 T4 INDICATOR
117-94051-07	124-499-5	SV	1 TOT INDICATOR
117-94051-07		OH	1 TOT-INDICATOR
117-94052-07	82000-05605	SV	1 ANNUNCIATOR PANEL
117-940521		NE	4 AIRSPED INDICATOR
117-94052-11		NE	1 ANN PANEL
117-94052-17		SV	1 ANNUNCIATOR PANEL
117-94052-17		NE	4 ANNUNCIATOR PANEL
117-94054-01	PF240-N3	OH	2 INDICATOR FUEL QTY KG
117-94054-03	PF240-N4	SV	1 INDICATOR FUEL QUANTITY (GA)
117-94056-03	6503A-3101	OH	1 N1 INDICATOR
117-94056-03	6503A-3101	OH	2 INDICATOR N1
117-94057-01		SV	2 TEMPRETURE
117-94058-07	124.498-6	OH	1 INDICATOR TEMPRATURE OIL
117-94058-07	124.498-6	NE	2 INDICATOR TEMPRATURE OIL
117-94061-01		SV	1 RPM WARNING CONTROL UNIT
117-943231		OH	1 STBY HORIZON IFR
117-945641		NE	1 MM-ANZEIGEGERAET
117-94564W2		NE	2 MM-BALANCER
117-945661		SV	1 SP MAST MOMENT INSTALLATION

117-945661		AR	1 SP. P MM INSTALATION
117-94680-03		NE	1 HOSE ASSY
117-95769-01		NE	1 WIRE HARNESS
117-95788-01		NE	2 WIRING HARNESS
117-95879-01		NE	1 WIRING HARNESS
117-958811		NE	1 WIRING HARNESS
117-958812		NE	1 WIRING HARNESS
117-98043		NE	1 FILTER
117-980601		NE	1 VENTILATION EQUIP DESK
117-98130		SV	1 P/C BOARD LR FUEL TK
117-98130.01		AR	1 BOARD ASSY
117-98133		NE	1 LR FUEL TANK
117-98135		NE	1 MOD PART RETROFIT VIP TANK
117-98192		NE	1 WIRING HARNESS 302VB
117-982021		NE	1 WIRE HARNESS
117-982041		NE	1 WIRE HARNESS
117-98228		NE	3 PANEL-LTG PLASTIC
117-98230		NE	1 WIRING HARNESS BOVB
117-98248		NE	1 WIRING HARNESS 48VB
117-98295		NE	2 WIRING HARNESS 67VB
117-98331		NE	2 BATTERY INST AFT SECT
117-98336		SV	1 CONTROL UNIT YAW CSAS
117-98336		NE	1 CONTROL UNIT YAW CSAS
117-98439		SV	2 CONTROL UNIT
117-98538		NE	1 WIRING HARNESS 538VB
117-98609		SV	1 RELAY VOLLST
117-98682		NE	1 PRINTED CIRCUIT BOARD ASSY
117-99701L9600		NE	1 CSAS P/R TEST SET
117-ASB20-104-3.1		NE	1 KIT
117-ASB80-127-3.1		NE	2 KIT
117-ASB90-105-3.1		NE	1 KIT
117C2-SB71-001-2.C	B711M4143101	NE	1 POWER PLANT, BLANKET ENG.
117-E0018-2		NE	1 COVER PLATE ASSY
117-SB20-1-3.1		NE	1 KIT
117-SB40-103-3.1		NE	1 SB KIT
117-SB40-104-3.1		NE	1 SB KIT
117-SB60-102-3.1		NE	4 KIT
117-SB80-105-3.1	KIT:117-SB80-105-3.1	NE	1 KIT CONV. A-3 TO A-4
1180-1-12	UNS1	SV	1 UNS1 NCU
11-8150-1		AR	1 TIMING KIT
11-9110-1		AR	1 TIMING LIGHT TESTER
119300-101		NE	1 AW119 FILTER ASSEMBLY UPPER
119350-101		NE	2 AFS AW119 FILTER ASSEMBLY SIDE
120-03048-0002		NE	6 IC LM139J

12042-0061		NE	5 DIODE
121-0011-000		NE	1 ANTENNA
121-016796-01	AT-51	SV	1 ANTENNA
121-049075-02		NE	1 ANTENNA
12192-00		NE	3 SMOKE DETECTOR
1-2233-28		NE	1 SEAL
1229-1		OH	1 INDICATOR, BATT TEMP
1234T100-7TZ		AR	1 TURN COORDINATOR
124-1128-1		OH	1 INDICATOR DUAL DC AMMETER
124-244-2	209-070-263-009	OH	1 IND VOLTMETER
124-444-2		OH	1 TOT INDICATOR
124-507-04		NE	1 AMMETER DC DUAL
124-545	222-375-024-101	OH	1 INDICATOR
124-546	222-375-016-101	OH	2 INDICATOR
124-549	222-375-017-101	OH	2 INDICATOR, XMSN OIL TEMP
124-550		OH	2 INDICATOR, ENGINE OIL TEMP
124-550-3		OH	1 INDICATOR, ENGINE OIL TEMP
124-679-1		SV	1 CGB-PRESS/TEMP-IND-
124L507-6		NE	1 DUAL AMMETER INDICATOR
1250120-4		OH	1 COMPRESSOR
12507G-44		SV	1 HEADSET MIC
1259T100-3		SV	5 ACTUATOR
126-182-10	AC410004	SV	1 ENGINE TORQUE IND
126-306-5	222-375-064-105	OH	1 INDICATOR, TOT DUAL FUEL QTY
126PN01Y07	704A47-621-086	OH	1 INDICATOR, ENGINE TORQUE
128-413	1159SCF426-2	SV	2 EL INDICATOR
1286-1-1	212-077-200-3	SV	1 COMMUNICATION CONTROL UNIT
129-0160-43-101		NE	13 SPACER INTERNAL
129-0160-44-101		NE	10 SPACER EXTERNAL
12903-4	PB0134004	NS	1 SWITCH PRESSURE
129415-024		NS	1 SOLENOID
1297C-4-04		OH	1 AIRSPEED INDICATOR
129920-3		OH	1 ATTITUDE INDICATOR
129920-3		OH	1 ATTITUDE INDICATOR
1300160-3	3G2150V10651	SV	1 COCKPIT CONTROL PANEL, ECS
1-300-363-03	2925-00-950-2516	NE	6 IGN-UNIT
1301S		NS	1 FAIL SAFE
130-380041-7	41-402-1	OH	1 TEMP TURBINE INTERSTAGE
130-380045-7	83-183-1	OH	1 OIL TEMP & PRESS IND
1305-1-5	1305-58-2	SV	2 SMART SWITCH ADAPTER
1308-85		NE	1 ANTENNA
13-1-0110		SV	1 SERVO MOTOR
13-11014P		NE	1 PART
1312-1-1		SV	1 RCVR/TRANS MODULE

1312-1-2		SV	1 MODULE
1317S		NS	2 FAIL SECURE
132NE		NE	1 OAT-SENSOR
1330-16		SV	1 SCAT COMPUTER
1333-200-200	071-50014-0400	SV	2 HGA-48 HIGH GAIN ANTENNA
1333-300-200	071-50014-0203	SV	1 BSU-48A BEAM STEERING UNIT
1333-500-100		SV	1 DIPLEXER
1343-85		NE	1 VHF ANTENNE
13477-11281		OH	1 DIR GYRO
134E0505-054		SV	1 MOUNTING TRAY
135-0350-4		NE	1 AIR SWITCH ASSY
135-0550-3		SV	2 COMPRESOR CONDENSATOR PALL
135-0550-3		NE	2 COMPRESOR CONDENSATOR PALL
135-0553-1		SV	1 COMP.COND.PALLET EL.SSTART
135-0553-1		NE	1 COMP.COND.PALLET EL.SSTART
135-1401-1		NE	3 AUX BLOWER ASSY
135ME1339.		SV	1 Pulse Generaor IFR6000
136266-1		SV	1 CONTROL UNIT CCU32A
13636-93921-1		SV	1 MOUNTING TRAY
137685-01	5990-00-073-1810	NE	1 SYNCHRO
13824-12-0211	TNL2000A	SV	1 GPS
13824-12-0234	TNL2000A	SV	2 GPS
138740-19	704A47330088	SV	1 HORIZONTAL SITUATION INDICATOI
1394T100-7A		OH	1 TURN COORDINATOR
1394T100-7B		AR	1 TURN COORDINATOR
1397-1		SV	1 AMP SLEW SWITCH
13F141		NS	5 RESISTOR
140100-03-01		SV	1 ATTITUDE IND
1401-020		SV	1 MONITOR
1401-1T-B3		OH	1 INDICATOR AIRSPEED
1402-1T-C1		OH	1 AIRSPEED INDICATOR
1403-01-11		SV	1 DATA TRANSFER UNIT
141063-2	BAU-35A	SV	1 BEACON, AIRFOIL UNIT
14141-0203-	GNSX	SV	2 GNSX
141852-3122	LCR-92	SV	1 AHRS
141987-0001		SV	1 A-C-U-
1426-1AE-A1		OH	1 AIRSPEED IND
1426-37A-A6		OH	1 AIRSPEED IND (MPH)
1426-6M-B17		OH	1 AIRSPEED INDICATOR
143236-0420	BAU-35A	SV	1 BEACON, AIRFOIL UNIT
14347-0101-06	GNSX	SV	2 GNSX CDU
1445-1-1	20001-004	SV	2 TCC AUDIOFILE
145-0174-1		SV	2 COCKPIT BLOWER ASSY
145-0250-1		NE	1 COCKPIT BLOWER ASSY

1453PGCP		OH	1 FUEL PRESSURE SWITCH
1461-BU-8-03	E-32	SV	1 INDICATOR, TACHOMETER
147B30A	MS28008-1	OH	1 INDICATOR TEMP
147B31A	MS28009-1	OH	1 INDICATOR TEMP
147B32A	MS28004-1	OH	1 INDICATOR TEMP
1-480710-0		NS	3 CONNECTOR
1486-1-16		SV	1 SWITCH PANEL
1486-1-20		SV	1 SWITCH PANEL
1486-1-6		SV	1 SWITCH PANEL
1486-1-7		SV	2 SWITCH PANEL
1486-1-8		SV	2 SWITCH PANEL
149-0020-003		SV	1 MOUNTING TRAY
149-015932-0001	C5000	NE	1 INSTALL KIT
1500-01-13		SV	1 AIR DATA COMPUTER
15-0007-127		SV	4 LIGHT ASSY
15-0105-1		NE	1 PANEL LIGHT
152HL2W	206-070-267-007	OH	1 TOT INDICATOR
152HL2W3		OH	2 TOT INDICATOR
153-017713-01		SV	2 FF HANDSET
153-168		NE	2 FIRE PROTECTION
1534-1-8		SV	1 AIRSHOW PANEL
1534-1-9		SV	1 AIRSHOW PANEL
153510-000017	STRATUS ESG	SV	1 ADS-B OUT TRANSPONDER
1550184-503		SV	1 ANNC COUPLER UNIT
155-02578-0001	TS10B	NS	1 HARNESS
155-02581-0000	TS10B	NS	1 APPLE BOARD CABLE
156-01	EDO AIRE	SV	1 ADF CONTROL HEAD
1564T100-5		SV	1 SERVOMOTOR
156F115B0084S180		NS	3 TUBE
156M1		SV	1 ADF CTL
1575-1-1	1305-58-2	SV	1 32 I/O ADAPTER MODULE
1575-4		SV	1 GPS AMP
1589-1F		SV	1 VOLTAGE REGULATOR
15989-005		NS	1 ANN- DCPL- FD- "OFF"
15989-006		NS	1 ANN- CYCLIC POSITION CTR
159AV10001EQ5		SV	1 TURBINE GAS TEMP
159AV10001TEQ5		SV	1 TURBINE GAS TEMP
15E02-1	222-325-013-102	SV	1 VALVE
15PX308		AR	1 GUARD RCVR
1601B-DC28		SV	1 COFFEE MAKER
1602-01-03	CVR30A	SV	1 COCKPIT VOICE RECORDER
1602-02-03		OH	1 CVR-30A Cockpit voice recorder
16030S	160305	OH	1 ALTIMETER
160SG139Q-2		OH	1 STARTER GENERATOR

1612-02		SV	1 CVR CONTROL
1616-050-02A		SV	1 SKY CONNECT
1616-050-03A		SV	1 SKY CONNECT
1616-055-00		SV	2 SKY CONNECT CONTROL HEAD
1616-055-10		SV	2 SKY CONNECT CONTROL HEAD
1616-450-01A		SV	1 SKY CONNECT TRANSCEIVER
162-1		NS	1 VIDEO ISO TRANS 75 OHM
16248-11		SV	5 GPS ANTENNA
162LC601A		SV	1 INDICATOR, TEMP ELEC
164BT-2		OH	1 ROTARY ACTUATOR
164ZS01Y		SV	1 AUDIO WARNING
1656A1100-01		SV	1 TRAILING ARM LH
1656A2100-02		SV	1 TRAILING ARM, RH
16650-1142		OH	1 ALTIMETER
16650-1172		OH	1 ALTIMETER
16722-007	13986-001	NS	30 ANNUNCIATOR
168SR101		SV	3 SWITCHING RELAY
170-431-02-100		SV	1 COMM CONTROL
17-100		SV	1 COMPASS
1713121-501		SV	1 RADAR PHASED ARRAY
1713122-501		SV	1 BASE
171-431-02-000		SV	1 COMM CONTROL
171-431-45-100		SV	1 COMM CONTROL
1716803-502		SV	1 ANTENNA ARRAY
171BS101-1		SV	2 AMPS500
172937-001		SV	10 RELAY
17343-62-340		NE	1 FIRE DETECTOR
173819-001		SV	1 RELAY
174213-02-01		SV	5 FLIGHT DATA RECORDER
1742500-09		NE	9 FILTER ASSY
1742500-09		NE	2 OIL FILTER
1742510-05		NE	1 FILTER ELEMENT
17479-549		NS	1 ANNUNCIATOR
175096-101		SV	1 RELAY
1762A020000		OH	1 DRAIN KIT
17680-01		NE	1 CONFIG MODULE
1778686-655		SV	1 C6 INDICATOR
1783180-122		SV	1 INTEGRATED INST RACK
18013B-011		OH	1 VSI
18013B-012		OH	1 VSI
1801-CH		OH	10 INDICATOR SIMPLE
180806-007		SV	1 AMP ASSY
1810-010		SV	1 ROSEN MONITOR
18-1030-2		SV	1 INVERTER

1811D605		NE	1 PILOT STATIC TEST SET
18152-1		SV	1 MODULE
18152-309		SV	1 IND
18152-907	422-18152-907	SV	1 MODULE
18152-983		SV	1 MODULE
18-1814	96774-18-1814	OH	1 TORQUE PRESSURE IND
18-1842-7	412-075-205-101	OH	1 TORQUE PRESSURE TRANSMITTER
18-2021	MS28010-1	OH	1 IND, PRESS, MULTIPURPOSE
18253G-19		NE	1 ADAPTER HEADSET
183-0251-000	183-0251-00	NE	5 CAPACITOR
18-380011	19B428	OH	1 FUEL QTY GAGE
18422-0		AR	1 THERMOSWITCH HEATER CONTROL
184-7668-000		NE	45 CAPACITOR
18650-000-04	704A44242008	SV	1 DAMPER TAIL SKID
1865-40		SV	3 FILTER DIFF- PRESSURE SWITCH
18790-500		NE	1 FLIR HARNESS
188-3305-901		SV	2 EMERGENCY LIGHTS BOX
18-947-1		SV	3 INVERTER
189-740-2		SV	1 INVERTER
189-740-2		NE	3 INVERTER
18-994		SV	3 ALC INVERTER
18-996		SV	4 ALC INVERTER
19095-100-00	19095-100-00B	SV	1 DRAG STRUT JACK, NLG
19100-0101		SV	1 GPU
1916400-7		NE	2 SHUT OFF VALVE
1918312-1		NE	1 TEMPERATURE SENSOR
19210-00-04		SV	1 CRASHWORTHY SEAT
192743-0001		AR	1 PSU SPEAKER
1936AA		SV	1 TRANSMITTER
1-936-BA		SV	1 TRANSMITTER
1945F200	1945F200W01	SV	1 ACTUATOR, MLG
1945G200A01		SV	1 MAIN LANDING GEAR L/H
1957EG		OH	1 INDICATOR DOUBLE
1957EH	3160.S.73.47.940	OH	6 INDICATOR DOUBLE
195-83072-1		NE	1 DEFLECTOR, FWD, WINDSHIELD
1962-26-1		SV	1 SWITCH PANEL
1-99302		NS	2 LINING
19A2593	206-073-913-1	SV	2 BLOWER
19A2696	222-325-009-101	SV	1 BLOWER
19E143-1A		NE	2 BENDIX SHAFT
1C27-10		AR	1 PUMP FUEL CARTRIDGE
1C27-11		SV	1 FUEL BOOST PUMP
1C469-6-443		OH	1 TRIM SERVO
1C64-7		SV	4 PUMP

1D1917		OH	1 INDICATOR
1G-1272		SV	1 AUDIO GENERATOR
1S14980-1		SV	1 FCU PUMP & MOTOR
1U262-001-10		AR	1 DIRECTIONAL GYRO
1U262-001-39	4000B39	OH	1 GYRO
1X25166857	EUROCOPTER	SV	1 DRIFT
1X25170023	EUROCOPTER	SV	1 DRIFT
1X31711W5	EUROCOPTER	SV	2 MOUNTING TOOL
1X36166806	EUROCOPTER	SV	1 SOCKET WRENCH
1X53166817	EUROCOPTER	SV	1 PULLER EXTRACTOR
1X53170049	EUROCOPTER	SV	1 PULLER EXTRACTOR
1X53174739	EUROCOPTER	SV	1 DRIFT
1X54176702	EUROCOPTER	SV	1 DRIFT
200000-1		OH	1 TANK RH, LONGI CRASHWORTHY
2000029-61		SV	2 SECURITY BELT
2000-106	SRC-2000	SV	1 SPECIFIC RANGE COMPUTER
200-0452-00	200-0452-00-R12	NS	1 MODULE
200-05330-0002		SV	1 EFIS AP FD PANEL
200-071-003	76450-01078-102	OH	1 FUEL PRESSURE INDICATOR
200-08777-0010		FN	1 SONY REPLACEMENT
2000-902	SRC-2000	SV	1 SPECIFIC RANGE COMPUTER
2000-902-2G	SRC-2000	SV	1 SPECIFIC RANGE COMPUTER
2001-053-01-0	A0089-100N	SV	1 DISPLAY UNIT
20-0158-1IR		NE	1 EYE BROW LIGHT
20018-11308	20020-11365	OH	1 AIR SPEED INDICATOR
20020-11190		OH	1 AIRSPEED INDICATOR
20020-11212	222-375-027-107	OH	1 AIR SPEED INDICATOR
20020-11293		OH	5 AIRSPEED INDICATOR
20020-11293E034-438		OH	1 AIRSPEED INDICATOR
20020-11327		OH	1 AIRSPEED INDICATOR
20020-11388	222-375-027-113	OH	1 INDICATOR, AIRSPEED, PITOT, STAT
200-2752-03	200-02752-0003	NS	1 VCO
200-2752-04	200-02752-0004	NS	1 VCO
200-4273-00		AR	1 RADAR ADAPTER
200-92704-101	MT-851	AR	1 MOUNT ASSY
200SGL115Q-2		OH	1 STARTER GENERATOR
200SGL129Q		OH	1 STARTER GENERATOR
20110-1-03	21105-2-03	SV	1 NDB-2 NAV DATA BANK
20230M1		SV	3 CONTROL UNIT
203-021-003	76450-01078-103	OH	1 FUEL QTY IND
203-022-005	76450-01078-101	OH	1 ENGINE OIL TEMP AND PRESS IND
203-022-008	76450-01078-112	OH	1 TRANS OIL TEMP IND
203-022-009	76450-01078-126	OH	2 OIL TEMP AND PRESS IND
203-022-012		OH	1 INDICATOR OIL PRESS & TEMP

203-022-013	76450-00906-102	OH	5 INDICATOR OIL PRESS & TEMP
203-022-016	76450-00907-103	OH	2 INDICATOR, OIL TEMP & PRESSURE
203-023-003	76450-01078-104	OH	1 DUAL HYD- PRESS-IND
20322-501		SV	2 CO-PILOT ANNUN CPLR
2035482-0701	5985-01-109-8878	NS	10 ISOLATOR,RADIO FREQUENCY
2037923-0503	5975-01-307-3609	OH	1 FRONT PANEL
2038070-0501	5998-01-107-4863	SV	1 ROLL AMP ASSY
2038992-0501	5841-01-089-2745	OH	1 RADAR SET SUBASSEMBLY
2039016-0501	5996-01-088-6358	OH	1 AMPLIFIER, RADIO FREQ
2039272-0502	5841-01-340-3771	OH	1 RADAR SET SUBASSEMBLY
2039273-0501	5841-01-088-3812	OH	3 POWER SUPPLY
204-001-264-1	204-001-264-001	NS	1 BOX ASSY
204-010-937-007	SGT520-6	SV	2 DAMPER ASSY
204-011-164-001		NS	2 STOP
204-011-174-1		NS	1 SPACER
204-011-179-1	5340-00-157-7846	NE	1 CLEVIS, ROD END
204-030-846-001		NS	1 SWIVEL ASSY
204-030-893-91		NS	4 BRACKET
204-032-743-1		NS	1 PLASTIC
204-032-743-1		NS	1 PLASTIC
204-040-219-001		NS	1 PACKING
204-040-760-3	204-040-760-003	OH	1 OIL FILTER
204-040-801-1	204-040-801-001	OH	1 GEARBOX
204-040-929-2	204-040-929-002	SV	1 COVER AND LIFT PLATE
204-060-005	76450-00904-105	OH	2 TURBINE INLET TEMP IND
204-060-006	76450-00904-106	OH	2 TURBINE INLET TEMP IND
204-060-663-003	204-060-663-3	NE	18 SWITCH ASSY, FUEL FL
2040918-0501	7021-01-269-3244	OH	1 COMPUTER,DIGITAL
2041441-0101	5975-01-192-0723	OH	1 MOUNTING BASE
2041441-0102	5975-01-091-1877	SV	2 MOUNTING BASE
2041442-0101	5975-010911876	AR	1 MOUNTING BASE
2041442-0102		NS	1 MOUNTING BASE
204A-1A1A	MS28008-1	OH	1 INDICATOR TEMP
204A2F1A	MS28004-1	OH	1 INDICATOR TEMP CYL HEAD
205-001-916-1	205-001-916-001	NS	2 BELLCRANK ASSY
205-032-161-006		NS	1 BRACKET
205-032-616-006		NS	1 BRACKET
205-040-229-001		SV	4 GEAR
205-050-125-1	205-050-125-001	OH	3 FIXED FLOAT DAMPER
205-070-283-003	8D181CDG	OH	1 TACH N1
205-070-710-1	205-070-710-001	NS	1 LEG ASSY
205-070-729-5	205-070-729-005	NS	1 CUPPORT BRACKET
205-072-708-001		NS	1 TUBE ASSY
205-075-158-001	205-075-158-1	OH	1 OIL PRESSURE INDICATOR

205-961-383-21		NE	1 CABLE ASSY
205RGU/FA/1		SV	1 RATE SENSOR
206-001-173-107A		NE	1 STICK ASSY
206-001-400-9		AR	3 LEVER ASSY
206-032-445-007		NS	1 SUPPORT ASSY
206-040-407-7	206-040-407-007	OH	1 TAIL ROTOR OUTPUT SHAFT
206-050-141-024		NS	8 AXLE ASSY
206-062-627-003	22A649	SV	1 TACH GENERATOR
206-062-831-1		NS	1 LINE ASSY
206-070-266-9	6501-3008	OH	1 N1 INDICATOR
206-073-913-1	19A2593	SV	1 BLOWER
206-075-190-001		OH	1 TOT INDICATOR
206-075-676-103	124-1014	OH	1 INDICATOR, FUEL PRESS & LOAD
206-075-681-117	DL401-15	OH	1 DUAL TACH IND
206-075-681-123	DL401-18	OH	1 DUAL TACH IND
206-075-711-001	6620-01-034-0883	OH	1 INDICATOR, TORQUEMETER
206-075-711-1	6620-01-034-0883	OH	1 INDICATOR, TORQUEMETER
206-076-037-001	206-076-037-1	OH	1 VALVE
206-360-501-101	10687D	AR	1 OIL COOLER
206-706-201-021		NS	1 NULL
2068623-0701		NE	1 WAVEGUIDE
206-951-383-011K		NS	2 CABLE ASSY
206-961-383-21		NS	1 CABLE ASSY
2070499-0101		SV	1 MOUNTING TRAY
2070499-0102		SV	1 MOUNTING TRAY
2070499-0104	MBA-1L	SV	1 MOUNTING TRAY
2070965-0101	5841-01-089-1022	SV	1 RADAR CONTROL
2087772-7304	CVA73-190	SV	1 ANTENNA COUPLER
209-062-005-001	209-062-005-001WTD2	SV	1 INSPECTION TOOL
209-062-104-001		SV	1 TUBE ASSY
209-063-010-1		NE	5 GASKET HEATING SYSTEM
209-076-021-013	209-076-021-13	OH	1 CYLINDER ASSY HYD
2090JFA		OH	1 PUMP FUEL BOOSTER
209-175-301-001		SV	1 VOLTAGE
20919-031		NS	1 INDICATOR
20919-033		NS	1 INDICATOR
20919-034		NS	1 INDICATOR
20919-035		NS	1 INDICATOR
20919-036		NS	1 INDICATOR
20919-037		NS	1 INDICATOR
20919-039		NS	1 INDICATOR
20919-042		NS	1 INDICATOR
20VR4D		SV	1 BATTERY PACK
2100284-4		SV	1 NAV COMPUTER UNIT

2100-8006-00		NS	1 MOUNTING TRAY
2103401-2		SV	1 SOURCE
2107-B-6		OH	1 RMI
2107D-B-6		SV	1 RMI
2116-40-1116	UNS-1L	SV	1 FMS
2117404-5	SERIES 4	OH	1 ELECTRONIC CONTROL UNIT
2118478-1		SV	2 CONTROLLER, ELECTRONIC UNIT
212-030-044-001	212-030-044-1	NS	1 COVER
212-030-044-001		NS	1 COVER
212-070-108-001	8DJ131AAJ	OH	1 INDICATOR TACHOMETER
212-070-116-003	124-972A	OH	1 OIL TEMP & PRESS IND
212-070-116-009	124-045	OH	1 OIL TEMP AND PRESS IND
212-070-116-3	124-972A	OH	1 OIL TEMP & PRESS IND
212-070-116-9	124-045	OH	1 OIL TEMP AND PRESS IND
212-070-160-007	9813-25-07	SV	1 DUAL TORQUE INDICATOR
212-070-160-017		SV	1 TORQUE INDICATOR
212-070-160-021	18-1838-21	OH	1 INDICATOR, DUAL TORQUE
212-070-160-129FM	9813-25-17	SV	1 DUAL TORQUE INDICATOR
212-073-912-1	30756-1	SV	1 SQUIB VALVE
212-075-523-101		SV	1 COMM PANEL
212-6000-09-1		NE	8 GASKET
212CW		SV	1 DRY AIR PUMP
21311MI		SV	1 INTERFACE UNIT
2133VENT		NE	2 VENT ASSY
213522B	213723	SV	1 ENGINE SYNC UNIT
213545A	213723	SV	1 ENGINE SYNC UNIT
213798C		SV	1 GOVERNOR COM
2138-50000-106	76900-01880-106	SV	2 AMPLIFIER
214-001-347-005	67A370	SV	1 ACTUATOR
214-001-347-007		SV	1 ROTARY ACTUATOR
214-001-347-101		OH	1 ACTUATOR
214-040-013-115	214-040-020-103	OH	1 GEAR BOX ASSY, COMB
214C50-60		SV	1 SWITCH, PRESSURE
215371-0		NE	1 DIGITAL PRESSURE GAUGE
217596-0		SV	1 FWD LEFT E.F.S. ASSY
217597-0		SV	1 FWD RIGHT E.F.S. ASSY
217598-0		OH	1 AFT LEFT E.F.S. ASSY
217599-0		OH	1 AFT RIGHT E.F.S. ASSY
217-601933-215	CMA-1100	NE	1 I/O CABLE ASSY
21867-1		OH	1 GENERATOR
2193-10C		NS	2 SERRATED DISC
21B67-1A	21B67-1	SV	1 CONTROL UNIT, GEN, AC
220-352864-000		NE	1 LAMP
22125BC050042L		NS	4 SCREW

221-3992-803		NS	1 AIR ASSY
22-1863-048		SV	1 FAILURE WARNING PANEL
22-1863-089	704A47723068	SV	1 FAILURE WARNING PANEL
22-1863-089-REP	704A47723068	SV	1 FAILURE WARNING PANEL
222-001-072-105		OH	1 SPR CART ASSY
222-001-072-109		OH	2 SPR CART ASSY
222-005-001-101		OH	1 ACTUATOR
222-005-030-101		OH	1 RPM LIMIT DETECTOR
222-005-030-111		OH	2 RPM LIMIT DETECTOR
222-025-182-001		NS	2 SEAL NOSE SKIN
222-031-306-033		NS	1 PANEL
222-036-017-001		NS	2 SHIM
222-065-562-133		NS	1 SEAL
222-075-132-101		SV	1 PANEL
222-366-684-103		SV	1 LOWER PROBE
222-366-684-103		AR	1 LOWER PROBE
222-375-010-107	80-0500-1	SV	1 ANNUNCIATOR PANEL
222-375-010-131	80-0500-17	SV	1 ANNUNCIATOR PANEL
222-375-020-103	HAI222070110	OH	1 TRIPLE TORQUE IND
222-375-021-101	78200000-01	OH	1 TRIPLE TORQUE IND
222-375-027-111	20020-11365	OH	2 AIRSPEED IND
222-375-033-101	4300-8170-1L	OH	3 ALTITUDE IND
222-375-071-105	78300000-05	OH	1 INDICATOR, TRIPLE TORQUE
222-375-077-113		SV	1 PRESSURE TRANSDUCER
222-382-002-103	143000-104	SV	1 DIRECTIONAL SERVO
22251BC050060L		NE	20 SCREW
22252BC050011L		NS	10 BOLT
22-260-014		OH	1 MANIFOLD PRESS IND
22-260-042-1A		OH	2 MANIFOLD PRESS IND
22-280	22-280-015A	OH	1 TACHOMETER INDICATOR
222-899-604-101		OH	1 PA CONTROL
222-899-604-113		SV	1 PA CONTROLLER
2231321-4		SV	1 UNIT-INTEGRAT FDR/HUMS
2231896-2		SV	1 PANEL-CONTROL PANEL
2241500-4A		SV	2 MDAU
225398-6		NS	1 CONNECTOR
225973-4		NS	1 CONNECTOR
2260-1001-1	209-075-326-1	OH	1 DETECTOR, RPM LIMIT
22-697-06-1		OH	1 AIRSPEED INDICATOR
22885-21-4174		SV	2 WING LIGHT
22885-22-4174		SV	2 WING LIGHT
229-0324-010		SV	1 VERTICAL ACCELEROMETER
229-0324-010-M		SV	1 VERTICAL ACCELEROMETER
229-0324-020		SV	1 ACCELEROMETER

229-0324-020-M	SA111128-020	SV	1 ACCELEROMETER
229-1001-000	229-1001-00	NE	1 MOTOR CONTROL
229-3044-040		NS	1 SYNCHO
229-6026-030		NE	1 SYNCHO
22A703		SV	1 GENERATOR
230-0257-00	6105-00-578-7304	NE	1 MOTOR DC
2302KGA/CP/1		SV	1 TACH GENERATOR
23032-022		SV	1 STARTER GENERATOR
23032-048		NE	2 STARTER GENERATOR
23032-048		SV	5 STARTER GENERATOR
23032-049		NE	2 STARTER GENERATOR
23032-049		SV	2 STARTER GENERATOR
23032-062		NE	1 STARTER GENERATOR
23032-062		SV	4 STARTER GENERATOR
23032-2711		NS	4 BACK PLATE
2306-557-00-10	704A37-650-100	OH	2 FUEL QTY IND
23081-001		NE	2 STARTER GENERATOR
23081-043		NE	1 STARTER GENERATOR
23081-043		OH	3 STARTER GENERATOR
23081-043		AR	3 STARTER GENERATOR
23081-303		NE	1 SUPPORT ASSY BEARING AND BRUS
2309-355-00-11		SV	1 AMMETER, DC
2311M-205-2		NE	1 MOTOR ASSY ELECTRIC
2312G-25		SV	1 TESTER
2312M41-12		NE	1 CONVERTER
2312M41-12		NE	2 CONVERTER
2312M-41-13		SV	1 CONVERTER
2312M-41-20		NE	1 CONVERTER
2313M-427-1	02313M-427-1	AR	1 WIPER MOTOR ASSY
2313M-427-1	222-625-001-101	SV	1 WIPER MOTOR ASSY
2315M116-1		NE	1 WIPER BLADE ASSY
2315M116-1		NE	2 WIPER BLADE ASSY
2315M6-1		NE	1 BLADE
2315M-75-2		NE	1 BLADE
233-1-2		SV	1 CURRENT SENSOR
233209-03		SV	1 FILTER
2338-50		AR	1 ANTENNA DME/TRANS
2381-05-L-18-IG-C		NS	1 EYEBROW
2383-05-L-18-IG-C		SV	2 EYEBROW
2393-05-L-18-IG-C		NS	1 EYEBROW
23932-005	570-23932-005	OH	1 ALTIMETER
23932-101	570-23932-101	OH	1 ALTIMETER
23932-901	570-23932-901	OH	2 ALTIMETER
2400-25-4-4-2		AR	1 PULSELITE CONTROL UNIT

24043GR79		NE	10 LINING ROTOR BRAKE ASSY
241-0570-010		NE	3 FILTER,LP
2420C1		NE	2 CONTROL UNIT
24353-0001		NE	1 CONNECTOR
244-602183-000		SV	1 POWER INTERFACE UNIT
245-604128-000	CMA-1100	SV	2 PILOT VIEW
245-604129-000	CMA-1100	SV	2 PILOT VIEW
245-604170-008	CMA-1100	SV	2 EMU
245-604244-215	CMA-1100	SV	2 EFB MOUNT
24640QAE0101		NE	1 FUEL JETTISON ASSY
24640QAE0101		SV	5 FUEL JETTISON ASSY
249-1398-000		NE	2 CONNECTOR ASSY
24HP883-101		NS	2 SHROUD PAD BASE
250003-1		SV	2 DC POWER SUPPLY
2500979-1		NS	6 CONTACT
25011-00312		SV	2 CVR CONTROL UNIT
2501-1-192H101A		SV	1 LAV SWITCH PANEL
2501-2-029H402A	2501-2-029	SV	1 SWITCH PANEL
2501-2-030H402A		SV	1 PANEL
2501-2-252/H101A	2501-2-252	SV	1 AIRSHOW MODULE
25020-1157	704A47-113-102	SV	1 AIRSPEED INDICATOR
25020-9601		OH	1 AIRSPEED IND
2504094-5		NE	2 COIL
2504-3002A-040M	6610-01-214-5884	OH	1 COMPUTER UNIT
2504-3002A-04ET		OH	1 COMPUTER UNIT
2504-600-004A		NS	1 TEMP PROB MOUNT
2504-900ET		OH	1 TRANSDUCER ASSY
25100-004	540-25100-004	SV	1 ALTITUDE ALERTER
25174A-25A		SV	1 ANGLE OF ATTACK TRANSDUCER
2524644-3		SV	1 FUEL CONTROL
2524667-12		SV	1 POWER TRUB GOVERNOR
2524667-4		SV	1 GOVERNOR
2524738-30		AR	1 RR250 FUEL CONTROL
2524738-30		OH	1 RR250 FUEL CONTROL
2524843-1		SV	1 GOVERNOR CONTROL
2524843-1A		SV	1 GOVERNOR CONTROL
2524843-3		SV	1 N2 REGLER
253-E0873-00		SV	1 S ROTOR SPEED ENCODER
25486-00426		NE	2 RELAY ARMATURE
256-1		SV	3 AIRSHOW CURRENT SENSOR
257.011-001		NE	1 RN6 EURONAV IV DIGITAL MAP
257.01-15G		NE	1 RN5-2.9 MAP-COMPUTER 2 RS422
257.012-002		NE	1 RN6-CM EURONAV DIG MAP
25850-219		OH	1 MAX ALLOW A/S IND

2586257-1		SV	6 COMPENSATOR
2586689-902	SP-50A	SV	1 AP CONTROLLER
2587193-42		OH	1 GYRO
2587193-43		OH	1 GYRO
2587400-844		SV	1 AIR DATA COMPUTER
2587516-8		SV	1 ELEC ASSY
2588302-4		OH	1 GYRO DIRECTIONAL
2588767-901		SV	1 RADIO DIR IND
2590004-904	SP50G	SV	1 ALT PRESELECT COUPLER
2591201-922	CL-201	SV	2 COMPASS COUPLER
2591202-902		SV	1 COMPASS CONTROLLER
2591411-444	HZ444	OH	2 HORIZON FLIGHT DIRECTOR
2591714-14		SV	1 ALT COMPUTER
2591715-4		SV	1 AIRSPEED COMPUTER
2593342-932		SV	1 COMPUTER
2593342-932		AR	1 COMPUTER
2593342-976		SV	1 COMPUTER
2593342-976		AR	1 COMPUTER
2594775-200		SV	1 ALTITUDE CONTROL
25ARM300-20E20		NE	1 INSULATOR
25ET1-S		NE	1 SWITCH
2-5X15-21B6		NS	1 ORING
26000-30-07		AR	1 Secondary Flight Display
2600-600-0000		SV	1 TAS/PLUS COMPUTER UNIT
2600-700-0000		SV	2 TAS/PLUS COMPUTER UNIT
260-2351-01		OH	1 IND, DUAL FUEL PRESSURE
262-2348-010	KW204S	NE	2 DIGITAL DISPLAY IND
26400-102		SV	1 CONVERTER
265-100A		NE	5 RELAY
266-7566-010		NE	4 SWITCH
2670104-2RX		NE	1 ANNUCIATOR PANEL
267-937-005		OH	1 IND, FUEL FLOW
269A1278		NS	5 SEAL
269A2063		NS	4 OIL SEALS
269A2335		NS	1 DAMPER PLATE
269A4714		AR	1 PANEL
269A5050-44P		NS	4 BEARING
269A5463		NS	4 CLAMP
269A5492-3		NS	6 SHIM
269A6053-3		NS	1 BUMPER
26ET32-T		NS	1 SWITCH
27000-01-20	9030-3046	NS	1 AIR DATA UNIT
2700-004A22		SV	1 COCKPIT DISPLAY
27005-00-08		SV	2 AIR DATA DISPLAY UNIT

2700-500-A2A00BJDGF		NS	1 DIGITAL CABIN DISPLAY
270-2196-010	590B2	OH	1 AIRSPEED SENSOR
270-2878-070	G7632-108	OH	2 CTL32G NAV CONTROL
270-839	839	SV	2 MICRO TOUCH PANELS
2716-00		NE	1 AEROTHERM AIR TEMP GAGE
273AA-205	311601	NS	1 COAX CABLE ASSY
273AA-206	311601	NS	1 COAX CABLE ASSY
273AA-207	311601	NS	1 COAX CABLE ASSY
273AA-208	311601	NS	2 COAX CABLE ASSY
273AA-220	311601	NS	1 COAX CABLE ASSY
273AA-221	311601	NS	1 COAX CABLE ASSY
273AA-222	311601	NS	1 COAX CABLE ASSY
273AA-223	311601	NS	1 COAX CABLE ASSY
277200-002		AR	1 COURSE DEVIATION INDICATOR
277200-214		SV	1 COURSE DEVIATION IND
2797-4		SV	4 AQUAFIX 406 GPS
28-1750-18	A141938	NS	2 RING
28260-004	930-28260-004	SV	1 DISPLAY CONTROLLER
282K2770-051		NE	1 CHCECK VALVE JET PUMP
2850-1		NS	1 SWITCH
28711-902	930-28260-004	SV	1 DISPLAY CONTROLLER
2891ESR		OH	2 DIRECTIONAL GYRO
29007-007	521-29007-007	SV	1 ALTIMETER
29007-204	521-29007-204	SV	1 ALTIMETER
29-1000		OH	2 OIL TEMP IND
2915-12-341-8026	300991124	SV	1 GOVERNOR
29264-001	CA-154-3A	SV	1 EMERGENCY BATTERY SUPPLY
29400-212		SV	2 RAD ALT CONVERTER
29400-4117		SV	1 RAD BAR CONVERTER
29400-4217		SV	1 RAD BAR CONVERTER
29400-8101		SV	2 RAD BAR CONVERTER
29400-8112		SV	1 RAD BAR CONVERTER
2-95X23-47-61D6		NS	1 ORING
2A350-1D1		SV	1 STATIC INVERTER
2C12-1	4320-01-483-9169	OH	1 FUEL PUMP
2LA001625-04WS		NE	2 TAIL LIGHT
2LA455359-00		NE	1 LED NAVIGATION LIGHT GREEN
2N3637		NE	3 TRANSISTOR
2N4925	5961-00-479-1735	NE	5 TRANSISTOR
2N6764		NE	5 TRANSISTOR
2N6782		NE	4 TRANSISTOR
2N6788		NE	4 TRANSISTOR
2S2C31		NS	1 RELAY
3001-01-100		NE	1 Accelerometer single axis

3001-01-101-4		SV	1 SINGLE AXIS ACCEL
300-2184-0000	300-2184-000	SV	1 RT30 GUARD RECEIVER
300-2202-000		SV	1 MOUNTING TRAY
300-2241-000		SV	1 GUARD RECEIVER WITH CRYSTAL
300-2265-000	H4	SV	4 RET CORD
30050-0707-1121	GNSX	AR	1 GNSX RPU
30050-0909-1121	GNSX	SV	1 GNSX RPU
30-0504-23		NE	1 ANTI COLL STR LIGHT
30-120-16		NS	185 PIN
3014C		SV	2 POWER UNIT
3017-42-211	UNS-1EW	SV	1 FMS WITH FC06 SOFTWARE UPGRA
3019-41-201	UNS-1ESPW	SV	3 FMS WITH FC06 SOFTWARE UPGRA
30-1994-1		SV	1 LIGHT, NAV, STROBE
30230-1165	222-375-030-001	OH	2 INDICATOR, VERTICAL VELOCITY
30-231-31		SV	1 SMOKE DETECTOR
30-2478-1		SV	2 FWD POSITION LIGHT
30-2478-2		SV	2 FWD POSITION LIGHT
303-006-005	76450-01078-123	OH	2 DUAL TORQUE INDICATOR
303-006-006	76450-01078-125	OH	2 DUAL TORQUE INDICATOR
30-303A		OH	1 CONTROL AMP FIRE DETECT
30-303AT		SV	1 AMPLIFIER
303990-02	TC-M	NS	1 ALTIMETER
3043574-01		NE	2 FUEL FILTER KIT
3044180-01		NE	1 FUEL AIR BLAST
3045819-01		NE	1 KIT FUEL FILTER CHANGED
3050562-01		SV	4 ACCUMULATOR, ECOLOGY SYSTEM
30510-133	422-30510-133	SV	1 AIR DATA COMPUTER
305154-00		AR	1 SAE5-35
3054015-3		OH	1 AUX SERVO PRESS REDUCER
30542-102		SV	1 CABIN DISPLAY PANEL
3057-147		OH	1 TORQUE IND
3057-148	704A47621092	OH	1 TORQUE INDICATOR
3057-148-1	704A47621094	OH	1 TORQUE INDICATOR
3057-148-2		OH	1 TORQUE IND
3057-149-6	704A47621120	OH	1 TORQUE IND
3057-165-2		OH	1 TORQUE INDICATOR
3057-169-2		OH	1 TORQUE INDICATOR
3057-3-10-143		SV	1 TORQUEMETER
3057-3-134		OH	1 PRESSURE INDICATOR
3057-3-136-6	704A47621128	SV	1 TORQUEMETER INDICATOR
3059026-01		SV	1 CARBON SEAL-CLUTCH DRIVE
306-4-1200		NS	5 10FT HOSE
30690B		SV	1 WINSLOW AEROFILTER
3070-00-01		SV	1 UNIVISION COMPUTER

30702-2		SV	1 MOUSE KEYBOARD INT EXT
3076214-01		OH	1 HEATER, OIL TO FUEL
3080-201-1		SV	1 INDICATOR
3080-201-2	117-94069-1	OH	2 DUAL TORQUE INDICATOR
3080-201-3	117-940711	OH	1 TORQUE INDICATOR
3080-201-4	117-902121	OH	1 TORQUE INDICATOR
30-97		SV	1 BRAKE ASSY
30E01-1B		OH	1 GENERATOR
30Y1000		OH	1 TACHOMETER INDICATOR
310-007-003	76450-00902-103	OH	1 DUAL TORQUE IND
310155-2		SV	3 AUDIO JACK
310155-2		NS	1 AUDIO JACK
3113645-01		NE	2 COVER
3121-748		FN	8 INNER SLEEVE
3121-748		NE	8 SLEEVE
31230-1120		OH	2 VSI
31300-0101-0111	C5000	SV	1 CONTROL UNIT
31300-0101-1200	C5000	SV	1 CONTROL UNIT
3130S35-60-010		NS	1 SUPPORT LH
3130S-68-00-907		NS	2 BEARING
3130S-88-10-020-1		NS	2 CABLE
31480-7123	575-31480-7123	OH	1 COMBINED SPEED IND
315A-88-00-0101		NS	3 CABLE
3160S12-20-960		NS	2 SEAL
3160S33-20-017		NS	1 THREADED PIN
3160S68-10-001		SV	2 HOUSING
3160S86-02-000-1		OH	1 PEDAL ASSY
318-00140		SV	1 TRANSMITTER
3192936-7		NE	60 STUD
32005-023		OH	1 TACH GENERATOR
320-1066-000	030-24478-0001	NE	7 COAX CONNECTOR
3202312-AB077		NE	2 FLIR HARNESS
3202312KAB240		NE	2 FLIR HARNESS
3202313KAD		NE	2 FLIR KIT
3203487-1	3203487-1K240	NE	1 FLIR KIT
3203487-1K240		NE	3 FLIR KIT
32-1012		SV	1 RATE OF CLIMB INDICATOR
32120-001		SV	1 COFFEE MAKER G280
3230008-3	3000U	SV	1 ALTITUDE SERIALIZER
324700M00		SV	1 DAMPER, ROLL
324900M03		SV	1 DAMPER, YAW
324AG64		SV	1 AFT FLOAT PACK ASSY PORT
3252013-0601		OH	1 ALTIMETER, ENCODER
326A25-30		SV	1 ELECTRO VALVE

32979-001		SV	1 ALT COMPUTER
33075-541	575-33075-541	OH	1 MACH AIRSPEED IND
330A98-3532-00		SV	1 WRENCH
331-0015-292		NS	1 CONN KIT
331-0025-292		NS	1 CONN KIT
3310071-01		NE	1 SEAL FACE
3311724-1	6220-00-576-3922	NE	4 PANEL INDICATING
3311A		SV	1 FUNCTION GENERATOR
331A		SV	1 FUNCTION GEN
332A67-4260-0051		SV	1 UNIT CONTROL, 426VU
332A67-4270-0051		SV	1 AUX- ENGINE CONTROL PANEL
332A67-4270-01		SV	1 AUX- ENGINE CONTROL PANEL
332A67-4271-00AA		SV	1 AUXILIARY CONTROL PANEL
332C-1		OH	1 DUAL RMI
332P61-6512-09		SV	1 AVIONICS SHELF
3357-9209		NS	1 JUNCTION SHELL
33776-0002-044		SV	1 ACTUATOR FITTING
33776-44788-041		SV	1 UNIT, RADAR ALTIMETER
33776-57574-042	76286-33776-57574-042	SV	4 S76 HEADLINERS
33776-66142		NE	4 RAD ALT KIT
33776-66143-041		NE	12 PLATE ASSY
33984-002	585-33984-002	SV	1 FUEL TANK TEMP C
34-0428020-65		NS	1 LAMP
34100-001	635-34100-001	SV	1 AIR DATA CONVERTER
34170-1X		SV	1 BAGGAGE LIGHT
341-93-3308-00		SV	1 TOOLING
341A31-4900-00		SV	1 BEARING BALL
341A41525400		SV	1 FILLET,LEG LH FWD
34401-30A22-1	6620-00-067-4946	OH	1 TRANSMITTER,PRESSURE
35020-11111		OH	1 VSI
350-321		OH	1 CYL TEMP IND
350-370		OH	1 TACHOMETER
350-93-3011-01	350A93-3011-01	SV	1 TOOLING
350-93-3302-01		SV	1 TOOL
350-93-3309-01	350A93-3309-01	SV	1 TOOLING
350-93-3711-00		SV	1 TOOL
350A00-0122-25		NS	2 LABEL
350A00-0138-31		SV	5 WEIGHT
350A00-0138-32		SV	1 WEIGHT
350A07-1156-71		SV	1 CONTROL PANEL
350A07-6544-75		NE	1 AFT COMMAND IMPROVEN
350A08-6011-14		SV	1 FOOTSTEP, RIGHT
350A08-6042-0151		SV	1 DOOR, RIGHT EQUIPED
350A08-8000-0072		NE	9 PIN AND FITTING

350A21106805		SV	1 BEAM ASSY, FRONT
350A21-1318-02		FN	2 FASTNER
350A21-1318-02		NE	1 FASTENER
350A2114382151		NS	1 DALOT
350A25-1082-20		NE	1 SHIM
350A31-1858-00		NS	1 SPACER
350A31-1872-21		FN	1 BUSHING
350A32110921		NE	3 WASHER LOCKING
350A32-3152-20		NS	1 BOLT
350A32-3152-20		NS	1 BOLT
350A-34-1015-21		NS	3 SPACER
350A37000305M		SV	1 MAIN ROTOR SHAFT
350A-37-1096-20		NE	5 LOCK WASHER
350A37-1178-20		NS	1 SHIM
350A55-1004-20		NS	6 SEAL
350A55-1031-04		NS	1 STRAP
350A58-1031-20		NE	4 DOG
350A73-0367-04		OH	2 ALTIMETER
350A73-1633-01		SV	1 ASSY ISO MOUNT
350A75-4005-02		SV	1 TANK,LOWER HYDRAULIC
350A76010701		SV	1 INDICATEUR EQUIPE
350A76014100		NE	1 COVER ASSY
350A76-1013-20		NS	1 HALF-FLANGE
350A76-1070-1		OH	1 INDICATOR EQUIPE
350A93-3201-00		SV	1 TOOLING
350A93-3204-00		SV	1 EXTRACTOR
350A93-3303-01		SV	2 EXTRACTOR
350A93-3405-10		SV	1 TOOLING
350A93-3405-11		SV	1 BUSH ASSY, LOCKING
350A93-3705-20		SV	2 EXTRACTOR
350D038-09		NE	1 CREW AUDIO PANEL MACHINING
351-1112-010		NE	7 IC LINEAR
351-1530-010		NE	50 MICROCIRCUIT
352-001		SV	3 AUDIO SELECTOR PANEL
352-1006-030		NE	2 TRANSISTOR
353-3740-200		NE	42 DIODE
355A32-0022-00		SV	1 BOX PRIN TRAN
355A32020002M		SV	1 PUMP OIL MGB
355A58-0917-03		NE	1 INDICATOR FLAG RH AFT
355A86-2008-20		FN	8 SHIM
3567401-3001		SV	1 TRANSMITTER
3571251-9110	222-375-022-101	OH	2 GAD PRODUCER TACHOMETER
3571251-9119	222-375-023-103	OH	2 INDICATOR
3571442-1004		SV	1 HORIZON IND

3571442-1004		AR	1 HORIZON IND
357-7204-010		NE	2 CONNECTOR
3600338-0001		NS	1 RDR1500B PHASED ARRAY
360-27-1210		SV	1 VSI
3603247-0001		SV	1 ELECTRON TUBE
3604618-0501		SV	1 MEMORY TIMER
3604989-0501	5841-01-331-9898	NE	3 REG BOARD ASSY
3605588-0501		SV	1 MOUNTING TRAY
360A32-1152-21		SV	1 VALVE
360A32-1163-01		SV	1 SUPPORT, EQUIPPED
360A32-3526-23		SV	3 BEVEL RING
360A57-2083-22Z		NS	1 SPACER
3614001-4001	064-1047-00	SV	2 VC-401B VHF COMM
3614002-4003		SV	1 COMM CONTROL
3614165-5512	AA5512B	SV	1 PHASE ARRAY ANTENNA
3614258-0802		SV	2 MT-1508 MOUNT
3614276-1004	CP-103A	SV	1 CONTROL
3614330-1001	071-1335-00	SV	1 CP-103D EFIS CTL PANEL
3614331-1001	066-4017-00	SV	2 NC-104B NAV CONCENTRATOR
3614331-1005	NC104B	SV	1 UNIT INTERFACE RADAR 1400
3614335-1002	SG101B	SV	1 SYMBOL GENERATOR
3614477-8601	IN861A	OH	1 RADAR INDICATOR
3614522-1019	CP-103E	SV	1 CONTROL PANEL
3614549-1008	3614549-1008-K	SV	1 RDR1500 INDICATOR MOUNT
36200-101	222-366-615-101	SV	1 VALVE
362-00135-100		SV	1 FLIGHT STATUS CONTROL
365A00-0337-DT		NS	1 DECAL
365A00-0337-DX		NS	1 DECAL
365A27326601		SV	1 ROD
365A2733050401		SV	1 COLLECTIVE PITCH STICK COPILOT
365A31117904		SV	1 MAIN ROTOR SHAFT
365A31-4706-00		SV	9 UPPER FLANGE,W SLEEVE & MASK
365A33-2167-20		NS	1 WEIGHT
365A33-2168-20		NS	5 WEIGHT
365A33614520		SV	2 CONTROL ROD
365A52-1266-20		NS	1 JOINT SEAL
365A57-3178-21		NE	1 DECAL
365A61-3416-21		NS	1 LOWER CUP
365A84-3061-20		NE	2 HOOK
365A91-2141-01		AR	1 JACK ADAPTER
365S67-8413-20		NS	1 PRESSURE TRANSMITTER
365W84-3061-20		NS	2 HOOK
366.684-921		NE	1 SERVICE SATION BOX
366-D-455-01		SV	1 ASSY-MGB FIRE DETECTOR

369A1140		NS	2 PAD
369A7951-47		NS	4 BEARING
369D21333		NS	1 STRIKER PLATE
369D27517NC		NS	8 COUPLER
37.014.20.000		NE	1 COLLER OIL AIR
37.016.20.000/3		NE	1 OIL COOLER
37.036.24.000		NE	5 VENTILATION
371-007-002		OH	2 PRESS TRANS
371-007-004		OH	1 PRESS TRANS
371-1-4		SV	5 CONTROLLER, 6 CIRCUIT
3718009-30		NS	2 SCREWLOCK
3718547-5		NS	1 BACKSHELL
375-1-3		SV	1 CONTROLLER, 5 CIRCUIT, 2 DELAY
37695-422629-811	422629-811	NS	1 HARNESS
380-004		SV	1 AUDIO PANEL
380-020		SV	2 AUDIO SELECTOR PANEL
3809-066-015		NS	2 BUSHINGS
38100-0128	PA520A	SV	1 ACTUATOR
38210-3941		OH	1 VSI
38210-490		OH	1 VSI
383392-1-1		OH	1 ENGINE AIR STATER
38399-330		OH	1 AIRSPEED INDICATOR
38399-330-02	704A47113066	SV	1 INDICATOR,AIRSPEED,MPH
38399-480		OH	1 AIRSPEED INDICATOR
386500-4		OH	1 PUMP, GEAR TYPE
386500-5		SV	2 FUEL PUMP
39.1-1100-02		NE	2 SPAS-ACTUATOR
390-389001-0001	MG94A-1	OH	2 STARTER GENERATOR
3911213-9012	222-DK117	OH	1 MGT INDICATOR
3911213-9016	222-375-023-111	OH	2 MGT INDICATOR
3-912S0613-60		NE	52 ORING
393026-03236		SV	1 INDICATOR,LIQUID QUANTITY
393086-01236		SV	1 FUEL QTY IND (US GALS)
393086-01236		SV	1 FUEL QTY IND
3932241-9002	222-375-064-101	OH	1 IND, TOT DUAL FUEL QUAN
3932241-9008	222-375-064-103	OH	1 TOTALIZING DUAL FUEL IND
3941213-9003	222-375-022-105	OH	1 IND, GAS PRODUCER TACH
3941213-9014	222-375-022-111	OH	2 IND, GAS PRODUCER TACH
394400-1		AR	1 FUEL PUMP
395-6798		NE	1 BEARING
396A7951-5L		NS	2 BEARING
397578-4-1		SV	1 TEMPERATURE SENSOR
397964-8		SV	1 VALVE
3A.63.32.20F.28.1.AB		SV	1 ALTIMETER

3A250-1A1		SV	1 STATIC INVERTER
3A43.32.50F.05.1.EG		OH	1 COUNTER DRUM ALTIMETER
3A43-42-50F-05-1-FT		OH	1 ALTIMETER
3A55.32.35F.00.0E		SV	2 Encoding Altimeter
3A61-22-20F-28-1-DS		OH	3 ALTIMETER
3A63.32.20F.28.1.AB		OH	1 ALTIMETER
3A632235F281HS		SV	1 Altimeter Drum Scale
3A67.32.50F.05.1AE		SV	1 ENCODING ALTIMETER
3A67-22-20F-58-1-AZ		OH	1 ALTIMETER
3CRJ5		NS	1 SPEEDAIRE ENGRAVING PEN
3D2314-06		SV	1 ADJUSTER FLOW VALVE
3E2044-1		NE	1 DE-ICE BRUSH
3G20F		NS	4 PUSH BUTTON
3H55.32.35F.00.0.AE		SV	1 Encoding Altimeter
3H65.32.20F.28.4.BP		NE	5 ALTIMETER
3L0-453/4-5		AR	1 G SWITCH
4000020-002		NE	3 LIGHT ASSY COCKPIT UTILITY
400-0073-010	C-962A	SV	1 CONTROL UNIT 28V
4000096-001		NE	1 FILTERCAP NVG
4000-10		SV	1 ELT
4000-1002	206-070-275-5	OH	1 CLOCK
400-0106-000	C-1000	SV	1 CONTROL UNIT 28V
400-0106-010	C-1000	SV	1 CONTROL UNIT 28V
400-0125-101	RT18D	SV	1 FF RT
400-0130-002	C118	SV	1 CTL UNIT
400-0130-003	C118	SV	1 CTL UNIT
400-0130-005	C118	SV	1 COCKPIT CONTROL
400-0130-005	C118R	NS	1 CONTROL PANEL
400-0131-005	C118BR	SV	1 COCKPIT CONTROL
400-0132-013	WH5HFR	SV	1 FF CABIN CTL
400-0138-002		SV	1 FF COCKPIT CONTROL
400-0140-025		SV	1 VHF FM TX/RX
400-014135-01		SV	1 GPS DOWNCONVERTER
400-014635-0101	IC-18	SV	1 FLITEFONE INTERCOM
400-018100-12	1014744-001	SV	2 FF HANDSET
4000369-8501	DH861A	SV	1 HORIZON IND
400-041181-0001	CDM-451	SV	1 DME TRANSCEIVER
400-045500-0005		SV	1 AFIS DMU
400-045500-2011		SV	2 AFIS DMU
4000460-0501	AD3405A	SV	1 SYS INTER ADAPTER
400-047152-9005	CVC-152	SV	10 COMM CONTROL NVG
400-048100-0008	CVC-151	SV	10 VHF COMM TRANSCEIVER
4000503-0203	IN1202A	SV	1 INDICATOR
4000504-0301	DA1203A	OH	2 ANTENNA DRIVE

4000525-1212		SV	3 RDR1400 PHASED ARRAY ANT
4000525-1218		SV	1 PHASED ARRAY ANTENNA
40007-1A64		NS	6 ADAPTER
4000833-0207	IN1401A	SV	2 RADAR IND
4000833-0208	IN1402A	SV	1 RADAR IND
4000965-0210	IN1302B	OH	2 RADAR INDICATOR
4000985-3101	DM-2031A	SV	1 DME R/T
4000986-3101	IN-2032A	SV	1 INDICATOR
400100-128		NE	1 COMPASS STANDBY 28 VOLT
40-0103-31		OH	1 LIGHT BEACON
40-0117-1		SV	1 LIGHT ASSEMBLY
4001291-2104	IN2021A	OH	1 RADAR INDICATOR
4001597-2304	IU-2023B	SV	2 REMOTE COMPUTER UNIT
4001598-2303	IU-2023C	SV	1 REMOTE COMPUTER UNIT
4001639-2405	CC-2024C	SV	1 MULTI-FUNCTION CHECKLIST UNIT
4001922-5201	IN-1152A	SV	1 COLOR RADAR INDICATOR
4001943-0401	AA1504A	SV	1 RDR1500 ANTENNA ARRAY
4001974-0207	IN1502A	SV	1 RADAR INDICATOR
4001977-0654	CN1506A	SV	1 RDR1500 CONTROLLER NVG 28V
40020-01		SV	8 HYDRAULIC PUMP
40020-01		OH	10 HYDRAULIC PUMP
4002963-404	RH404	OH	2 RMI
4002963-444	RH444	OH	2 RMI
4002963-904	RH404	OH	1 RMI
4004444-901	RA-210	OH	2 RADIO ALT IND
4004T63G04		OH	2 STATOR VANE ACTUATOR
4005088-0502		SV	1 MOUNTING TRAY
400-6		NE	25 AIRSPEED POINTER
4007261-0502		SV	1 RACK
4007543-0502		SV	1 MOUNTING TRAY
4007550-0507		NE	1 CONNECTOR KIT
4007561-0502		SV	1 MOUNTING TRAY
4007637-2	AT222	SV	1 ALTIMETER ANTENNA
4007701-9		NS	1 CONNECTOR
4008-103		NS	1 ECS RACK
400GL		SV	1 VOLTMETER
400R-1		SV	1 EMERGENCY LIGHT
400R-1		SV	1 EMERGENCY LIGHT
401/262		SV	1 ANTENNA CTL UNIT
4012373-903	SM710	OH	3 ACTUATOR
4012373-904	SM710	OH	3 ACTUATOR
4012373-905	SM710	OH	3 ACTUATOR
4012373-905	SM710	NE	10 LINEAR ACTUATOR
4012373-906	SM710	OH	3 ACTUATOR

4012373-907	SM710	OH	3 ACTUATOR
4012373-908	SM710	OH	3 ACTUATOR
4012373-909	SM710	OH	3 ACTUATOR
4012373-910	SM710	OH	3 ACTUATOR
4012373-911	SM710	OH	3 ACTUATOR
4012373-912	SM710	OH	3 ACTUATOR
4012373-913	SM710	OH	3 ACTUATOR
4012373-914	SM710	OH	3 ACTUATOR
4012373-915	SM710	OH	3 ACTUATOR
4012373-916	SM710	OH	3 ACTUATOR
4012373-917	SM710	OH	3 ACTUATOR
4012373-918	SM710	OH	3 ACTUATOR
4012373-919	SM710	OH	3 ACTUATOR
4012373-920	SM710	OH	3 ACTUATOR
4012455-2		FN	1 DC MOTOR BRUSH RING
4012565-1		FN	2 COND ASSY
4013013-907	VS200	SV	3 VER AIRSPEED
4013241-903		OH	1 AIR DATA COMPUTER
4013241-937	AZ-241	SV	1 AIRDATA COMPUTER
4013242-708	AZ-242	SV	1 AIRDATA COMPUTER
4013242-726	AZ-242	SV	1 AIRDATA COMPUTER
401-40-2		SV	1 AIRSPEED SWITCH
4018285-901	AL-205	SV	1 ALTITUDE ALERT CONTROLLER
4018368-901	MS500	SV	1 MODE SELECTOR
4018368-902	MS500	OH	1 MODE SELECTOR
4018368-913	MS500	SV	1 MODE SELECTOR
4020501-594	GH14	OH	1 GYRO HORIZON
4020550-904	AD300H	OH	1 ATTITUDE DIRECTOR INDICATOR
4021541-191	GH14B	OH	1 GYRO HORIZON
4021541-331	GH14	OH	1 GYRO
4021541-391	GH14	OH	2 GYRO HORIZON IND
4021541-560	GH14	OH	1 GYRO HORIZON IND
4021541-590	GH14	OH	1 GYRO HORIZON IND
4021541-671	GH14	OH	2 GYRO HORIZON IND
4021541-671		NE	1 GYRO HORIZON
4021541-671NVG	GH14	OH	2 GYRO HORIZON IND
4021541-791	GH14	OH	1 GYRO HORIZON IND
402-2301		NS	1 SPDT 1GHTZ COAX RELAY
4023400-0503	RT-859A/APX-72	SV	1 TRANSPONDER
4023400-0506	RT-859A/APX-72	SV	1 TRANSPONDER
4025008-910	SP711	SV	2 HELIPILOT COMPUTER
4025008-911	SP711	SV	2 HELIPILOT COMPUTER
4025008-915	SP711	SV	2 HELIPILOT COMPUTER
4026206-902	RI-206	SV	1 INST REMOTE CONTROLLER

4026206-972	RI-206	OH	1 INST REMOTE CONTROLLER
4027395-023		NS	1 PANEL
402-90-1		OH	1 PRESSURE SWITCH
4029377-907		FN	1 SP600 Autopilot Computer
4029377-912	SP600	AR	1 AUTOPILOT COMPUTER
403001-005	153-017310-01	SV	1 HPA/LNA
403001-006		SV	3 HPA LNA GPS PRE AMP
4030182-901	AC702	OH	1 ALTITUDE SENSOR
40-41320-1010		NE	3 DIAPHRAGM ASSY,ALTI
404-38-X018		SV	1 MOUNTING TRAY
404-910-1	5841-041-0540	SV	1 RT-833AV1/APN-175V
404-910-1	RT-833AV1/APN-175V	SV	1 RECEIVER TRANSMITTER
404A-25-S-D/DPXB-0		SV	2 TRAY
404A-38-S-1/DPXB/C-0		SV	2 TRAY
404A-50-X003		SV	1 MOUNTING TRAY
405001A-PMA		FN	1 Satcom IGA Antenna
405010A	AERO-I	SV	2 SATCOM HPA
405012A	AERO-I	SV	1 SATCOM DLNA
405016A		FN	2 TT-5016A High Power Amplifier
405033A-01	AERO-I	SV	1 SATCOM SDU CONFIG MOD
405033A-UAT-NRS	AERO-I	SV	1 SATCOM SDU
405622A-UAB		SV	1 SATCOM CRADLE
405624B-THR		FN	6 AVIATOR Wireless Handset Black
405AD		SV	1 AC ADAPTER
4-063-020-17		OH	1 INLET HOUSE
4-063-020-17		AR	1 INLET HOUSE
4-063-140-02		NE	2 PANEL ASSY
4066010-910		SV	1 TCAS II COMPUTER
407-240-018-101		SV	1 DRIVESHAFT TOOL SPAN
407-375-001-105	90090001-02	OH	1 MGT INDICATOR
407-375-008-101	DL439	OH	1 DUAL TACHOMETER INDICATOR
4-081-080-11		SV	1 FUEL PUMP DRIVE
4088468-902	DBA-1160MR	SV	1 ASSY SATELLITE ANT RCVG FLTD
4088622-2		NS	3 CONNECTOR
4088622-3		NS	7 INSULATR
4088622-4		NS	2 CONNECTOR
4092745-901	XMDPRT-02	SV	2 XMWX DATA PORT
40T15K		NE	1 PUSH BUTTON ASSY
4-101-060-13		SV	1 SHROUD ASSY
41102010-01		SV	1 ACTUATOR
41-104082-01		SV	1 RELAY UNIT
412-075-008-111	9813-25-21	OH	2 DUAL TORQUE IND
412-075-008-113	DT410-2	OH	2 DUAL TORQUE IND
412-075-010-111		SV	1 TRIPLE TACH

412-075-205-101	18-1842-7	OH	2 PRESSURE TORQUE TRANSDUCER
412-075-706-107	292-412-706-107	NS	2 PANEL
412-075-710-101	67564-101	NS	2 PANEL
412-075-711-101	97499/412-075-711-101	NS	2 PANEL
41222-100-009-001	100-009-001	SV	1 CVR
412-375-702-101	292-412-702-101	NS	2 PANEL
412-375-703-101	292-412-703-101	NS	2 PANEL
412-375-704-101	292-412-704-101	NS	2 PANEL
412-375-711-103	292-412-711-103	NS	1 PANEL
412-375-712-103	292-412-712-103	NS	2 PANEL
412-375-713-101	292-412-713-101	NS	2 PANEL
412-375-714-101	292-412-714-101	NS	2 PANEL
412-832-151		NS	2 SEARCHLIGHT CONTROL PANEL
4-141-010-24		SV	1 HOUSING
4-141-026-05		NS	1 SPACER
414-180615-3		NS	1 LENS RH WING
4-143-020-07		SV	1 HOUSING
4-143-020-07		NE	2 COMBUSTOR HOUSING
416-00293-010		SV	1 P/R SAS COMPUTER
416-00293-100		SV	1 P/R SAS RECHNER
416-00293-120		SV	1 SAS2000 COMPUTER
416-00297-302		SV	2 PA 4-AXES DUPLEX SAR
416-00297-310		SV	1 AUTO PILOT MODULE
416-00298-100		SV	2 APMS2100 EFIS
4-161-417-02		NS	2 REDUCER
418-00275-003	1560SA0572907	SV	3 BAROMODULE, AP AIR DATA CONTF
418-00302-000	704A47-1350-08	SV	1 ELECTRIC ACTUATOR
418-00625-114	704A47135033	SV	1 ACTUATOR,ROLL
418-00625-174		SV	1 ACTUATOR
418-00847-100		SV	1 SEMA 8399
418-00874-001	704A47-1320-58	SV	3 ACTUATOR,PITCH TRIM
418-00876-250		SV	1 SMART ACTUATOR
418-00876-800		SV	2 ACTUATOR
418-00876-800		AR	5 ACTUATOR
418-00881-000		SV	1 DUPLEX TRIM PARALLEL ACTUATOR
418-01141	212-061-010-001	SV	1 TRANSMITTER, OIL PRESS
418-02461-001		SV	1 ACTUATOR
418-09084	45AS86825-005	OH	1 OIL PRESSURE TRANSMITTER
4184NX		NE	1 FAN
41850A14-4580		SV	2 LANDING LIGHT
41850A17-4580		SV	1 LANDING LIGHT
419-00320-561	704A47-1332-05	SV	1 COUPLER, CDV 85
419-00320-660		SV	1 CDV AUTOPILOT COUPLE
419-00320-660		AR	1 CDV AUTOPILOT COUPLE

419-18		NS	1 SWITCH
41950-0000		SV	1 RECEIVER ACCESSORY
4200-005-2		NE	1 CIRCUIT BREAKER
420-00332-411		SV	2 AHRU APIRS F201
420-00332-460	261500123-0460	SV	2 AHRU
420-00339-000		NE	2 MAGNETOMETER
422-18152-933	18152-933	SV	1 STATIC CORR
422-23080-027	23080-027	AR	1 LEAR 35A/36A STATIC DIFF COR
422559-2WH	336695-802WH	AR	2 MAGNASTAR PHONE
422650-801	1HGD9REVB	SV	1 CABLE
42325-371		NE	3 MOTOR FAN ASSY
42325-389		NE	2 FAN MOTOR
4254A010-100		NE	8 SWITCH DIFFERENTIAL PR
426-1-13		SV	1 GALLEY SWITCH PANEL
42701-1	42701-01	SV	4 MOUNT
4271-606		NS	1 CONNECTOR
4271-613		NS	3 SWITCH MATRIX
427-375-001-103	160M020	SV	1 IIDS DISPLAY
42960-00	704A47612052	SV	1 INDICATOR,TACHOMETER
42HP601-19		NS	6 PANEL
42HP605-1		NS	1 PANEL
42HP911-1		NS	5 PANEL
42HP920-7		NS	4 PLATE
42HP926-1		NS	4 RING
42HP928-1		NS	1 PANEL
4300-20000-00		FN	1 DCU
430-040-080-101		OH	1 LOWER MAST BEARING CASE
4300-8170-1L	222-375-033-101	SV	2 ATTITUDE GYRO
4-301-099-10		OH	1 T1 SENSOR 650B1
4-301-099-10		AR	1 T1 SENSOR 650B1
4-301-128-04 C	4-301-128-04	NE	1 FUEL PUMP
4-301-483-01		OH	1 CONTROLLER
4-301-483-01		AR	1 CONTROLLER
4-301-687-01	6860501E1	OH	1 FUEL MANIFOLD
430-215-100-101		SV	1 GAUGE, TRIM TAB BEND
43025-0400		NS	20 RECEPTACLE
430-360-055-101		SV	1 SOLENOID MECH
4305-7150L		SV	1 DIRECTIONAL GYRO
4305-8175-1L	222-375-034-101	SV	2 ATTITUDE GYRO
430-6090-600	GSL71	SV	1 UAT CONTROL PANEL
4308-05000-20-101		NE	1 FAERITO AVIONICS RECORDER
4308-15003-23-101		NE	1 RIGHT HAND CAMERA
4344-2020	206-075-706-3	OH	1 OIL PRESSURE IND
4351-1203		SV	1 TORQUE METER

43622-02-03-01		SV	1 ROLL ROD ASSY
437-1-4		SV	1 CONTROLLER: GALLEY CALL
438-00100-021		NE	2 PITCH YAW GYROMETER
438-00100-021		SV	1 PITCH YAW GYROMETER
4-381-128-10		SV	1 FUEL PUMP
442042-1		SV	1 FUEL CONTROL APU
44301-406		NE	1 FLOAT ASSEMBLY
44301-700		SV	1 FUNCTION BOX
44311-721		SV	1 PENDANT CONTROLLER, HOIST
44410-2-245		SV	1 ROTATING
444-DMC57-1	CD-571	SV	1 ANTENNA, UHF, BLADE
4484-100-020		SV	1 MASTER CAUTION PANEL
449-2	212-075-962-1	SV	1 POWER SUPPLY
45-0019-7		OH	1 LANDING LIGHT
450-1000-200		SV	1 CAMERA POD FLIR 4000, ULTRA
450120-H		NS	16 SEAL PLAIN ENCASED
45-0182-1	76550-02005-101	OH	1 SEARCHLIGHT
45-0182-3	76550-02005-102	OH	1 SEARCHLIGHT
45-0182-5	76550-02005-103	OH	1 SEARCHLIGHT
45-0182-7	76550-02005-104	OH	1 SEARCHLIGHT
45-0182-7M		OH	1 SEARCHLIGHT
45-0253-11		OH	1 LAND LIGHT RETRACT
45-0300-1		SV	1 NVG SEARCHLIGHT, CONTROL, F3
45-0300-1		SV	3 SEARCH LIGHT
45-0339-11		SV	1 SEARCH LIGHT
452-0111		SV	1 ANTENNA
452100-02		SV	3 MODE SELECTOR UNIT
453-0150-01	ELT100HM	SV	2 ELT
453-6603		SV	1 ELT
4545-00-5	209-072-433-101	SV	1 VALVE
454640-01	LTN72	SV	1 CONTROL DISPLAY UNIT
454C01		NE	6 DRAIN VALVE
455-0407		SV	1 ELT
455-5001(999)	455-5001	NE	1 EMERGENCY TRANSM C406-2H
455-6196		NE	16 INSTALL KIT W/NAV REMOTE SWITC
455-6500		NE	4 ELT/NAV INTERFACE
45900-1		SV	1 ANTI-COLL-BEACON
45AS88856-3		SV	1 CONTROL BOX
46060-10	706-10	OH	2 GYRO DISPLACEMENT
46060-11	706-11	OH	2 GYRO DISPLACEMENT
4632AA	704A49430049	SV	1 BOX,DETECTOR VIBRATION ANALYS
46700-1	704A47111037	SV	1 IND-W SETTER,VERT- SPEED FT/MN
46D36		NE	1 VENTIL
47-00000-9		SV	1 CHADWICK CONTROL

47-120-142-1		NS	4 SEAL
47360-1100		SV	1 TRANSCEIVER
47-620-200-12T210		SV	1 PLUG TOOL
47-620-617-007	2802-070-8060-80080	NS	80 PLATE
47-644-213-003		NS	3 BEARING HOUSING
481-301-104	76450-00706-104	OH	2 T5 INDICATOR
481-401-103	76450-00706-103	OH	1 DUAL TORQUE IND
481-501-104	76450-00706-102	OH	1 TRIPLE TACH INDICATOR
482-5086-010	6695-00-438-3977	NE	10 METER MOVEMENT
483GC01Y032	704A46570104	SV	1 MASTER,ELECTRICAL,RT
48707-002	527-48707-002	OH	1 SERVO ALTIMETER
48770017-01		SV	1 NAV SENSOR UNIT
488-3305-001		SV	1 CONTROL
492-1-50		SV	1 UNIVERSAL SPC
492GC01Y021	704A46570068	SV	1 ELECTRICAL MASTER BOX,LH
494-116-001-694		SV	3 HEADSET, MIC
4A16.32.60F.28.4.CE		NE	8 VERTICAL SPEED INDICATOR
4A2000-1B		SV	1 FREQ CONVERTER
4AA-010-105-103		NE	4 STUD
50-0002-01	50-000X-XX	SV	1 CDI-500 COURSE DEV IND
500185-5		SV	1 AEROROUTER 700
500-21	C668520-0101	OH	1 OAT INDICATOR
500-23164-101		NE	1 KIT, HSD-400 RF COAX
500-280		SV	1 3 PHASE AC
500-30577-17		NE	1 HPA TO ANT COAX
500-30577-18		NE	1 HPA TO ANT COAX
5006-1036		OH	1 TOT-INDICATOR
5006-1039		NE	1 EXHAUST TEMP. INDICATOR
500-83007-01	311501	NS	1 COAX CABLE ASSY
500-83007-02	311501	NS	1 COAX CABLE ASSY
500-83007-03	311501	NS	1 COAX CABLE ASSY
500-83007-04	311501	NS	1 COAX CABLE ASSY
5008512-002		SV	1 DATA BUS COUPLER
500N5433		NS	1 SEAL
50-1-053		SV	3 NO SMOKING PANEL
501-1038-01	AC111D	SV	1 FLT CONTROL
501-1121-01		SV	1 VG208A Vertical Gyro
501-1121-01		OH	1 VG208A Vertical Gyro
501-1121-01		AR	2 VG208A Vertical Gyro
501-1142-03	AD102A	SV	1 AIR DATA SENSOR
501-1142-04	AD102B	SV	1 AIR DATA SENSOR
501-1170-21		OH	1 ATTITUDE GYRO
501-1170-23	AI-904U/HA/B	OH	1 ATTITUDE GYRO
501-1170-27		OH	1 ATTITUDE GYRO

501-1170-40		OH	1 ATTITUDE GYRO
501-1185-01	FN100A	SV	1 RFI FILTER NETWORK
501-1197-29	AI-804CE	OH	1 ATTITUDE INDICATOR
501-1207-08	DC-2001H	SV	1 DIGITAL NAV COMPUTER
501-1210-01	VG208C	OH	1 VERTICAL GYRO
501-1224-02	76600-02113-102	OH	1 VERT GYRO
501-1240-01	SI-100A	SV	2 STATIC INVERTER
501-1453-01	76600-02113-103	OH	4 VERTICAL GYRO
501-1475-01		FN	1 PS-855A S.I. 115V
501-1568-17	AI330	OH	2 ATTITUDE INDICATOR
501-1845-01	AI-803CY	NE	3 HORIZON INDICATOR
501-1845-01	AI-803CY	OH	2 HORIZON INDICATOR
501580-401		AR	1 SEAT BELT
5018-753-00-00		SV	1 AUDIO AMP
502-1-50		SV	1 VIDEO SPC WITH ALAN I
502A15		SV	1 POWER ADAPTER UNIT
502-DP1-ST5	2102-070-1060-10010	NS	10 SPRING CLAMPS
503067-405-2255		NS	1 SEAT BELT
503067-407-4185		NS	3 SEAT BELT
503068-409-2862		SV	2 BELT ASSY
503-19-3		SV	1 G-SWITCH
503-22		NE	1 COCKPIT CONTROL PANEL
5035P2-P26P.100	5035P2-P26	OH	1 ENCODING ALTIMETER
50-380034-3	515-3	SV	1 TACHOMETER IND
50-384081-21	B326-1	OH	1 ENGINE GAGE
50-389091	22-280-026-1A	SV	1 TACH SYCHRO INDICATOR
504-0017-901	510-1A	AR	1 ATTITUDE GYRO
504-0017-901	510-1A15	OH	1 ARTIFICAL HORIZON
504-0017-908	510-1B	OH	1 ATTITUDE GYRO
504-0017-917	5108C	OH	1 ATTITUDE GYRO
504-0017-933		OH	2 ATTIT.GYRO (510-1P-15)
504-0035-905	520-2A	OH	1 GYRO
504-0045-902	510-35B	OH	1 ATT GYRO
504-0110-905	1100-14S(11)	OH	1 HORIZON GYRO
504-0111-902	1100-28(11)	OH	2 HORIZON GYRO
504-0111-903	1100-28L(20B)	OH	2 HORIZON GYRO
504-0111-904	1100-28(0)	OH	2 HORIZON GYRO
504-0111-905	1100-28L(0F)	OH	2 HORIZON GYRO
504-0111-906	1100-28(0)CES	OH	1 HORIZON GYRO
504-0111-907	1100-28LS(8F)	OH	2 HORIZON GYRO
504-0111-908	1100-28(5)	OH	2 HORIZON GYRO
504-0111-909	1100-28(8)	OH	2 HORIZON GYRO
504-0111-910	1100-28(12)	OH	2 HORIZON GYRO
504-0111-911	1100-28(14)	OH	2 HORIZON GYRO

504-0111-912	1100-28L(5F)	OH	2 HORIZON GYRO
504-0111-913	1100-28L(7F)	OH	2 HORIZON GYRO
504-0111-914	1100-28L(8F)	OH	2 HORIZON GYRO
504-0111-915	1100-28L(12F)	OH	2 HORIZON GYRO
504-0111-916	1100-28L(14F)	OH	2 HORIZON GYRO
504-0111-917	1100-28LS(0F)	OH	2 HORIZON GYRO
504-0111-918	1100-28LS(5F)	OH	2 HORIZON GYRO
504-0111-919	1100-28LS(12F)	OH	2 HORIZON GYRO
504-0111-920	1100-28LS(14F)	OH	2 HORIZON GYRO
504-0111-928	1100-28LS(7F)	OH	1 HORIZON GYRO
504-0111-929	1100-28L(15F)	OH	2 HORIZON GYRO
504-0111-930	1100-28LS(15F)	OH	1 HORIZON GYRO
504-0111-931	1100-28L(11F)	OH	2 HORIZON GYRO
504-0111-932	1100-28LS(11F)	OH	1 HORIZON GYRO
504-0111-933	1100-28L(15B)	OH	1 HORIZON GYRO
504-0111-934	1100-28L(10F)	OH	1 HORIZON GYRO
504-0111-935	1100-28LS(16F)	OH	1 HORIZON GYRO
504-0111-937	1100-28L(6F)	OH	1 HORIZON GYRO
504-0111-940	1100-28L(4F)	OH	1 HORIZON GYRO
504-0111-942	1100-28LS(14E)	OH	1 HORIZON GYRO
504-0111-943	1100-28LS(11B)	OH	1 HORIZON GYRO
504-0111-944	1100-28K(10)	OH	1 HORIZON GYRO
504-0122-902	1200-2RS(15D)	OH	2 AH3 HELI 28V FRONT W
504339-211-1028		NE	1 LAP BELT ASSY
505-0002-904	200DC(28)	OH	1 DIRECTIONAL GYRO
505-0002-917		OH	1 DIRECTIONAL GYRO
505-0010-902	200DCL	OH	1 DIRECTIONAL GYRO
505-0031-904		NE	1 DIRECTIONAL GYRO
50691-7	222-375-062-107	SV	2 MAST TORQUE SIGNAL CONDITIONI
50691-9	222-375-062-109	SV	1 MAST TORQUE SIGNAL CONDITIONI
507-220-101	2102-070-1060-10010	NS	10 CIRCUIT BREAKER SWITCH
5083-100		NE	1 RADOME ASSY
50C-0024-10		OH	1 INDICATOR
50C-0024-10		AR	2 INDICATOR
50C-0024-12		OH	2 INDICATOR
50C-0024-12		AR	2 INDICATOR
51008-0065		NE	4 IC
5110-1050-00		SV	1 BEVERAGE MAKER
513-18352-10	18352-10	SV	1 SDC MODULE
51522-000	222-375-060-103	SV	1 REGULATOR/CONTROLLER
51522-002	222-375-060-109	SV	1 REGULATOR/CONTROLLER
51530-006A	76550-09006-105	SV	1 D-C- GENERATOR CONTROL UNIT
51538-005A		NE	1 DC GENERATOR CONTROL UNIT
51538-005A		SV	2 DC GENERATOR CONTROL UNIT

51565-000R		SV	4 VOLTAGE REGULATOR
518-16007-161	16007-161	OH	1 ALTIMETER
518-16007-334	16007-334	SV	1 ENCODING ALTIMETER
51824-1	2602-070-6060-60060	NS	60 GREEN THERMASHIELD
5201-1		SV	1 ATC CONTROL PANEL
520-3150-003	HSI-315A	SV	1 STANDBY H.S.I.
520-3337-207	3337LB21C	SV	1 RADIO MAGNETIC INDICATOR
520-4150-007	HSI-415A	SV	1 STANDBY H-S-I-
520-7137-014		OH	1 RMI
520-8014-001	RVG-801E	NE	2 VERTICAL GYRO
520-9100-101		OH	1 DIRECTIONAL GYRO REMOTE
522-0240-003	350X-1	SV	6 RACK
522-0700-023	37P-5	SV	1 GLIDE SLOPE ANTENNA
522-1658-000		SV	1 MOUNTING TRAY
522-1660-000	618T3	SV	1 HF TRANSCEIVER
522-2357-019	614L8	SV	1 ADF CTL
522-2447-560		SV	1 NAV CONTROLLER
522-2449-000		SV	1 VHF CONTROLLER
522-2644-00		OH	1 SLAVING ACCESSORY UNIT
522-2644-011		OH	1 SLAVING ACCESSORY UNIT
522-2788-015		SV	1 MONITOR, COMPARATOR WARN
522-3443-000	490T1	SV	1 ANTENNA COUPLER
522-3616-204	313N4D	SV	1 CONTROL UNIT , NAV
522-3617-003		SV	1 CONTROL UNIT , VHF
522-3761-001	137A6A	SV	1 ADF ANTENNA
522-3918-001		SV	1 CONTROL IND
522-3918-004		SV	1 COMPARATOR MONITOR IND
522-3948-001	54W1C	SV	1 MONITOR COMPARATOR WARN
522-4114-003		OH	1 RAD ALT INDICATOR
522-4140-007	437X1	SV	1 ANTENNA
522-4853-001	5985-00-617-7123	OH	2 ANTENNA
522-4945-001	323A2G	SV	1 FLUX VALVE
5232C		SV	1 INTERFACE ADAPTOR
52347-100BCL	262-070-660-606	NS	10 NUT
52347-100BCL		NE	20 NUT
52355FBD050N	2112-070-1160-11011	NS	11 FASTENER
524-031	704A46-1010-11	OH	1 STARTER GENERATOR
528401-5		SV	1 EATON RUDDER TRIM CTL
52D67M	700-3CF	OH	1 ATTITUDE GYRO
5306-155-00-10	704A37-641-008	OH	2 OIL PRESSURE IND
5306-155-00-10		OH	1 ENGINE OIL PRESSURE IND
5306-160-00-11		OH	1 MGB OIL PRESSURE IND
5306-168-00-10		OH	1 OIL PRESSURE IND
5306-255-00-11	704A37-633-008	OH	1 OIL TEMP IND

5309-155-00-11		OH	2 FUEL PRESSURE IND
53114-24ADL		NS	1 WASHER
53114-24ADL		NE	1 WASHER
53114-24ADL		NE	1 WASHER
53-1784-503-00		SV	1 PANEL
540-011-118-001	540-011-118-1	NE	1 BARREL
540-011-123-001	540-011-123-1	OH	5 PINS
540-012-125-005	3120-01-026-6942	FN	16 SLEEVE
540-012-125-007	3120-01-026-6943	FN	9 SLEEVE
540-012-125-5	3120-01-026-6942	FN	16 SPACER
540-012-125-7	3120-01-026-6943	FN	9 SPACER
540-23989-011	23989-011	OH	2 ALTITUDE SELECT
542-1037-08		NE	1 DUAL SWITCH MODULE
5448-706-91-10		OH	2 N1 INDICATOR
5448-709-91-11	117-902101	SV	1 N1 INDICATOR
5448-709-91-11	117-902101-A	SV	1 N1 INDICATOR
5448-712-91-10		OH	2 N1 INDICATOR
5485-054-K		SV	1 ACTUATOR
549-4800-000		NS	1 SWITCH
5500-01		SV	1 LED READ LIGHT
5501-04		NS	14 READING LIGHT
5501-05		NS	9 READING LIGHT
550-18013B-012	18013B-012	OH	1 VSI
550-18013B-954	18013B-954	OH	1 VSI
5506L-S		OH	2 ALTITUDE ALTERTER
5506L-SL14		OH	1 ALTITUDE ALTERTER
5506-S		OH	1 SERVOED ENCODING ALTIMETER
5506-S5		OH	1 SERVOED ENCODING ALTIMETER
5506-S5-Y		OH	1 SERVOED ENCODING ALTIMETER
5506-SG		OH	1 SERVOED ENCODING ALTIMETER
5506-SG5		OH	1 SERVOED ENCODING ALTIMETER
5506-SG5Y		OH	1 SERVOED ENCODING ALTIMETER
5506S-S-39		OH	1 SERVOED ENCODING ALTIMETER
55100-010		NE	1 YOKE FOR PULLER
55132-102	2142-070-1460-14014	NS	14 PIN
55134-202		NS	5 RECEPTACLE
55216-092-112		NS	1 CLAMP
5550-101-07	FLIGHT VISIONS	SV	2 HEADS UP DISPLAY PDU
5550-8340N5L		OH	2 2 INCH TURN AND SLIP
5550-9235N1L	222-375-072-101	SV	2 TURN & BANK IND-
5560-8165N1L	222-375-028-101	SV	2 TURN & BANK IND-
5600-S938	209-075-372-1	SV	2 RELAY, TIME DELAY
5601-036		SV	2 ROSEN MONITOR
5601-130		SV	1 ROSEN MONITOR

5601-160		SV	2 ROSEN MONITOR
56056-0101A	56056-0101	SV	1 SATCOM FAX APAPTER
5617-355-91-11	704A47-660-012	OH	1 INDICATOR, OIL TEMP & PRESS
5622103A		NE	2 IFF MOUNT MTR401
5626-555-00-11	704A47-632-038	OH	1 TEMP IND
5633-619-00-12	704A47612123	OH	1 INDICATOR DELTA NG
566-1814-04		NS	1 CLAMP MOUNTING IND
5677-752-00-12	704A47621125	OH	1 INDICATOR TORQUEMETER
5678-553-80-12		OH	2 ITT IND
5678-710-80-12		OH	1 PROPELLER SPEED IND
568A0000-01		SV	2 SOLENOID VALVE
570-24929-053		OH	1 ENCODING ALTIMETER
571-2	222-375-009-103	OH	1 DETECTOR, RPM LIMIT
5713-20-10-C2C		NE	24 STUD, TURNLOCK FASTENER
5718-A3-ACNC		NE	6 TURNLOCK FASTENER
574-1220-01		NS	1 HARNESS
574-3		SV	1 WINDSHIELD TEMP CONTROL
575-31500-436		SV	1 AIRSPEED IND-
5800-465-80-14	704A47270025	OH	1 INDICATOR 14 INFOS
5800-473-80-10	704A47270129	OH	1 INDICATOR 14 INFOS
5800-483-80-10	704A47270136	OH	2 INDICATOR MFD
5802-1006		OH	1 AIRSPEED INDICATOR
58057-12	461-00272-101	OH	3 GYRO
58057-42	461-00272-101	OH	1 DIR GYRO
5821-01-135-6056	RT-1168C/ARC164V	SV	1 RCVR/TRANS
5821-01-137-6300	RT-1168B/ARC164V	SV	1 RCVR/TRANS
582-507-11		SV	1 TCAS IND
586BK-0142		OH	1 AIRSPEED IND
58960-4088630-901	4088630-901	NS	12 CONNECTOR ASSY
5909244-4		SV	1 INDICATOR
59140-010		NS	1 PROXIMITY SENSOR
5916-46A-1-B		OH	1 INDICATOR AUTOSYN
5934A-1		OH	1 ALTIMETER
5934PAD-3		AR	1 ALTIMETER
59-52.02-41-70		NS	2 CLAW RING WASHER SET
5952-CW-6	5952-CW-6 REV C	NE	1 LUMINATOR
597-1987-003	51RV-4DF	SV	1 NAV RCVR
5A16.32.18K.28.4.DT		NE	8 AIRSPEED INDICATOR
5A16.32.30K.00.0.BK		SV	1 Airspeed Indicator
5A16-13-27K-00-0A		OH	1 AIRSPEED INDICATOR
5A58-42-45K-05-1-DH		OH	1 AIRSPEED IND
5-AS350-19		OH	1 COMPRESSOR ASSY
6004061-10		SV	1 BRAKE CONTROL SYSTEM
600-52262-1		NE	1 PLACARD

600-52262-2		NS	1 PLACARD
600-52267-6		NE	1 PLACARD
600-52267-6		NE	1 PLACARD
6007-61B-7B		OH	1 INDICATOR OIL QUANTITY
60-1431-3		SV	1 GRIMES STROBE LIGHT PWR SUPPL
60-1592-5		SV	1 STROBE LIGHT POWER SUPPLY
60-1755-1		SV	1 STROBE LIGHT POWER SUPPLY
601A50922-11		NE	4 BEZEL
601A50923-7		SV	1 LIGHT PANEL
60225S0CN8044286		SV	1 CURSOR CONTROL DEVICE
602667-1		SV	1 POWER SUPPLY
602-7664		SV	1 HAND MIC
60-2885-1	60-2885-1REVD	SV	1 STROBE LIGHT PWR SUPPLY
60-2915-1		SV	1 FILTER ASSY
603-32-0		NS	3 TIMER
60344-103		NE	1 PUMP
60-3474-3		SV	3 POWER SUPPLY
6038T62P13	763700-13	SV	1 H-M-U-
6041H190		SV	1 RELAY 200 AMP SPST
6041H255	369A4658	NS	2 DC AIRPLANE CONTACTOR
6073-102		SV	1 MOUNTING TRAY
608-9419-003	5821-01-023-9318	OH	1 GUARD RCVR
608-9420-003	5996-01-248-0614	SV	2 AMPLIFIER,INTERMEDIATE FREQ
609-4009-001		NE	2 KNOB
6097768-200		SV	1 AIR TRANSPONDER
6103-1004		OH	1 ALTIMETER
610C-001		SV	1 ENGINE MONITOR
611-016		NE	2 AURAL WARNING GENERATOR
61148-110		OH	1 CONTROL BOX
61148-110		NE	4 CONTROL BOX
61-21-3		NE	1 BALLAST FLUORESCENT LAMP
612-1-52885-001		SV	1 BLADE TRACKER
61474-130-1		OH	1 INDICATOR,NR-NTL1-NTL2
61474-130-2	704A-47-616-023	OH	1 INDICATOR,NR-NTL1-NTL2
61476-402-1	704A47610065	OH	1 INDICATOR NR-NTL
61533-107-1		OH	2 TEMP IND
61595-0101		NE	2 KIT
616-ECU-01		SV	2 AMPLIFIER
616-ECU-01		AR	2 AMPLIFIER
617-6195-103		NS	1 RACK ASSY
617-8759-002		SV	5 RECEIVER BOARD
617-9618-001	5821-00-180-8250	SV	1 SYNTHESIZER, FREQUENCY
618-5054-002		NE	1 PLATE
618-5057-002		NE	1 PLATE

618-5078-005		NE	1 PLATE
618-5079-002		NE	1 PLATE
618-5080-001		NE	1 PLATE
620317-2REVE	620317-2	SV	3 DUPLEXER
621-0450-001		OH	3 618M3 SUBASSY
621-0451-001		OH	1 618M3 SUBASSY
621-0451-002		OH	2 618M3 SUBASSY
621-0452-001		OH	1 618M3 SUBASSY
621-0452-005		OH	2 618M3 SUBASSY
621-0453-003		OH	2 618M3 SUBASSY
622-0142-003		SV	1 SELECTOR, REMOTE
622-0171-002	339H3	OH	1 RAD ALT IND
622-0193-001	641D1	SV	2 CAPACITOR
6220-300-01	FLIGHT VISIONS	SV	1 HEADS UP DISPLAY GRID AMP
62-2040	9900BX	FN	2 XPDR COUPLER KIT
622-0629-002	913F2	SV	1 CONTROL, RADIO SET
622-0876-001	VIR30A	AR	2 NAV RCVR
622-0876-011	VIR30A	SV	5 NAV RCVR
622-0876-012	VIR30A	AR	2 NAV RCVR
622-0876-201	VIR30A	AR	1 NAV RCVR
622-0876-211	VIR30A	SV	5 NAV RCVR
622-0876-212	VIR30A	SV	1 NAV RCVR
622-0950-001		SV	1 MODE SELECTOR
622-1032-001	699Z1	SV	10 RMI ADAPTER
622-1036-001	161H1	SV	1 PROGRAMMER
622-1204-002	339H4	OH	2 RAD ALT IND
622-1204-003	339H4	OH	2 RAD ALT IND
622-1204-004	339H4	OH	2 RAD ALT IND
622-1205-001	339H4A	OH	1 RAD ALT IND
622-1205-002	339H4A	OH	1 RAD ALT IND
622-1205-003	339H4A	OH	1 RAD ALT IND
622-1205-004	339H4A	OH	1 RAD ALT IND
622-1239-201	VIR31A	SV	2 RCVR, VOR/LOC/GS/MB
622-1270-001	TDR90	AR	5 TRANSPONDER R/T
622-1334-002	VHF20B	AR	2 VHF COMM TRANSCEIVER
622-1391-003	5895-00-567-4548	SV	2 CONTROL RCVR TRANS
622-1391-004	5895-01-513-5529	OH	1 CONTROL RCVR TRANS
622-1678-001	5826-01-012-4864	SV	2 ADAPTER, RECEIVER-TRANS
622-1738-002	913Y1	SV	1 MODE SELECT UNIT
622-1742-003	990C3D	SV	1 MOUNTING TRAY
622-1783-001	MT4682A	OH	2 MOUNTING BASE
622-1879-001	VHF20A	AR	8 COMM TRANSCEIVER
622-1879-002	VHF20A	AR	8 COMM TRANSCEIVER
622-1879-002	VHF20A	OH	8 COMM TRANSCEIVER

622-1945-011	339R7	SV	4 REMOTE READOUT UNIT
622-1947-011		SV	1 REMOTE READOUT UNIT
622-2041-001	MT-4915A	OH	3 MOUNTING BASE
622-2080-011	VIR351	AR	2 NAV
622-2091-000		SV	1 RCVR
622-2091-001		SV	1 RCVR
622-2093-001		SV	1 POWER CONVERTER PWC-150
622-2313-058		SV	1 FLIGHT GUIDANCE PANEL
622-2362-001	ADF60A	SV	4 ADF RCVR
622-2506-002	RMI-36	SV	1 RMI
622-2506-004	RMI36	SV	2 RMI
622-2883-001	PWR200	OH	1 HF POWER AMPLIFIER
622-2884-004	AAC200	SV	1 HF COUPLER
622-2913-001		SV	1 RELAY UNIT
622-2921-001		OH	1 860E5 DME TRANSCEIVER
622-2921-001	860E5	OH	1 DME TRANSCEIVER
622-2923-004	PRE80A	AR	1 ALTITUDE ALERTER
622-2937-004	ALI55	OH	1 RAD ALT INDICATOR
622-2937-009	ALI55	OH	1 RAD ALT INDICATOR
622-2938-001	ALI55A	OH	1 RADIO ALT INDICATOR
622-2938-002	ALI55A	OH	1 RADIO ALT INDICATOR
6222M87		SV	2 ACCELEROMETER
622-3015-001	SVO80A	AR	1 PRIMARY SERVO
622-3374-002	ADI55V	OH	3 ATTITUDE DIRECTION INDICATOR
622-3670-001	TCR451	SV	1 DME
622-3915-001	IND40	SV	1 DME IND
622-3920-001	IND41B	OH	1 DME IND
622-3922-002	990C12	OH	1 HF COUPLER RACK
622-4038-001	RT-1300/ARC-186V	SV	1 RECEIVER TRANSMITTER
622-4160-015	DRI55	OH	1 RAD ALT INDICATOR
622-4298-001	HSI45	OH	3 HORIZONTAL SITUATION IND
622-4523-015	CTL20	AR	3 COMM CTL
622-4524-087	CTL30	AR	1 NAV CONTROL
622-4526-015	CTL60	SV	2 ADF CONTROL
622-4527-015	CTL90	SV	1 TRANSPONDER CONTROL
622-4730-002	FPA80	SV	3 FLIGHT PROFILE ADV
622-4782-001	VSI-80A	OH	1 INDICATOR, VERTICAL SPEED
622-4782-004	VSI80A	SV	1 INDICATOR, VERTICAL SPEED
622-4938-007	RMI30	AR	2 INDICATOR, RADIO MAG
622-5369-002	993S1	SV	2 MOUNTING BASE, ELEC EQUIPMEN
622-5462-004	728U-2	SV	1 HF R/T
622-5612-036	RTU-90	SV	1 RADIO TUNE UNIT
622-5656-001	PAC200	SV	1 HF COUPLER
622-6019-001	SSS-65	SV	1 SLIP SKID SENSOR

622-6137-001	VIR32	OH	4 RCVR, VOR/LOC/GS/MB
622-6152-001	VHF22A	AR	6 TRANSCEIVER, VHF COMM
622-6152-011	VHF22A	OH	2 TRANSCEIVER, VHF COMM
622-6152-031	VHF22A	OH	2 TRANSCEIVER, VHF COMM
622-6174-001	RCP-65	SV	2 REMOTE COMPENSATION UNIT
622-6199-001	HPU74A	AR	1 H-S-I- PROCESSOR UNIT
622-6200-002	HCP-74	SV	1 H-S-I- CONTROL PANEL
622-6212-003	UMT12	NE	1 RACK
622-6321-001	RT-1250A	SV	4 ARC-182 COMM UNIT
622-6520-007	CTL22	OH	1 VHF CONTROL
622-6520-007	CTL22	AR	2 VHF CONTROL
622-6520-008	CTL22	AR	2 VHF CONTROL
622-6521-013	CTL32	SV	1 CONTROL
622-6521-014	CTL32	SV	2 NAV CTL
622-6523-005	CTL92	AR	2 TRANSPONDER CONTROL
622-6523-008	CTL92	AR	2 TRANSPONDER CONTROL
622-6523-203	CTL92	OH	2 TRANSPONDER CONTROL
622-6557-001	TCR230	AR	2 HF TRANSCEIVER
622-6590-001	CAD62	AR	5 CONTROL ADAPTER
622-6590-002	CAD62	AR	2 ADF/TRANS ADAPTER
622-6590-002	CAD62	NE	1 ADF/TRANS ADAPTER
622-6590-002	CAD62	SV	2 CONTROL ADAPTER
622-6614-022	CTL230	AR	1 HF CONTROL
622-7139-002	PAC230	SV	1 HF PROBE COUPLER
622-7154-002		AR	2 FAN MONITOR MODULE
622-7292-101	VHF-422A	AR	1 VHF COMM TRANSCEIVER
622-7382-101	ADF462	AR	1 ADF RECEIVER
622-7667-001	DDA-42	SV	3 ADAPTER, DME DIGITAL DISTANCE
622-7695-001	CAD-870G	AR	4 TRANSPONDER CTL ADAPTER
622-7695-002	CAD-870G	AR	4 TRANSPONDER CTL ADAPTER
622-7824-001	790S11	SV	1 MOUNTING BASE, ELEC EQUIPMEN
622-8332-002	CAD31	SV	2 CONTROL ADAPTER
622-8365-003	PWR851A	SV	4 IAPS POWER SUPPLY
622-9116-014		AR	1 DISPLAY SELECT PANEL
622-9210-108	TDR94D	SV	3 TRANSPONDER
622-9301-003	RTA-852	SV	2 RECEIVER TRANSMITTER ANTENNA
622-9313-004	C-12019A	SV	4 ARC-182 CONTROL UNIT
622-9353-415		NS	1 TVI-920D ACAS Display
622-9405-001		SV	2 HF-9042 HF Coupler
622-9462-004	PRE-80C	OH	1 PRESELECTOR/ALERTER
622-9462-025	PRE-80C	SV	1 PRESELECTOR/ALERTER
622-9728-415		FN	1 TVI-920D TCAS VSI
625614-1-1		SV	1 CONTROL SENSOR TEMP
628-6492-001		SV	1 HF 230 RACK

628-6492-003		SV	1 RACK
628-8657-001		SV	1 RACK ASSY
629-7941-026		SV	1 BEECH 200 MOD FOR PN 622-3167
62980-2		NS	1 STRIKER
629-9503-001		SV	1 FLAT PLATE 12IN
6302-101	S0085-109	SV	1 MOUNTING TRAY
63-211378-003	890119-940	SV	2 INCLINOMETER PANEL
634-0333-001		SV	1 MOUNTING TRAY
634-1081-003		NE	1 PIGGYBACK BRACKET
634-1103-003		NE	4 ADAPTOR KIT, DUAL (UMT-12)
634-1104-003		NS	1 PIGGYBACK KIT
634-1112-001		NE	1 CONNECTOR KIT
634-1130-012		NE	1 CONNECTOR PLATE
634-1898-003		NE	4 CONNECTOR KIT
63700-025		NE	5 HEADSET
637-1981-001	637-1472-001	SV	1 HF CTL SELECTOR
637-6500-001	5821-01-077-3397	OH	1 PANEL ASSY
637R		SV	1 WHEATSTONE BRIDGE
638-6378-002	5998-01-251-6833	SV	2 CIRCUIT CARD ASSEMBLY
638-6378-003	5998-01-318-0299	OH	1 CIRCUIT CARD ASSEMBLY
638-8270-002	5998-01-100-6095	OH	2 CIRCUIT CARD ASSEMBLY
638-8273-002	5998-01-100-6089	OH	2 CIRCUIT CARD ASSEMBLY
64/55980		SV	4 SERVO ACTUATOR
6402-11001-01		AR	1 MFD-640, No DSP or AUX, Gray
6402-11001-01		SV	1 MFD-640, No DSP or AUX, Gray
6402-11011-01	MFD-640	OH	1 FLAT PANEL INTEGRATED DISPLAY
64050-228-1		SV	1 AIRSPEED INDICATOR
64142-720-1		SV	1 ALTIMETER
64210-002-1		SV	1 FUEL PRESSURE TRANSMITTER
6430-91015-102	2995-00-992-9399	SV	4 BLOWER,AIR INLET SE
64435B-103		SV	1 MOUNTING TRAY
64514-203-1	704A-37-616-003	OH	2 TACHOMETER IND
64514-208-1	704A47616009	OH	2 TACHOMETER IND
64530-068-4	704A47612044	OH	1 TACHOMETER IND
64536-500-1	704A37612012	OH	1 TACHOMETER IND, ROTOR
64538-305-1	704A47612092	OH	1 NG INDICATOR
64538-308-1		OH	1 TACHOMETER IND
64-55980		SV	1 SERVO ACTUATOR
64-55990		NE	1 SERVO ACTUATOR FAS/20/MB/11C,
6461-1		SV	1 ADF CONTROL
646-5410-001	5998-01-251-4580	SV	1 CIRCUIT CARD ASSEMBLY
64807-605-1		OH	1 INDICATOR, OIL TEMP MGB
64809-417-1		OH	1 INDICATOR, OIL MGB
64809-421-1	704A47-641-028	OH	1 INDICATOR, HYD PRESS MAIN

64809-617-1	704A47641085	OH	1 OIL PRESS INDICATOR MGB
64838-006-1		OH	1 PRESS IND
64905-005-1	704A47-730-007	OH	1 INDICATOR, PITCH
64905-006-1	704A47-730-008	OH	1 INDICATOR, PITCH
6490-60220-012		SV	1 FIRE WARN TEST
64975-020-1	704A47-612-070	OH	1 INDICATOR, NR
6500-037		SV	4 DISPLAY
65008-D02		NE	2 CONNECTOR RAIL
65008-D04		NE	3 CONNECTOR RAIL
65009-004-513		NS	1 CONN KIT
6501-1051	105-90845	NE	2 RPM INDICATOR
6501-1056		OH	1 TACHOMETER
6502-3030	206-070-265-7	OH	1 INDICATOR, DUAL TACHOMETER
6503A-1058	704A-47-612-042	SV	1 TACHOMETER
65053-208		NS	5 CONN KIT
6505A-3061	117-902011-1	OH	1 TRIPLE TACH-
6505A-3068		SV	1 TRIPLE TACHOMETER
65-0648-1	209-075-325-011	SV	1 INDICATOR, RPM
65-0911-5		SV	1 LIGHT ANNUCIATOR PANEL
65-0911-7		SV	1 LIGHT ANNUCIATOR PANEL
65-10051		NS	1 LIGHT
65-1005-1		SV	1 AOA INDEXER
653-1-50		SV	1 AAU SPC
65550-04023-103	30-326E-7	SV	1 AMP, SMOKE DETECTOR
660-0001-001		SV	1 MONITOR
6600156-032	19710/2R6205B	NS	4 RUDDER TRIM ROTARY ACTUATOR
6600156-032	2R6205B	NS	1 RUDDER TRIM ROTARY ACTUATOR
6601-1004		SV	1 RATE OF CLIMB IND
6601-1004		SV	1 VERCITAL SPEED INDICATOR
6607-1-90A		NE	6 OIL PRESSURE WARNING SWITCH
66084416-7		SV	1 WARNING LIGHT CONTROL UNIT
6620-01-594-9063	9813-25-21	OH	2 DUAL TORQUE IND
66503ASSY213778		SV	1 ENGINE SYNC
66969-04		SV	1 TCAS
6700-1225-900		NE	1 REGULATOR VACUUM LIFEPORT
6700-1225-900		NE	1 REGULATOR VACUUM LIFEPORT
673529-02		NE	1 INU PLENUM
674-0004-000		NE	1 TRANSFORMER, PWR
680-6D		NE	4 FITTING HOSE 90 DEG
682-112-45-000		SV	1 NAV CONTROL
6895173-B		SV	1 FILTER
6895D1-6-5-5		SV	1 IMPACT SWITCH
6900020-000		SV	1 POWER SUPPLY
6900053-001		OH	1 POWER SUPPLY

6CL6		NS	10 TUBE
6M-40U		SV	4 DISPLAY
700-00159-001		SV	1 SATELLITE RADIO RECEIVER
7000299-901	PC702	OH	1 HELIPILOT CONTROLLER
7000299-903	PC702	OH	1 HELIPILOT CONTROLLER
7000299-907	PC702	OH	1 HELIPILOT CONTROLLER
7000300-901	AS-702	OH	1 AIRSPEED SENSOR
7000466-914	AD650H	OH	3 ADI
7000466-915	AD650H	OH	2 ADI
7000466-925	AD650H	OH	1 ADI
7000466-935	AD650H	OH	1 ADI
7000469-902	RD650A	AR	1 H-S-I-
7000469-903	RD650B	OH	1 H-S-I-
7000469-909	RD650A	OH	1 HORIZON SITUATION IND
7000605-902	MS702	OH	2 MODE SELECTOR
7000789-901	ZC301	AR	4 FLT COMP
7000836-911	AD500C	OH	1 ADI
7000836-912	AD500C	OH	1 ADI
7000836-922	AD500C	OH	1 ADI
7000839-901	RA315	OH	2 RADIO ALTIMETER INDICATOR
7000850-571	GH222	OH	2 INDICATOR, ATT DIRECTOR
7000850-771		OH	1 INDICATOR, ATT DIRECTOR
70-009H000A265A		NS	1 HOSE ASSY
7001179-966	RD550	SV	1 H.S.I.
7001182-902	AD-550A	OH	1 ATTITUDE DIRECTION IND
7001182-904	AD-550B	OH	1 ATTITUDE DIRECTION IND
7001237-6		SV	1 ANNUNCIATOR PANEL
7001305-901	AN700	OH	1 ACTUATOR POSITION IND
7001410-901	SM410	OH	2 ROD END, ACUATOR ASSY
7001410-902	SM410	OH	2 ROD END, ACUATOR ASSY
7001410-903	SM410	OH	2 ROD END, ACUATOR ASSY
7001410-904	SM410	OH	2 ROD END, ACUATOR ASSY
70-0158-1	76550-01008-101	SV	1 DIMMER CONTROL
70-0158-5		SV	1 DIMMER CONTROL
700-1710-001		SV	1 CONFIG MODULE
7001840-901		SV	1 RT-300 RAD ALT R/T
7002-060		SV	6 7IN LCD MONITOR
7002-061		SV	6 7IN LCD MONITOR
7002353-901	AZ649	OH	1 AIR DATA SENSOR
7002353-902	AZ649	OH	2 AIR DATA SENSOR
7002353-913	AZ649	OH	8 AIR DATA SENSOR
7002353-913	AZ649	NE	5 AIR DATA SENSOR
7002412-902		SV	2 AL-200 AIR DATA PRESELECT CONT
7002412-904	AL300	SV	2 ALTITUDE PRESELECT CONTROLLE

7002800-801	SM725	OH	2 ACTUATOR
7002800-804	SM725	OH	2 ACTUATOR
7002800-901	SM725	OH	2 ACTUATOR
7002800-912	SM725	OH	2 ACTUATOR
7002800-914	SM725	OH	2 ACTUATOR
7002860-903	SI-225A	OH	1 MACH AIRSPEED INDICATOR
7002860-908	SI-285	OH	1 AIRSPEED IND
7003180-901		SV	1 SZ-400 STABILITY AUG COMPUTER
7003183-904		SV	2 FLIGHT COMPUTER
7003183-932	FZ-700	SV	1 FLIGHT COMPUTER
7004110-901	SM510	OH	2 CONTROL ROD ASSEMBLY
7004123-313	SC800	SV	1 SENSOR SOURCE CONTROL
7004206-901	SP-717	SV	2 CSAS COMPUTER
7004402-977	NZ920	AR	2 NAVIGATION COMPUTER
7004402-978	NZ920	AR	1 NAVIGATION COMPUTER
7004402-997	NZ920	AR	1 NAVIGATION COMPUTER
7004577-902	VN801	SV	1 VNAV CTL
7005383-911	TM410	OH	1 TRIM SERVO
700700-047		SV	1 COMPUTER
7007062-932	MC800	SV	1 MODE CONTROLLER
7007062-941	MC-800	SV	1 MFD CONTROLLER
7007689-905	IU-410	SV	1 RADAR - PARALLEL EFIS INTERFACE
7007700-201		FN	2 Radar Indicator
7007700-803		AR	1 Weather Radar Indicator
7007990-902	PC880	SV	1 TURN PITCH CONTROL
7008138-903		SV	3 DIGITAL FLIGHT CONTROL COMPUT
7008470-822		AR	1 WU-650 RADAR R.T.A.
7008470-914		US	1 WU-650 RADAR R.T.A.
7008470-924		OH	1 WU-450 RADAR R.T.A.
7008471-7418		FN	1 Wx Controller for RDR-7000
7008471-7710		FN	1 WC-7000 RADAR CONTROLLER
7008471-7712		FN	1 WC-7000 RADAR CONTROLLER
7009289-804	MG820	SV	1 SYMBOL GENERATOR
700-D36115A-004		SV	1 MARKER CONTROL HEAD
700-D36407A-006		SV	1 COMM CTL
700-D36409A-004		SV	1 NAV CONTROL HEAD
700-D36409A-005		SV	1 NAV CONTROL HEAD
700-D36411A-004		SV	1 ADF CONTROL HEAD
700-D36411A-005		SV	1 ADF CONTROL HEAD
700-D36415A-003		SV	1 MKR PANEL
700-D36415A-004		SV	1 MKR PANEL
700Y17-1835B7		NS	1 FREQ SELECT
7011672-606	SG-605	SV	1 SYMBOL GENERATOR
7011673-661		SV	1 MFD SYMBOL GENERATOR

7011673-667	MG-605	SV	1 MFD SYMBOL GENERATOR EFIS
7012100-821	RM850	SV	1 RADIO MANAGEMENT UNIT
7012100-825		AR	4 RM-850 RMU, CRT, 8.33 kHz, TCAS
7012409-901	SM512	OH	1 PITCH ACTUATOR ASSY
7012640-901	WU870	SV	2 RADAR R.T.A.
7012640-901		AR	1 WU-870 Radar Antenna
7012693-901		SV	3 SERVO MONITOR
7012977-707		AR	1 DISPLAY CONTROL
7012977-772		AR	1 DISPLAY CONTROL
7013348-921	DA800	AR	1 DATA ACQUISITION UNIT
7013512-912		SV	1 CONTROLLER, BEACON
7014700-601		AR	2 AZ-850 MICRO AIR DATA COMPUTE
7014803-901		SV	1 RACK
7014940-801		SV	1 INSTALLATION MODULE
7016600-901	DL-900	SV	2 DATA LOADER
7016600-902	DL-900	SV	3 DATA LOADER
7016954-907	RI-553	SV	1 INSTRUMENT REMOTE CONTR
7016986-723	DC-550	SV	1 DISPLAY CONTROL
7018352-6		NS	1 CONNECTOR
70219-01041-044		SV	1 ABSORBER
70-2420-8TAS600	9900BX	SV	1 TRAFFIC ADVISORY SYSTEM
70250-01004-101	9059-1	SV	4 PARKING BRAKE VALVE
70251N02D04		SV	1 ALTIMETER
7025-21-258-0587		SV	2 DATA ACQUISTION UNIT
7025891-901		SV	1 PROTECTIVE DEVICE
70265N02D01		OH	1 BAROMETRIC ALTIMETER (BLACK)
7028432-1902		FN	2 Actuator I/O Proc (AIOP) Modu
7029782-1912		FN	2 MAU-12L Modular Avionics Unit 12 s
7030-C27	7030	SV	1 VSI
7030-C29	7030	SV	1 VSI
7036333-1906		FN	2 CIO-AP2 Dual Chan Generic CIO Mc
7036410-1904		NE	2 MAU ADVANCED GRAPHICS
7036410-1904		FN	4 MAU advanced grap. Module
7038231-1801		FN	4 NIC-210 Network Interface Card (NI
7038248-1901		FN	4 PWR-200 Power Supply Module
703A53-0000-04		SV	1 OIL TANK
704A31-211-020		NS	10 FLEXIBLE MONTING
704A34410035		NS	1 PIPE
704A35333053	5985-14-534-7649	NE	1 MOBILE ANTENNA
704A37641095		SV	1 HYD PRESSURE EMERG IND
704A37643002		SV	1 FUEL PRESSURE TRANSMITTER
704A44820006		OH	1 RELAY, BREAKING CURCUIT
704A45751263	7900100-10M10.0W10.0	SV	1 VIDEO RADAR UNIT
704A45751263	7900100-10M10.0W10.0	NE	1 VIDEO RADAR UNIT

704A46580088		SV	1 DERATING BOX
704A47310017		OH	1 SYSTEM UNIT, AIR DATA
704A47-315-011		NE	1 CONTROL UNIT, EGPWS
704A47621089		OH	1 INDICATOR, TORQUEMETER
7050A4252012		SV	1 PILOT SEAT
7050A4316017		SV	1 VEMD
705906-801	RT1168/ARC164V	OH	1 TRANSCEIVER
705906-802	RT1168/ARC164V	OH	1 TRANSCEIVER
705906-803	RT1168/ARC164V	OH	1 TRANSCEIVER
705906-804	RT1168/ARC164V	OH	1 TRANSCEIVER
706077-801	RT-1167/ARC-164V	SV	2 RECEIVER TRANSMITTER
706077-802	RT-1167/ARC-164V	SV	2 RECEIVER TRANSMITTER
706077-803	RT-1167/ARC-164V	SV	2 RECEIVER TRANSMITTER
706077-804	RT-1167/ARC-164V	SV	2 RECEIVER TRANSMITTER
706077-805	RT-1167/ARC-164V	SV	2 RECEIVER TRANSMITTER
706177-801	ARC-164	SV	6 TXR MOUNT
7064-4656	MS24178-D1	SV	2 LEACH RELAY 55 AMP
706567-801	C-10116	OH	2 CONTROL BOX, ELECTRICAL
706-786-3	704A47652008	SV	1 AMPLIFIER FUEL GAUGE
706A31213063		SV	1 ECLAIRAGE PANNEAU PLAFOND
706A37-721-001		SV	4 TRANSDUCER, GLYCOL PRESS
707074-801	RT1168B/ARC164V	SV	4 TRANSCEIVER
707074-802	RT1168B/ARC164V	SV	4 TRANSCEIVER
707074-804	RT1168B/ARC164V	SV	4 TRANSCEIVER
707074-805	RT1168B/ARC164V	SV	2 TRANSCEIVER
707648-801	RT1505/ARC164V	SV	1 TRANSCEIVER
707648-802	RT1505/ARC164V	SV	1 TRANSCEIVER
707648-803	RT1505/ARC164V	SV	1 TRANSCEIVER
707648-804	RT1505/ARC164V	SV	1 TRANSCEIVER
709-0104-01-101		SV	1 BLADE ASSY MAIN ROTOR
709-0160-48-101		AR	1 TR BLADE ASSY
709-0160-55-101A1		NE	4 BUSHING OVERSIZE
70-907		NS	3 CONTACTOR
709149-801	5821-00-078-1342	SV	1 RCVR TRANS RADIO
709149-802	RT823ARC131	SV	2 RCVR TRANS RADIO
70EM016100		OH	1 MODULE REDUCTION GEAR ARRIUS
70HF10		NS	8 DIODE / RECTIFIER
710696-100		SV	4 CABLE
71-2480		SV	1 TAS SYSTEM W/O DISPLAY
714042-9005		SV	3 PRINTER
7160C130		OH	2 VSI
716-686		SV	1 FUEL QTY IND
716-760-3		OH	1 INDICATOR PANEL, FUEL KG
716-760-4	704A47-653-057	OH	1 INDICATOR PANEL, FUEL

716-879	704A47-650-078	SV	1 INDICATOR, FUEL QUANTITY
7185-15	206-062-721-15	SV	1 LINEAR ACTUATOR
7200-0500-001		AR	1 ENGINE MONITOR
720-7719		SV	1 WHEEL
7217-28-01		SV	1 NR PANEL
7220-3	204-070-483-003	NE	1 AIR OUTLET
7236-1-150		NS	1 SENSOR CONTROL
724855-801	C-2000	SV	1 MAGNASTAR ARTU
724855-802	C-2000	AR	3 MAGNASTAR ARTU
724855-803	C-2000	SV	1 MAGNASTAR ARTU
724866-805WH	724866-805	SV	1 HANDSET
724866-807WH	724866-807	SV	1 HANDSET
724866-808PD	724866-808	SV	1 HANDSET
724868-802	724868	SV	1 MOUNTING TRAY
724986-801		SV	5 AIU
724986-802		NE	1 AIU
725058-801		SV	1 COCKPIT PHONE
725729-802WH	725729-802	SV	2 CONFERENCE TABLE HANDSET
725729-807BK		SV	1 HANDSET
725729-807BK	725729-807	SV	2 HANDSET WITH RETRACT CORD
725729-807WH	725729-807	SV	5 HANDSET WITH RETRACT CORD
725729-815BK	725788-802BK	SV	1 HANDSET WITH RETRACT CORD
725729-815WH		SV	3 HANDSET WITH RETRACT CORD
7260151-415		NS	5 SEAT BELT
7-26-4W		SV	1 INDICATOR
729-1201-001		NE	1 INSTL PILOT ISO BARRIER II
730152760A		SV	1 EXHAUST PIPE, EXTENDED
730152760A		SV	1 EXHAUST PIPE, EXTENDED
730152760C		SV	1 EXHAUST PIPE, EXTENDED
7315-0050-1		SV	1 ADAPTER
732-8101		SV	1 CONTROL STICK TRIGGER ASSY
73415-1460		NS	1 CONNECTOR KIT
736-3652	CU-3001-A	NS	1 MINIBOX
739CX-4-023		SV	1 AIRSPEED
741C0000-03		SV	1 ACTUATOR TAIL ROTOR
743425-801	1LZU1-743425-801	NE	1 CONNECTOR KIT
744-082-3	704A47-671-031	SV	1 INDICATOR, FLOWMETER
749852-1-1		SV	3 CONTROL PANEL
75-0341-27		SV	1 LIGHT ASSY ANNUNCIATOR
75-0341-7		SV	1 LIGHT ASSY ANNUNCIATOR
7510100-711	RNZ850	SV	1 INTEGRATED NAV UNIT
7510100-713	RNZ-850B	SV	2 UNIT, INTEGRATED NAVIGATION
7510100-733	RNZ-850	SV	1 UNIT, INTEGRATED NAVIGATION
7510124-920	MT-851	AR	1 MOUNT ASSY

7510700-765	RCZ-833K	SV	2 COM UNIT, 25/8.33 KHZ, DIVERSITY
7510700-766	RCZ-833E	SV	3 INTEGRATED COMM UNIT
7510700-901	RCZ850	SV	2 INTEGRATED COMM UNIT
7510700-951	RCZ852	SV	4 MODE S DIVERSITY XPDR
7511001-915	AV850A	SV	3 AUDIO CONTROL PANEL
751-2417-001		NS	2 CABLE
751-2417-002		NS	1 CABLE
7513006-911	DI851	SV	2 DME IND
7517455-902		SV	1 MOUNTING TRAY
7517943-22		NS	200 CONTACT
7517943-9		NS	1 CONNECTOR
7519248-911		NS	4 CABLE ASSY
7519248-913		NS	4 CABLE ASSY
7519349-3		NE	1 SPLITTER, RF
75-258V2M1		SV	1 COMPUTER
75-270M2	75-270	SV	1 SFENA COMPUTER
754-0073-005	5826-01-065-9996	NE	1 PANEL LIGHTING
756-0115-300-101	MT-3317-101	NE	3 DFDAU TRAY ASSY (G200)
756-122		OH	1 ENGINE STARTER
76088-61043-050		SV	2 PILOT BEARING & HS I SWITCH
76088-61043-051		SV	2 CO-PILOT BEARING & HS I SWITCH
76089-60276-041		SV	1 FUSE BOX
761110-4	76900-01807-104	SV	1 AFCS AMPLIFIER ASSY
761111-3		SV	2 SLICE AMP
761112-3		SV	2 SLICE AMP
761240-1		SV	1 AFCS CONTROL PANEL
761272-3	76900-01804-103	OH	4 AFCS INDICATOR
761-6205-001	5930-00-911-1794	NE	1 SWITCH
761-7226-001		NS	2 SWITCH
7-627TG		SV	1 INDICATOR FEED UNIT
76378-200	KIT- 76378-200	SV	2 WINCH AGGREGATE
76378-300		AR	2 WINCH
76403-01104-041		SV	1 ADJUSTER ASSY, PEDAL
76450-00907-102		OH	1 INDICATOR
76450-01015-046		SV	1 PANEL ASSY
76450-01041-041		SV	1 HEATER CONTROL
76450-01072-109		OH	1 TORQUE IND-
76450-01076-102		OH	1 T-5 IND-
76550-01001-103		SV	1 MASTER CAUTION PANEL
76550-01001-104	843766	SV	1 MASTER CAUTION PANEL
76550-02001-063		SV	1 COCKPIT FLOODLIGHT
76550-02014-042		SV	1 PANEL
76550-09005-102	PC00401C	SV	1 TRANSFORMER
76550-09005-104		SV	1 GENERATOR CONTROL UNIT

76600-02014-046		SV	1 RELAY
76600-04162-045		NE	1 HOLD DOWN/HF ANTENNA
76650-01802-102		OH	1 VTA ACTUATOR
76650-02802-103		OH	1 CONTROL VALV
7-676-10		NS	4 HOMING ADAPTOR
768-10		SV	1 NARDA ATTENUATOR
768-128		SV	1 TRANSMITTER, FUEL GAUGER
768-129		SV	1 TRANSMITTER, FUEL GAUGER
768-20		SV	2 NARDA ATTENUATOR
76900-01803-101		OH	1 CONTROL PANEL
76900-01805-102		SV	1 SWITCH
76900-01810-103	76900-01810-103B	SV	1 PEDAL DAMPER
76900-01851-042		SV	2 VTA AMP
771523-2		SV	1 AMP SLICE
772-0738-001	680T1	SV	1 HF SLICE
772-5132-001		SV	1 MODE COUPLER
777-1029-002	714E3D	OH	1 CONTROL
777-1034-001	345A7A	SV	1 SENSOR, RATE OF TURN
777-1061-001	334C6	OH	1 PRIMARY SERVO
777-1061-001	334C6	AR	1 PRIMARY SERVO
777-1062-001	251B6	OH	1 MOUNTING SERVO
777-1062-001	251B6	AR	1 MOUNTING SERVO
7801-13000		SV	1 FUEL FLOW TRANSMITTER
780926-1	76900-01826-101	SV	1 AMPLIFIER
78200000-07	HAI-222-070-105	OH	1 INDICATOR
78200000-08	222-375-021-113	OH	1 TRIPLE TACH INDICATOR
78300000-03		OH	1 INDICATOR
78300000-09	222-375-071-107	OH	2 INDICATOR, TRIPLE TORQUEMETER
78340MK4C		SV	5 SARBE BEACON MK4C
785340-5-024	3117090-05	SV	1 CTRL UNIT ENGINE ELECTRONIC
787-6173-217	ADI-84	OH	1 FLIGHT DIRECTOR INDICATOR
787-6366-006		SV	2 CONTROL BOX, ADF
78-8051-9160-4	WX1000	AR	1 PROCESSOR
78-8051-9170-3	WX-1000	SV	1 STORMSCOPE DISPLAY
78-8051-9200-8	WX1000	SV	1 ANTENNA
78-8060-5900-9		AR	1 DISPLAY
7892740-051		AR	1 CAROSEL SIX CTL UNIT
78CF9919		OH	1 FLEXBALL CONTROL
79000660-1		SV	1 KPA900 KIT
7900100-10	7900100-10M10.0W10.0	SV	1 VIDEO RADAR UNIT
7900100-10	7900100-10M10.0W10.0	NE	1 VIDEO RADAR UNIT
792-6091-009	331A9G	OH	1 H.S.I. INDICATOR
792-6091-011	331A9G	OH	1 H.S.I. INDICATOR
792-6091-019	331A9G	OH	1 H.S.I. INDICATOR

792-6216-001	51Y7A	OH	1 ADF RCVR
792-6275-001	614L13	SV	1 ADF CONTROL
792-6275-002	614L13	SV	1 ADF CONTROL
792-6672-002		OH	1 ADC
792-6784-001	351B6A	OH	1 MOUNTING SERVO
792-6784-001	351B6A	AR	4 MOUNTING SERVO
794-165		SV	1 PROBE, FUEL GUAGE
794-166		SV	1 PROBE, FUEL GAUGE
7G304		SV	1 SWITCH
800006-1A		NE	1 RACK
800-010655-1		SV	1 PANEL
80-0093-1		SV	1 MASTER WARN PANEL
80-0093-5		SV	1 MASTER WARNING PANEL
800496-E	800496	SV	1 BATT TEMP
80-0500-33	222-375-010-149	SV	1 ANNUNCIATOR PANEL
80-0533-3		NE	1 PANEL ANNUNCIATOR
800-G-5392L	G5392L	SV	1 DUAL COMM CONTROL
800-G-5868C	G5868C	SV	1 DUAL COMM CONTROL
800J8J4AH19		SV	1 METER
80-1-026/H402A		SV	1 SWITCH PANEL
801-40011		SV	1 ENG-RPM-SENSOR
802-10-0006	HLD-7260	SV	1 SWIFT BROAD BAND DUPLEXER
802-10-0016	SDU-7310	SV	1 SWIFT BROAD BAND SDU
80265-00-0311	TNL-3100	SV	1 GPS
80265-01-0210	TNL2100	SV	1 GPS
80265-01-0234		SV	2 GPS SENSOR
802GC01		NS	1 CIRCUIT BOARD
8032-1	704A44831118	SV	1 SERVOCONTROL,MAIN ROTOR
8033-3000	ACU-810	SV	1 AMPLIFIER COUPLER
804-001		SV	3 KING AIR SWITCH PANEL
804-10-0011	5895-01-538-5542	SV	4 DIPLEXER/LNA DAU-7050
8047-20		OH	1 STANDBY ALTIMETER
805-001		SV	2 KING AIR SWITCH PANEL
80-500-1		SV	1 ANNUNCIATOR PANEL
805-10024-001		SV	1 MOUNTING TRAY
80654B5W		SV	1 HOVERMETER
80790A01		SV	1 RECEIVER DECCA MK 3
80792A03S303		SV	1 NAVIGATION COMPUTER UNIT
80792J40T090050		SV	1 COMPUTER RNAV2 S76A+
80794ES003		SV	1 CONTROL DISPLAY UNIT
80794NS301	80794	SV	1 CDU
80822-00-0235		SV	1 GPS
80822-10-0224		SV	1 GPS
8095361-2404	CC2024F	SV	1 CONTROL

8095444-4103		SV	1 NAV CONTROL CD413B
809908-3-2		SV	2 TRANSDUCER CABIN PRESSURE
8114-110-00-00	704A47-643-014	OH	1 TRANSMITTER FUEL PRESSURE
81170753-4		NS	2 CARTRIDGE
811B		SV	3 CLOCK
811B-1		OH	1 CLOCK
8125-20		SV	1 VALVE
8136-AB-08	901F	SV	1 INDICATOR TACHYMETRIQUE
8136-BA	901F	SV	1 INDICATOR TACHYMETRIQUE
81438-00-0237	TNL2101	SV	2 GPS
81438-02-240D	TNL2101	SV	2 GPS
81439-00-0237	TNL2101	SV	2 GPS
81439-02-240B	TNL2101	SV	2 GPS
81439-02-240M	TNL2101	SV	2 GPS
81439-02-240P	TNL2101	SV	2 GPS
81439-32-240M	TNL2101	SV	1 GPS
81439-32-240N	TNL2101	SV	1 GPS
81439-32-240P	TNL2101	SV	1 GPS
81439-32-241P	TNL2101	SV	1 GPS
81440-00-0229		SV	3 GPS
81440-00-0233	TNL2101	SV	1 GPS
81440-00-0233		SV	2 GPS RECEIVER
81440-00-0238	TNL2101	SV	1 GPS
81440-00-0243M	TNL2101	SV	1 GPS
81440-00-0243N	TNL2101	SV	1 GPS
81440-00-0243P	TNL2101	SV	1 GPS
81440-02-0241J	TNL2101	SV	1 GPS
81440-02-0241M	TNL2101	SV	1 GPS
81440-02-0241N	TNL2101	SV	1 GPS
81440-02-0241P	TNL2101	SV	1 GPS
81440-02-0241Q	TNL2101	SV	1 GPS
81440-12-0241E		SV	1 GPS
81440-12-0241M		SV	1 RECEIVER GPS
81440-42-241M		SV	1 RECEIVER, GPS 2101I/O APP+, NV
81440-42-241N		SV	1 RECEIVER, GPS 2101I/O APP+, NV
81440-42-241P		SV	1 RECEIVER, GPS 2101I/O
81440-42-241Q		SV	1 RECEIVER, GPS 2101I/O
81448-21		NE	1 2101 I/O INSTALL KIT
81567A04A102020		SV	1 SATELLITE DATA UNIT
817-10009-001		NE	1 KIT INSTALL L-BAND ANT 40IN
81821/20		SV	1 DIPLEXER/LNA
81821/AA	81821/ACA	SV	2 TWO AXIS STAB PLATFORM
81821/F01A001	81821CGA001	SV	1 TASP/ACU ASSY
81821B01A001004	81821B01A001	SV	1 SATCOM ANTENNA ASSY

81821G01A001004	81821G01A001	SV	2 SATCOM ANTENNA ASSY
81B		SV	1 COAXIAL RESISTOR
81F09GX10-30		NE	1 FILTER
81N2581		NS	10 SOCKET, BAYONET
8210-002-01		SV	1 PROP GOVERNOR
8210-007-01		AR	1 PROP GOVERNOR
822-1109-011	ADC3000	SV	3 AIR DATA COMPUTER
822-1-17		SV	2 COMM CONTROL
822-1349-001	SRT-2000	SV	1 SATELLITE DATA UNIT
822-1484-201		SV	2 OCM-3100 OPTIONS CONTROL MO
822-1484-241		SV	2 OCM 3100
822-2175-001		FN	7 CTL-22D
822-2177-003	CTL23D	SV	1 CONTROL UNIT VHF COM
822-2182-107	CTL93T	SV	1 TCAS CONTROL
822-2215-302	DBU-5000	SV	1 DATA BASE UNIT AFIS
822-2576-050		NS	1 DIU-3110 Display Interface Unit
822-2576-051		FN	1 DIU-3110 Display Interface Unit
822-2576-051		SV	1 DIU-3110 Display Interface Unit
822835-5-105		SV	1 ELECTRONIC ENGINE CONTROL
822835-5-106		SV	1 ELECTRONIC ENGINE CONTROL
822835-5-107		SV	1 ELECTRONIC ENGINE CONTROL
8230B528	8230	OH	1 MAX ALLOWABLE AIRSPEED IND
82821CGA001	82821CGA	SV	1 TASP/ACU ASSY
8330450100-1		NS	1 VACUUM OUTLET
834610-00-002		SV	1 TUBE, PITOT ELEC HEATED
8350-0262-03	AHRS500GA	SV	1 AHRS
8383AU		OH	1 INDICATOR PYROMETRIQUE
84303-210DEB		NS	1 PLUG
84327-50-XXXX		FN	2 1203C GPS/SBAS RECEIVER
8-436-10		OH	1 TACH INDICATOR
843-67-6	109-0729-33-1	OH	2 INDICATOR, VERTICAL SPEED
843-67-6-R	446000275	OH	1 INDICATOR, VERTICAL SPEED
8436-BA	901F	SV	1 INDICATOR TACHYMETRIQUE
843772-149	76550-01001-149	SV	2 MASTER CAUTION/ADVISORY PANE
8444-19477-30201		SV	1 RACK ASSY RNAV 2 MODIFIED
8502-600-1	1159SCAV408-1	SV	1 0-400 KTS MACH AIRSPEED
8502C-S20LW		OH	1 AIRSPEED INDICATOR
8503S20LW-MB5V-ES		OH	1 BAROMETRIC ALTIMETER
85097-02	85097	NE	1 HOBBS HOUR METER
85-41320-1340		NS	3 PRINTED CIRCUIT BOARD ASSY
8590A	HP8590A	SV	1 SPECTRUM ANALYZER
8595-03	704A47152004	OH	1 VERTICAL GYRO
85A30-C24-AA0495	74-00040-002	NS	1 RESISTOR
85AP-105		NE	1 8500C+APPLIC KIT B0105

85AP-135		NE	1	8500C+APPLIC KIT EC135
85AP-135DS		NE	3	8500C+APPLIC KIT EC135DS
85B-ECD		NE	1	8500C(+)T&B KIT, BASIC, ECD
85B-FA		NE	1	FASTRACK ASSY BASIC
85B-FA		NE	1	FASTRACK ASSY, BASIC
85B-SA		NE	1	STROBEX ASSY, BASIC
8-6137-1A		NS	4	CAM
875A0000-02		SV	4	TAIL ROTOR SERVO ACTUATOR
875A0000-02		NE	4	TAIL ROTOR SERVO ACTUATOR
87F2959		NS	100	PLUG
8800-T		SV	1	ALTITUDE SENSOR
885-2142		NS	1	TEST JACK
890114-940	3AA78/63-211397-001	AR	2	LASERCAM BRACKET
89095-0031		SV	2	COCKPIT VOICE RECORDER
8948710G001	8948710G1	SV	1	COIL
894TS05NY		SV	1	SWITCH LANDING GEAR
8A584-001	206-040-555-001	NE	1	THERMOSTAT
8DJ120WAA1	206-070-265-7	OH	1	INDICATOR, TACHOMETER
8DJ278WAD1		OH	1	INDICATOR, ROTOR SPEED
8DJ81LZE4		SV	1	TACH IND
8DJ81LZF4		SV	2	TACH IND
8DJ81WB84		SV	1	INDICATOR
8ES003417-00	704A46830026	SV	1	POWER SUPPLY UNIT, STROBE
8TW003-491-00		NE	10	PUMP
900-000-05		NE	14	RING ALUMINUM
90004-00311111009	90004	SV	1	AIR DATA COMPUTER
90004-00311131000	90004	SV	1	AIR DATA COMPUTER
90004-00321111000	90004	SV	1	AIR DATA COMPUTER
90004-00321111009		SV	1	AIR DATA COMPUTER
90004-00321111009		FN	5	Air Data Computer
90004-00321111051	90004	SV	1	AIR DATA COMPUTER
90004-00342111038		SV	1	AIR DATA COMPUTER
90004-00343111061	90004	SV	1	AIR DATA COMPUTER
90004-00348111011		SV	1	AIR DATA COMPUTER
900101-806	RT-1505A/ARC164V	SV	1	UHF AIRBORNE RADIO
900101-807	RT-1505A/ARC164V	SV	1	UHF AIRBORNE RADIO
900-4345		NE	1	BRACKET, RELOC STROBE POWER
900-700-036-72		OH	1	OXYGEN REGULATOR
9007000-57001		SV	1	MST-70B ADS-B Out Xpdr
900-8171-001		NE	4	HEAD CROSS BRACE
900-8348		NE	4	BULKHEAD PLATE
9009-3004	206-075-188-001	OH	1	OIL TEMP PRESS IND
900D51508	D51508	SV	1	RECORDER, CVFDR
900E2752137-101		SV	1	PANEL

901002-11	706-11	OH	1	GYRO DISPLACEMENT
9011-100-2013	16020-3001	NE	12	RF FILTER
901-12631		SV	1	UNIT, 139 VXP,POWER SUPPLY
90153-5	222-375-025-111	OH	2	INDICATOR, DUAL AMMETER
9020-3026		SV	1	PRESSURE SWITCH
9020-3042	222-375-025-111	OH	2	DUAL AMMETER IND
902205-804		NE	1	MAGNASTAR ISDN TERM ADPT
90245A012		NS	1	THREAD REPAIR KIT
9030-1017		NE	1	PREESURE INDICATOR
9030-1017		SV	1	PRESSURE INDICATOR
9030-3046	260-2351-1	OH	1	IND-, DUAL FUEL PRESSURE
9036-3010	109-0729-27-1	SV	1	OIL/TEMP PRESSURE IND
90-380037-1		SV	1	INDICATOR CONDITIONER UNIT
903BDV5		OH	3	ARTIFICAL HORIZON
906-16789		SV	1	ACCELEROMETER,ICP W/ D38999
90F8554		NS	2	SENSOR
90G196-2		SV	1	PRESSURE SWITCH
910020-238	AIRSHOW	SV	1	AIRSHOW DIU
911010-1		NE	1	TTD CONTROLLER
911010-1		SV	1	TTD CONTROLLER
911010-2		NE	1	AIRSHOW TTD CONTROLLER
911010-2		AR	2	AIRSHOW TTD CONTROLLER
9120-1000-21		SV	1	UNIT
913210-3-1-2-2-X-2	913200AR-3-1-2-2-X-2	SV	1	ENGINE TREND MONITOR
9-138-15		SV	1	FUEL SV IND
914095-100		SV	1	AERA DISTRUBUTION BOX
917-1208-000		NE	7	CAPACITOR, VARIABLE
919C70200		NE	3	RF SWITCH
9200-18000-02		FN	1	Camera IRIS "180" degree
9203CF		SV	4	ANTENNA, DECCA
92070-55017-041		SV	1	PANEL ASSEMBLY, NO-3 RELAY
92070-55017-042		SV	4	PANEL ASSEMBLY, NO-4 RELAY
92070-55039-011		SV	1	MOD KIT, WIRING PUMP SENSOR
92101-11003-102		SV	1	BARREL ASSEMBLY, TR PITCH ROD
9222-0130-002		SV	1	ROSEN AVIATION
92382LR008-02		NE	6	OUTER SLEEVE
923V11		SV	1	HORIZON GYRO
92410-04830-106		AR	1	TRIM SERVO ROLL
92410-04830-106	DR3840M23-2	SV	1	TRIM SERVO ROLL
92550-01817-101	0230636-006	NE	1	SEARCHLIGHT
92550-02813-104		SV	1	CONTROLLER, RIPS
92602-21400-049	21400-049	NE	4	RAD ALT XMT
926125-10-1	214000-049	NE	4	RAD ALT HARNESS
9290K98		SV	5	SPRING

930121-7		NS	1	CABLE ASSY
930-500-25-1		SV	1	SEARCH LIGHT
930-500-50-1		SV	3	DUAL SEARCH LIGHT
932810-01		NE	1	BARO CONVERTER
933612-02		SV	1	SERIAL CONVERTER
933810-01	6220-01-232-7723	SV	2	IRS/FMS ADAPTER
93921-1	13636-93921-1	NE	1	MOUNTING TRAY
93-A055-95		SV	1	AREA MIC
93-A151-20	A151B	SV	1	CVR CONTROL
93-A151-30		OH	1	CVR CONTROL UNIT
93-A152-70		SV	1	CVR CONTROL
941063-1	TAC200	SV	1	DUAL AUDIO CONTROLLER
94290701-01	HAI-222-070-145	SV	1	INDICATOR, TOT
94290703-01	HAI-222-070-135	SV	1	INDICATOR, TACH
943210/943200-3	943200-3	SV	1	KEY AND DISPLAY PANEL
9506-0-0		NE	2	CREW SEAT 230/260
9507-0-0		NE	3	PASSENGER SEAT
9507-0-0-3X21310		OH	1	PASSENGER SEAT LH
9507-0-0-XXXX3XX		NE	1	PASSENGER SEAT
95-210	MODEL95-210	AR	1	NAT PANEL
95-220-1G		NS	1	BLOWER
95-40-17-D6-56911		NS	1	INDICATOR
95-40-18-B6-64235		NS	1	SWITCH ASSY
9543705-1		OH	1	NOSE WHEEL ASSY
95-46-11-S2-70583		OH	1	SWITCH ASSY
9550BN577	9550B	OH	1	TURN AND SLIP
9599-607-12305	9599-	SV	2	RAD ALT ANTENNA
9599607-14169		SV	1	RADIO ALTIMETER INDICATOR
9599-607-14191	IND 821A	SV	1	RAD ALT INDICATOR
9599-607-4535		SV	1	RADIO ALTIMETER TRANSMITER
95-XX-17-H6-50624		NE	3	CIRCUIT BREAKER
95-XX-18-B6-64438	95-XX	NS	1	CAP ASSY
95-XX-18-B6-64439	95-XX	NS	1	CAP ASSY
95-XXX-6D1-19552		NS	2	CAP ASSY
9601-2		SV	2	SEAT BELT
9603-560-L5		NE	1	FRONT SUPPORT BAR LH
9603-560-R5		NE	1	FRONT SUPPORT BAR RH
9603-570-L5		NE	1	REAR SUPPORT BAR LH
9603-570-R5		NE	1	REAR SUPPORT BAR RH
9603A	704A46860001	SV	1	PANEL, FAILURE ADVISORY
960453-1	7515	SV	1	RESERVOIR ASSY HYDRAULIC 375C
9606-10-03-3X21910R		OH	1	PILOTSEAT HEIGHT ADJ
9609-505-RX		NE	1	REAR MEDIUM SUPPORT BAR
9609-505-RX		NE	1	REAR MEDIUM SUPPORT BAR

96-10-500-50		NS	3	FASTNER
96-10-500-50		NE	3	FASTENER
96202(B)	96202	FN	2	LAP JACKET
962820-1		SV	1	FUEL/AIR DATA COMPUTER
962820-2		SV	1	AIR DATA COMPUTER
962830A-1-S-8	ADC2000	SV	1	FUEL AIR DATA COMPUTER
962830AR-3-X		SV	1	FUEL/AIRDATA COMPUTER
962831A-3-S-8	ADC2000	SV	1	FUEL AIR DATA COMPUTER
963001-103		SV	3	ENCODER DIGITAL INTERFACE BOX
963405-100-015		NE	1	CABLE ASSY
964-0421-001	2940	OH	1	8300 AIR DATA SENSOR
965-0676-006	MKV	SV	1	GPWS COMPUTER
965-0686-001	MKVI	SV	2	MARK VI GPWS
965-0686-020	MKVI	SV	2	MARK VI GPWS
965-1198-005		AR	1	EGPWS
965-1227-005		AR	1	EGPWS
965-1595-020		SV	1	EGPWS PROCESSOR
96774-18-1842-7	96774-412-075-205-101	OH	3	PRESSURE TORQUE TRANSMITTER
96774-412-075-205-101	96774-18-1842-7	OH	2	PRESSURE TORQUE TRANSDUCER
9701-500-5		NE	2	HIGH SUPPORT FRAME ALU
97-3057-10		NS	1	CONNECTOR
97-389002		SV	1	TRANSMITTER TORQUE PRESS
97499-18-1842-7	97499-412-075-205-101	OH	1	TORQUE PRESSURE TRANSMITTER
97536-02	2330B	OH	1	INDICATOR
9768-03	NDN9768	SV	1	FLT PATH CTL COMPUTER
978F-1D		SV	1	INSTRUMENT TEST SET
979-0223-001		SV	1	BIAXIAL ACCELEROMETER, LINEAR
979142-1-1		NE	1	VALVE OUTLINE
9809-0-0		NE	2	PASSENGER SEAT
981-24C28		SV	2	NAV SWITCH RELAY
983403-1	0401907-G1	OH	1	ANTENNA
98571/843766	76550-01001-104	SV	2	MASTER CAUTION/WARNING PANEL
98571/843772	76550-01001-103	SV	1	MASTER CAUTION/ADVISORY PANEL
987-6038-001		SV	10	DATA PORT INTERFACE
990-2993-001	M7852	NE	8	AUDIO AMPLIFIER
990-3250-001	M1084PS	SV	1	AUDIO AMPLIFIER
990-3273-002	M1081PS	SV	1	AUDIO AMPLIFIER
990-3307-002	S4000-2	SV	1	PASSENGER BRIEFING SYSTEM
990-3333-069	B1045-F356-HMD3	SV	1	AUDIO CONTROL SYSTEM
990-3334-112	B1035-J290-HWZ5	SV	2	AUDIO CONTROL SYSTEM
990-3338-000		SV	1	AUDIO AMP SUMMING
990-3342-028		SV	1	PANEL, AUDIO SELECTOR
990-3392-001	M1086	SV	3	AUDIO AMP
990-3392-002	M1086H	SV	1	AUDIO AMP

990-3393-001		SV	2	M1084 AUDIO AMP
990-4063-002	LF91	NE	4	SPEAKER
990-4074-002		SV	1	AUDIO AMP
990-4099-001	VDA600	SV	1	VIDEO DISTRIBUTION AMP
990-4140-005		SV	1	DISPLAY
990-4144-001		SV	2	DISPLAY
990-4150-002	HB1500AAB	SV	1	MONITOR DISPLAY
990-4152-027		SV	2	CABIN MANAGEMENT SYSTEM
990-4300-001	AS200	SV	1	AUDIO SYSTEM
990-4500-001		SV	1	CABIN MANAGEMENT SYSTEM
990-5734-100		NE	1	XM CONTROL HEAD
990-6000-000	M4010	SV	1	DIGITAL BRIEFING SYSTEM
990-6820-001		SV	1	CABIN MANAGEMENT SYSTEM
990-9104-036		SV	1	CABIN MANAGEMENT SYSTEM
990-9104-037		SV	1	CABIN MANAGEMENT SYSTEM
990-9700-004		SV	1	CABIN LAN
990-E1900-002	1901-102H	NE	4	19IN HD MONITOR
990-G7104-004		SV	1	CABIN MANAGEMENT SYSTEM
99-230-1B1-19640	A0164	NS	1	IND- LIGHT
996-G7000-002		SV	4	C-SERIES OLED
996-G7000-224		SV	6	OLED DISPLAY
996-G7002-140		SV	1	CABIN MANAGEMENT SYSTEM
996-G7004-012		SV	1	COCKPIT SWITCH
996-G7100-004		SV	2	SWITCH PANEL
996-G7100-144		SV	1	SWITCH PANEL
996-G7101-004		SV	1	SWITCH PANEL
999-0057-27-619		NE	7	SHIM
999-0300-55-102		NE	1	ELBOW FITTING
999-1000-04-103		NE	2	SPRING HELICAL TENSION
9A2043		SV	8	HOUSING
9B-81040-15		SV	1	ANALOG INTERFACE UNIT
9B-81040-26		SV	1	ANALOG INTERFACE UNIT
9D0271-101T	CB4020V3N6-750	NS	10	RIGHT ANGLE MOUNT
A0164BC050014LT	A1077	NS	3	SCREW
A1077F	76550-00902-103	SV	1	RELAY
A119-5010-T7		NE	2	AC TUBE
A119-6014-1		NE	1	AIR BOX ASSY
A119-6018-2		NE	2	RESISTOR PLATE ASSY
A119-6020-2		NE	9	EVAPORATOR AIRCOMM
A119-8422-3		NE	1	ASSY RELAY PANEL
A121B	A1280	SV	4	ACCELEROMETER
A1280-1	A1301	NS	1	LENS
A13018-5	A15-L	SV	1	INERTIA, CVFDR
A14.3	A14.05	NS	2	SEAT BELT

A146A2209DW		NE	8 SEAL MATERIAL
A1500		NS	2 CIRCUIT BOARD
A153A2312RB		NE	10 EXTD RUBBER SILICONE
A1600		SV	1 INDICATOR, TURN & SLIP
A24081-1	2995-00-992-9399	SV	3 BLOWER, AIR INLET
A2455		SV	1 SWITCH PANEL, WINDOW SHADE
A2475		SV	1 SWITCH PANEL
A24A9430-1		SV	1 WINDOW TEMP CONTROL
A2928710001	A29287	OH	2 INDICATOR SLAVE TRUE AIRSPEED
A301-61ACVR	A301C	SV	2 ICS CONTROL
A301CM222	A3374	NE	1 GAUGE
A33747	A3392	NS	1 LINER
A33925	A-35-	AR	1 HEAT SHIELD
A41322-10-003		OH	2 ALTIMETER
A413A,HAD-CF-14/28	A413A	SV	2 POWER SUPPLY
A413A,HAD-CF-14/28	HAD-CF-14/28	SV	1 POWER SUPPLY
A414371066	A4442	SV	2 MACH AIRSPEED
A4442000002		SV	2 PITOT TUBE
A490ATSCF	01-0770062-03	SV	1 POWER SUPPLY
A490ATSCF14/28	A490A	SV	3 POWER SUPPLY
A490ATSDF14/28	01-0285055-18	SV	3 POWER SUPPLY
A596A07		NE	2 JUNCTION
A691-2		SV	1 AUDIO AMP-
A6912-1	A692-	SV	1 AMPLIFIER SUMMING, HUMS
A692-1	SGB-A692-1	SV	1 AUDIO AMP-
A-700AAP	205-075-642-1	SV	1 CUTOFF RELAY GENERATOR
A-700ZC-7	205-075-642-1	SV	1 CUTOFF RELAY GENERATOR
A-700ZG		SV	1 VOLT REGULATOR
A-703G		SV	1 VOLT REGULATOR
A-772XTA		SV	1 RELAY
A81-59	5831-00-539-1471	SV	1 CONTROL PANEL
A825F	AA20-	SV	1 GENERATOR CONTRL
A864A1308E022F		NE	16 SHIM
AA20-IKC	AA31-	NS	2 P-A- CONTROL INSTALL KIT
AA31-002	AA32-	SV	1 AUDIO INTERFACE
AA31-006		SV	1 NAT AUDIO CONTROL
AA31-006		AR	1 NAT AUDIO CONTROL
AA32-001	AA34-	NE	1 AUDIO INTERFACE
AA34-001		SV	1 NAT MODULE
AA34-105		SV	1 NAT MODULE
AA34-200	AA82-	SV	3 AUDIO INTERFACE
AA3701-2		SV	3 ADF RCVR
AA82-060		SV	1 6 PLACE STEREO INTERCOM
AA83-001		SV	2 PLT/COPLT STEREO INTERFACE

AA95-210	AA95-	SV	2 AUDIO BOX
AA95-465		SV	1 AUDIO PANEL
AA95-488	AA95	SV	2 STATION BOX
AA95-745		AR	1 ICS PANEL
AA95-745		SV	3 ICS PANEL
AA95-748		SV	1 AUDIO PANEL
AA95-763		SV	1 AUDIO PANEL
AA95-781		SV	1 AUDIO PANEL
AA95-861		SV	1 AUDIO PANEL
AA95-894		SV	2 AUDIO CONTROL PANEL
AA95-894		NE	1 AUDIO CONTROL PANEL
AAC-4483A		SV	1 CONTROL BOX
AAC4616		SV	1 NAV HEAD CONTROL
AB44-12	AB5-5	SV	1 RELIEF VALVE
AB5-5	ABD21	SV	1 SEAT BELT
ABD211-01		SV	1 ANTENNA
ABD211-03		SV	1 ANTENNA
ABU-5/A	86000-1107	OH	1 CLOCK ACFT MECH
AC131	AC-16	SV	1 AIRSPEED INDICATOR
AC7-13280B	AC899	SV	1 CONTROLLER
ACA103		SV	1 RPM SIGNAL TX
ACA109		SV	1 RPM SIGNAL TX
ACA-AS117-02-00		SV	1 ABSORBER ASSY
ACA-AS117-03.00		NE	1 VIBRATION ABSORBER
ACS-1278	ACU61	SV	1 AUDIO MIXER PANEL
ACS-2080	ACS-2080-300	SV	3 AIR COMM AUDIO MIXER
ACT-01-001		SV	1 AC TRANZORB ASSY
ACT-01-001		SV	1 AC TRANZORB ASSY
AD.32.32.35F.28.1.EA		FN	1 Air Data Display >CONFIG 8104<
AD1007TD1527	AD1007	NS	1 CODE GENERATOR
AD43011-01C	013-1909-010	SV	1 RAD ALT ANTENNA
ADS43010-1AC	ADS43010	NE	2 ANTENNA
AE6100E0360-180	AE702	NS	1 HOSE ASSY
AE70280084-180	AE981	NS	1 HOSE ASSY
AE705780-3		NE	1 HOSE ASSY
AE705827-2		NE	1 HOSE ASSY NG12
AE706292-4		SV	1 HOSE ASSY
AE706292-5		SV	1 HOSE ASSY
AE85692P		NE	1 FITTING FRANGIBLE
AE98148N	AFD50	NS	1 ADAPTER ASSY
AFD50-24-108SN-6094	80937363	NS	2 CONNECTOR
AFG013176		AR	1 INERTIA REEL MOUNT
AFG0391653	AI-16	SV	1 STRAP BLOCKING
AFG0424879		NE	6 INERTIA REEL MOUNT

AFG763300-02		NE	4 FUEL INDICATOR
AG34		AR	1 TACH
AHA1121M0D1-2-3-4-5		SV	2 BRAKE HAND ASSY
AI-1611-1G	AI-36	SV	1 SAT TV ANTENNA
AI-360		OH	1 ATTITUDE GYRO
AI-BSE65-01-2		SV	4 MONITOR RECEPTICLE
AI-EQ1	A1-EQ1	SV	1 AUDIO INTL MODULE
AI-LCD65-01-SWL		SV	2 MONITOR DISPLAY
AIM500E		OH	1 HORIZON REF IND
AIR-AP1220B-A-K9		SV	1 WIRELESS ACCESS POINT
AIRCOM55	AIS20	SV	1 CONTROL PANEL
AIS200-35		SV	1 REMOTE SWITCH UNIT
AIS80-1		SV	1 CDI SWITCH UNIT
AIS80-1		NE	2 CDI SWITCH UNIT
AI-STR-01A		SV	1 AUDIO INTL INTERFACE MODULE
AJ6-60		NS	4 DZUS STUD
AK-551-9M		NE	2 POWER CONVERTER
AK-950-KLN89B	AK950	SV	1 GPS/NAV SWITCHING ANNUC
AK950TNL2000-28V	AL-05	NE	9 ANNUNCIATOR
AL15-8005	AL-16	SV	1 CVR CONTROL
AL-1611-1G	1302168-001	SV	1 ORBIT TECH POSITIONER
AL-21SG	AL-215G	NS	6 FILTER
AL-2600-3	AL-26	NS	7 ANTENNA CONTROL UNIT
AL-2600-SRR	1302167-001	SV	1 ORBIT TECH S-R-R-
AL-5117		NE	1 PROTECTED POWER SUPPLY
AM1779/ARA48	5996-00-617-1676	OH	2 AMPLIFIER, ELECTRONIC CONTROL
AM-1964F/AIC	5996-00-777-0173	SV	1 AMPLIFIER, AUDIO FREQ
AM-1965B/AIC	5831-00-952-3453	NE	2 AMPLIFIER, AUDIO FREQ
AM-3209/ASN		SV	1 AMPLIFIER ELECTRONIC CONTROL
AN161-8RS	AN302	NS	1 TURNBUCKLE, FORK
AN3025-100	A-718AP	OH	3 CUTOFF RELAY, AIRCRAFT
AN310-8	AN3H4	NS	5 NUT
AN3C46A		NE	13 BOLT HEX
AN46-17A	AN4H6	NS	2 EYEBOLT
AN4-7		NE	13 BOLT
AN5544-3		SV	1 TACH GENERATOR
AN565F1032H9		NE	13 SET SCREW
AN5760L2	671CKL-010	OH	1 ALTIMETER
AN5770-1A		AR	1 MANIFOLD PRESSURE IND
AN5795-6	10499-A	OH	1 DUAL OIL TEMP INDICATOR
AN814-3DL		NE	5 PLUG BLEED
AN8516-2		SV	1 HANDLE, SPANNER WRENCH
AN913-6D	AN937	NS	6 FITTING
AN924-12D		NE	5 NUT

ANV142SZ		SV	2 VHF ANTENNA
AOA5001		NE	1 CONTROL BOX RG FUEL TANK
AP05VC-032-01		SV	2 HYDRAULIC PUMP
AP2034C	AP2034A	SV	1 TEAM
APS1979A		OH	1 AUDIO FREQ AMPLIFIER
APT-100-1000-2030SG	APT-100-1000-2030	OH	1 PRESSURE TRANSDUCER
APT-100-1000-2030SG	APT-100-1000-2030	AR	3 PRESSURE TRANSDUCER
APTE51C-70D		AR	1 TRANSDUCER
AR2010/15		SV	1 COMM 2000 SYSTEM
AR2010/25		SV	1 COMM 2000 SYSTEM
AR209-11		OH	3 FLOW RATE IND
AR-209-11		OH	3 RATE INDICATOR
AR-209-6		OH	1 RATE INDICATOR
AR-209-8		OH	3 RATE INDICATOR
AR-2E-825-30000-302		NE	1 CONNECTOR
AR75-500		NE	11 ESCUTCHEON PLATE
AS21-15		AR	1 CARGO HOOK
AS2264		SV	1 DOUBLE CARGO HOOK FIX PROV
AS22-64		NE	1 DOUBLE CARGO HOOK FIXED PROV
AS22-83		NE	1 DUAL CONTROLS CARGO HOOK
AS2284		NE	1 DOUBLE CARGO HOOK FIX
AS-2890/APR-39(V)	5985-01-026-3927	SV	2 ANTENNA, BLADE
AS3100-(31N)-09		NE	1 COMM. CONTROL (NVG)
AS3209-146		NE	4 ORING
AS5174D0606		NE	2 FITTING
ASH671-1	ASNA0	OH	2 STATIC INVERTER
ASNA0045-120BCL		NS	1 NUT
ASU-ADI-A119-1		NE	1 NVG FILTER
ASU-BK-155165-1		NE	1 NVG FILTER KX165 LEFT SIDE
ASU-BK-155165-2		NE	1 NVG FILTER KX165 RIGHT SIDE
ASU-IND-3		NE	1 NVG FILTER
AT-206-2		OH	1 FUEL QTY IND
AT-209-NL		OH	1 TOTALZR IND-
AT-209-NL-05		OH	4 TOTALZR IND-
AT-884/APX-44		SV	2 ANTENNA
AT-884/APX-44		AR	2 ANTENNA
AV16E1293	222-366-680-101	OH	1 FUEL SHUTOFF VALVE
AV17125-1		SV	1 SUPPLY VALVE
AVS420-ZX-28-OCU	AVS420-ZX-28-CH	SV	1 AERIAL VIEW SYSTEMS
AW001FB1S03		NE	18 STUD ASSY
AW-5544-3		SV	1 TACHOMETER GENERATOR
B-00368-5		AR	1 ALTERNATOR CONTROL
B03C0Z		NE	1 MOD KIT
B183M2010101		SV	1 CONTROL UNIT Z

B183M2010102		NE	8 CONTROL UNIT
B18-945.22.28.4.AZ		NE	1 CLOCK(NVG)
B18-945-32-28-1AJ		SV	1 CLOCK
B19030NA02		SV	1 VEMD NVG
B19030NA04		SV	1 VEMD V2003 NVG
B19030NA04		NE	1 VEMD V2003 NVG
B19030NA05		SV	1 VEMD BK 117 NVG
B212M2049101		SV	5 VENTILATION BLOWER ASSY
B212M20C1013		NE	1 BLOWER ASSY
B212M20C1015		NE	1 BLOWER ASSY
B234M1020881		NE	1 RETROFIT SWITCH GEAR
B24000		SV	2 FUEL DUMP VALVE
B246K3002-109		NE	1 WIRED ASSY - DISTRIB BOX 1
B281K2753-051		NE	1 SUPPLY TANK
B281K2757-051		SV	2 AFT MAIN TANK
B284K3751-051		NE	4 TRANSMIT FUEL QTY SUPPLY TANK
B284M30C1002		NE	1 FUEL SENSOR SUPPLY TANK
B290P0007201		NE	2 HOUSING
B311M3010101		NE	1 MAIN SWITCH PANEL
B311M3038101		NE	1 TERMINAL JUNCTION
B31521-10-008		SV	1 INDICATOR,TR.TACH.NF-NR
B327M2001102		NE	1 SNOW SKIDS PREASSY LH-S
B327M5007102		NE	1 SETTL.PROTEC.EFS ASSY LH-S
B327M5008102		NE	2 SETTL.PROTEC.EFS ASSY RH-S
B334M3006104		SV	1 ELT-UNIT L/S-LIGHT ASSY
B344M3809102		NE	1 SUPPORT VERTICAL ASSY RDR1600
B34610-00-002	B3550	SV	2 TUBE, PITOT ELEC HEATED
B3550-7-307	B4553	NS	1 DOME LIGHT
B4515210005		OH	1 Encoding Altimeter
B45531-10-002		SV	2 ALTIMETER (IN/HG WITH ENC.)
B45531-10-004		SV	1 ALTIMETER (IN/HG W/O ENC)
B45531-10-104		OH	1 ALTIMETER
B4B-D		SV	1 INDICATOR, BANK & TURN
B521M3067101		NE	1 ARM WELDED LH-S
B551M0005101		NE	1 END PLATE ASSY LH
B620M0001103		NE	1 ROTOR SYSTÉM
B621M1002053		SV	2 BLADE ARM 2
B622M1004201		SV	1 QUADRUPLE NUT UPPER
B622M1005201		SV	1 QUADRUPLE NUT LOWER
B633M2008201		NE	3 HEXAGON BOLT
B671M1002101		NE	1 SHORTING PLUG
B671M5001104		SV	1 COLLECTIVE LEVER RH
B671M5801102		NE	1 COLLECTIVE LEVER LH
B672M1805102		NE	1 BELL CRANK

B711M3530101		NE	12 COVER XMSN COWLING RH
B711M4121101		NE	1 FRONT HINGE LH
B716M1024101		NE	1 FLANGE
B7-213-001-00		SV	1 CLOCK
B851M10X2001		NE	1 LOAD ROPE AFT
B851M2012052		NE	2 INST GRAB RING F HOOK EH
B851M2085101		NE	1 GRAB RING ASSY
B851M2105101		NE	3 HOLDER CONTROL PEND.EH COMF
B9845-1-305	BAC08	NS	1 DOME LIGHT
BAC086-33B		SV	1 COCKPIT WINDOW
BAC086-B		SV	1 COCKPIT WINDOW
BC1-0002-022		SV	1 COMPT LIGHT
BC1-0002-023		NE	1 EXIT SIGN
BC1-0002-024		NE	1 EXIT SIGN
BC1-0002-025		NE	1 EXIT SIGN
BC147-252	BD755	NS	1 BUTTON
BD755-212	BDW-A	SV	1 RADOME
BE369	BH185	SV	2 T-I-T- INDICATOR
BH185R4B	BHL-S	SV	2 T-I-T- INDICATOR
BHL-STD1036-331	BJ197	SV	1 STAND OFF
BLSABX-SWS32CS	BP-13	NS	1 LINER BALL BEARING
BN846-03		NE	1 TE450
BP-134-3616		OH	1 AUDIO CONTROL
BP230-6		OH	1 LH FUEL PUMP
BP-600C-01		SV	1 PWR/COMM UNIT
BR398		SV	2 ANGLE POSITION IND
BR5000-517		SV	1 OUTLET PLUG
BTI-600-2A		SV	1 BATT TEMP
BTI-600-3A		SV	2 BATT TEMP IND
BWS01		NE	1 BALANCE WEIGHT SYSTEM
C0001-81103		OH	1 ALTIMETER, PRESSURE
C-10109/USC-14V	774-1320-002	AR	1 CONTROL
C1-22306	67-523-412-21	SV	3 MICRO SWITCH
C12847BB		SV	2 AVIONIC RACK
C12847BB		NE	2 AVIONIC RACK
C12847CB		NE	1 AVIONIC RACK
C12847CB		SV	3 AVIONIC RACK
C13077AA		SV	2 RACK 4 SLOTS
C145-6034-1		SV	1 AFT EVAPORATOR
C1611D-AIC		OH	3 ICS PANEL
C16287CA	704A47612135	SV	1 SIMPLE INDICATOR NR
C17591-105		NE	1 VALVE ASSY
C175F3C		SV	1 VENT BLOWER
C19209VF11		SV	1 SMD 45 H

C19243AB02		SV	1 CAD
C19243AB07		SV	1 CAD 2002
C19243AB08		NE	1 CAD V2003 DISPLAY
C19243AB08		NE	1 EC135 CAD V2003 DISPLAY
C19243AB09		SV	1 CAD SW V2005 NVG DISPLAY
C19243AB09		SV	1 CAD SW V2005 NVG DISPLAY
C19243EA02		SV	1 CAD NVG
C19243EA04		SV	4 CAUTION ADVISORY DISPLAY
C19243EB04		SV	3 CAD V2003 NVG
C19243EB05	B316M30S1001	SV	1 CAD BK117 NVG
C19252FB06		NE	1 FLIGHT CONT. DISPLAY MODULE
C19252FC07		NE	1 FCDM
C19252FC07		SV	5 FLIGHT CONTROL DISPLAY MODULI
C19252JC07		SV	4 FCDM FBL3 SHS
C19252LC07		NE	1 FCDM
C19253AA		SV	4 INSTRUMENT CONTROL PANEL
C19254AA		NE	3 RCU
C19254AA		SV	2 RCU
C19267NG10		SV	3 SMART MULTIFUNCTION DISPLAY
C19267SG10		SV	3 SMART MULTIFUNCTION DISPLAY
C19267VF11		AR	3 SMD NVG
C-2106/AIC-18	5831-809-3180	OH	1 CONTROL, INTERCOMM SET
C-2106A/AIC-18	5831-809-3180	OH	1 CONTROL, INTERCOMM SET
C-2106A/AIC-18	5831-809-3180	AR	3 CONTROL, INTERCOMM SET
C215A1930103		SV	1 BOX CONTROL, EQUIP COWLING
C-2323A/AIC	5831-00-539-1471	SV	1 PANEL, MONITOR
C24160045-2		SV	1 PUMP, HYDRAULIC, LH
C3495100045		SV	1 OVERSPEED WARNING SWITCH
C-3835/ARC-54		SV	1 CONTROL, RADIO SET
C3BE4825A01		SV	1 PANEL, WARNING
C4FP4613A05		NS	2 FALCON 50 OVERLAY PANEL
C5175Y		NS	1 INDICATOR, EMER-FUEL VALVE
C594502-0102		AR	1 FLASHER
C598501-0202	14-50-01	OH	1 ANTENNA
C622010-0101	156-0019R	SV	1 NAV STROBE POWER SUPPLY
C622010-0102	156-0019G	SV	1 NAV STROBE POWER SUPPLY
C622010-0104		AR	1 NAV STROBE POWER SUPPLY
C-6287/ARC-51BX	C632A	SV	1 CONTROL
C631A1101101		SV	1 COUPLING ASSY, FLARED
C642A0201104		SV	1 PLATE ASSY, CONTROL
C661035-0101		SV	1 VSI
C661035-0101		SV	1 VSI
C661053-0103		OH	1 DIRECTIONAL GYRO
C661056-0202	5000F10	OH	1 GYRO

C668511-0102		SV	1 ALTIMETER
C67TS/1		OH	1 IGNITION UNIT
C6SC10373		OH	1 PROP TACH IND
C-79-2KAI		NE	1 PUSH LATCH
C826A-AIC10	CA-10	SV	1 CONTROL
CA-101A		SV	4 DISPLAY UNIT
CA3100E24-28PF80		NS	4 CONNECTOR
CA3106F32-1P-F80	CA-41	NS	1 CONNECTOR
CA-412-98-94		NE	1 KIT
CA-52-1A	7000T	OH	1 VSI
CB-2100-T4	AN5766-T4	SV	1 COMPASS, MAGNETIC PILOTS
CB2100T6D	CB301	SV	2 COMPASS
CBC43W2F00JVL0		NS	5 CONNECTOR
CCU-01-001	CCU-01	SV	1 COOLING CONTROL UNIT
CDM-630		SV	1 VIDEO CONVERTER
CDP250C		SV	1 DISPLAY UNIT,ISAT
CDS-728FK	CDX-W	SV	1 VCR
CDX-757MX		SV	1 CD CHANGER
CDX-W404	CE-00	SV	15 10 DISK CD CHANGER
CE394/U	CE413	NS	1 SWITCH BOX
CE413490073		SV	1 EGPWS RELAY UNIT
CE443490003-01		SV	1 EGPWS RELAY UNIT
CES3000-2	SES-83-1018-12	SV	1 SAS CTL AND IDLE CII TEST SET
CGS962U050V4C		NS	3 CAPACITOR
CH150-14-00		SV	1 CONTROL HEAD, RADIO TETRA
CHA-S634		SV	1 CD AUTO CHANGER
CI-105-7		NS	1 DME/TRANS ANT
CI-105-9		AR	1 ANTENNA
CI-120-1		SV	1 ANTENNA
CI-125		SV	1 VHF COMM ANT
CI-222		SV	1 AM/FM ANTENNA
CI-2RR		SV	1 JENSEN MODULE
CI401-420		SV	1 ANTENNA
CI-5000-1-L	CI5000	SV	1 TRANS/RADIO TELE ANT
CI-818A	3500-137-1D	SV	1 PC BOARD
CI-884		SV	1 PC CARD
CI-9051		SV	1 PC CARD
CIA-100		SV	1 RGB AMP INTERFACE
CIX94K6-74	CL-33	NS	1 SWITCH CABLE ASSY
CL-33	209-375-096-103	SV	2 CURRENT LIMITER
CN-405/ASN		SV	1 COMPENSATOR
CNS022		NS	1 PLUG
CP-1285A		SV	6 TEAM AUDIO CONTROL
CP-1285D		SV	1 TEAM AUDIO CONTROL

CP2618DB01		SV	1 SWITCH SELECTOR,ICS45
CP-5129/AYQ-507V3	C20709-1	OH	1 DATA ACQUISITION UNIT
CPW-ELW35		NS	2 MOUNTING CLIP
CR2795B105A1		SV	1 REGULATOR
CR2795E100A1	CTA33	SV	1 VOLT REG
CR3523-5-11		NE	100 RIVET CHERRY MAX
CRN6-83-1	704A45354002	SV	1 UNIT,SWITCHING
CSIBF14501-MANT		NE	1 IBF KIT 145
CTA339B1	D091-	SV	1 DME INDICATOR TEST ADAPTOR
CTJ120E03D513		NS	2 MODULE,TERMINAL
CTJ-3D-05		NE	1 RACK,ELECTRONIC JUNCTION
CTJ420E044D513		NS	1 MODULE,TERMINAL
CTJ420E128-513		NS	1 MODULE,TERMINAL
CW0622-1010		NE	3 SHROUD A119 MD41 HTAWS
D00282-0005		NE	1 LAST SENSOR
D091-1		SV	1 REGULATOR,VOLTAGE
D0C20-06		SV	1 ANTENNA COUPLER
D107318E		NE	4 FUEL PUMP ASSY
D107318E		SV	1 FUEL PUMP ASSY
D107318E		NE	4 FUEL PUMP ASSY
D107319		SV	1 FUEL PUMP
D107611E		SV	1 SERVO MOTOR
D107611E		NE	4 SERVO MOTOR
D120-P2-T	5120-P1	SV	2 ALTITUDE DIGITIZER
D134-1463		NE	1 CARD
D134-994		NE	1 WIRING HARNESS 38VB
D136-1010		NE	1 COPILOT SEAT
D136-1013.03		NE	1 STRENGTHENING
D136-1013.04		NE	1 BAR SPLINED
D136-1014		NE	1 SEAT RAIL RH
D163-1013		NE	2 SEAT RAIL LH
D19-035	704A46211023	SV	1 VOLTAGE REGULATOR
D20516-L		SV	1 NAV ANTENNA
D20516-R		SV	1 NAV ANTENNA
D205-523-011		SV	2 HELI-RAPPEL KIT LH
D240845	D24AB	SV	1 PUMP
D240845	D240845F	NE	3 PUMP
D24AB1042	D2979	OH	1 RELAY, BREAKING CIRCUIT
D3040E		SV	1 LANDING LIGHT GRIMES
D30-45		OH	1 PROPELLER
D34160-101	D5150	SV	1 FLOAT ASSY FWD LH
D350-578-017		NE	3 AS350/AS355 BEARPAWS FLAT TOP
D38999/26WJ-20PA		NS	1 CONNECTOR,RCPT,ELECTRICAL
D4703-041		NE	2 LOCKOUT PIN

D50020-111W		NE	3 CEILING PANEL ASSY
D50020-111W		NE	3 CEILING PANEL ASSY
D50020-112W		NE	1 CEILING PANEL ASSY
D50022-121W		NE	1 ROOF SIDE PANEL RH
D50023-111W		NE	2 CEILING SIDE PANEL ASSY LH
D50026-2W		NE	1 WINDOW TRIM ASSY RH
D50026-2W		NE	1 WINDOW TRIM ASSY RH
D50027-1W		NE	1 SIDE POST COVER ASSY RH
D50042-121W		NE	1 PANEL ASSY UPPER LH
D50042-131W		NE	1 PANEL ASSY SIDE
D50043-111W		NE	1 PANEL ASSY
D50043-112W		NE	2 PANEL ASSY RH
D50043-1W		NE	1 PANEL ASSY
D50043-2W		NE	1 PANEL ASSY
D50055-111W		NE	1 JOINER PANEL UPPER CARGO
D51506	900/D51506	SV	1 CVFDR,VOICE/DATA RECORDER
D51546-011	D5161	OH	2 CVFDR
D60268MK11112	D6026	SV	2 AIR DATA SENSOR
D60268MK21121	D6026	SV	2 AIR DATA SENSOR
D60268MK21123		SV	1 AIR DATA SENSOR
D-9961-3		NS	3 COVER (RED)
D9J13-00980	80008030	SV	1 ARINC RACK
DA-24658-31		NE	4 BACKSHELL SUB-D
DAAB0786CH061	CP-1828/ARN-148	OH	1 COMPUTER, AIRSPEED
DAPSHDMI-1		SV	1 HDMI SPLITTER
DB438	438	SV	1 AMP
DB600		SV	1 TONE GENERATOR
DBA5W5SA197F0		NS	4 CONNECTOR
DBD-01-001		SV	6 DUAL BAND DETECTOR
DBMAM25S		NS	1 CONN KIT
DC7ZX+071W		AR	1 MOTOROLA RADIO
DCR-1A-06		NE	4 CONNECTOR RAIL
DCR-1A-10		NE	1 CONNECTOR RAIL
DD44F10JVLO		NS	2 CONNECTOR
DDL-OC119A	76450-01076-105	OH	1 T5 INDICATOR
DE-24652	DF-88	NS	2 BACKSHELL
DF-88A		OH	2 DIR FINDER IND
DH7BC		SV	1 RELAY
DHS433-141-05		NS	10 NUT
DK041-1		NE	1 OIL PRESSURE PICK-OFF 14 NT
DL016-3		SV	1 RPM TRANSMITTER
DL016-3		NE	1 RPM TRANSMITTER
DL404-38		SV	1 TRIPLE RPM INDICATOR
DL404-39		SV	1 TACHOMETR

DL404-40		SV	1 TRIPLE RPM INDICATOR
DL404-40		SV	1 TACHOMETR
DL404-53	105-957201	OH	1 TRIPLE RPM INDICATOR
DL412-39		OH	1 SINGLE RPM INDICATOR
DL412-39	105-90845	NE	2 SINGLE INDICATOR
DL412-40		OH	1 SINGLE RPM INDICATOR
DL412-40	105-90845	OH	1 RPM INDICATOR
DL436-38		OH	1 TRIPLE RPM INDICATOR
DL457-021	L771M40C1005	SV	1 TRIPLE INDICATOR RRM
DLA900-85-M-SB76		NE	1 CRYSTAL FILTER UNIT
DMC63-2		SV	1 ANTENNA
DMC63-4/A	DMC70	SV	1 ANTENNA
DMC70-1A	DMELT	NE	1 ANTENNA VHF
DM-C70-1A		SV	1 ANTENNA
DMH21-1		NE	1 VOR/LOC ANTENNA COUPLER
DMH21-1		SV	2 VOR/LOC ANTENNA COUPLER
DMH24-1		SV	1 COUPLER, GLIDE ANTENNA
DMN4-17-1/N		SV	3 VOR/LOC/GS ANTENNA
DMNI-24		SV	1 ANTENNA DME TRANS
DMNI50-10-2		NS	1 ANTENNA
DMNI50-6-2		SV	10 ANTENNA
DMNI50-9		SV	1 ANTENNA
DMNI50-9		SV	1 ANTENNA
DPP4FS464	MS27644-1	NE	10 BEARING
DPXBMA57-33S-0001		NS	4 CONNECTOR
DRA45C-26		SV	4 OVERSPEED WARNING SWITCH
DSR59176-1014		NE	30 SPRING DISC
DSRM-10		NE	1 REMOTE CONTROL UNIT
DST1017-5	850568-1	SV	1 ITT IND
DT410-2	412-075-008-113	OH	1 DUAL TORQUE IND
DT501-2		SV	1 DOUBLE TORQUE INDICATOR
DT501-9		NE	1 TORQUE INDICATOR
DT-A8GA		SV	8 SPEAKER
DT-AX2		SV	14 DT SYSTEMS SPEAKER ASSY
DTE12-001		SV	1 NAT DTFM PAD
DV00514-0291-0002-03	0514AD3	SV	1 ELECTRONIC JUCTION BOX
DVD-023-01-1		SV	1 AUDIO INTERNATIONAL
DVD-024-03-1		SV	1 DVD PLAYER
DVD1270E-H01A	DVD1270E	SV	1 MULTIFORMAT DVD WRITER
DV-EL320-240	DB586	SV	1 DYNAFLIGHT SEISBAG
DVI250A		SV	1 ISAT100 CONTROL HEAD
DVI-250C		SV	1 ISAT100 CONTROL PANEL
DVP-S5301	DW5FS	SV	1 DVD/CD PLAYER
DZP_04-800W		FN	1 DZMx DZUS with Sat,4G,Wifi,BT

E00101E00010100		NE	1 TRIPLE RPM INDICATOR
E07391-10-057		OH	1 AIRSPEED IND (KNOTS)
EA124AN-124		SV	1 FUEL QTY IND
EAD01		NE	3 FIXED EXTERNAL ABSEIL DEVICE
EB2BW		SV	1 FLOATING ELT
EC135-1004-14		NE	1 FWD SLIDE RH WINDOW
ECD-AMG-11	CD402B-NVG	SV	3 CONTROL DISPLAY UNIT
ECD-AMG-17	CD671C-NVG	NE	1 CONTROL DISPLAY UNIT
ECJ504-8		NE	1 CONNECTOR
ECU76A		AR	1 CONTROL UNIT
EE4-1450		NE	1 CONE GUIDE
EMSE377-2	ES400	SV	1 POWER SUPPLY
EMU-A-010-2		SV	1 PROCESSOR ADAS
EMU-A-010-3		SV	1 PROCESSOR ADAS
EPT941		SV	1 B LINE ELT LOCATOR
ES40020-4	ES721	NS	2 NUT
ES61104-1		NE	4 MOTOR
ESB-36C/3		SV	1 AIRBORNE COMM
ESB76A/3		SV	1 CONTROL
F15-0141-1	F2MA6	NS	2 BASE RAIL
F2MA600232110B2	600232	SV	1 ELT CONTROL PANEL
F32827.5		NE	4 NEEDLE BEARING
F32828-5		NE	4 NEEDLE BEARING
F36C2S28LEAE		NS	1 FLEX LIGHT
F50-11202-501	F50-1	SV	10 PC BOARD
F50-11203-501A	F50-11510A	SV	1 PC BOARD
F50-11205-501B	F50-1	SV	8 PC BOARD
F50-11891-505-701		SV	1 P- ANNUNC- FRAME ASSY
F50-11891-505-703		SV	1 P- ANNUNC- FRAME ASSY
F50-11891-505-704		SV	1 P- ANNUNC- FRAME ASSY
F50-11894-501		SV	1 JUNCTION BOX
FD104ARM		FN	1 Display 10,4" with arm
FD104ARM-VERSION_180		NE	2 Display 10,4" 180 deg version
FD151DMT		FN	1 15" Cabin Display Mount
FD70ARM		FN	1 FD70CV-V Display w/FD70DMT
FDS81-1029		FN	7 MAU - MODULAR ACQUISITION UNIT
FE463		AR	1 PC CARD
FE897	704A47131019	SV	1 UNIT,INDICATING
FERN0-SRFW-12-2		NE	1 FERNO-TYP LITTER
FGFB600232		SV	1 ELT CONTROL PANEL
FLX2645		SV	1 ANTENNA
FLYM23800-2		SV	1 MOTOR DIRECT MAGNET
FM10-12		SV	1 FLUGH MARKER BEACON
FM10-12G		SV	1 ANTENNA, MARKER BEACON

FM20-66		NE	2 HYBRID COUPLER
FM2510		SV	1 FURUNO FM TRANSCEIVER
FM504		OH	1 AIRSPEED INDICATOR
FM504-49		AR	1 AIR SPEED
FMB10-272-1		SV	1 ANTENNA MARKER BEACON
FN-100		NE	1 AVIONICS FAN, 11-32 VOLTS
FT-25242	L281M20C1010	NE	1 FUEL TANK
FV-0910		SV	1 CAMERA CONTROL UNIT
G-1684		SV	1 ATC CONTROL PANEL
G-2139		SV	1 CONTROL
G2581-03		SV	1 SELCAL PANEL
G300103	704A47720100	SV	1 ROTOR RPM WARNING
G3849A		SV	2 TACAN CONTROL
G4345		AR	2 AUDIO PANEL
G-4433A		SV	1 ADF CONTROL
G-4434		SV	1 VHF CONTROLLER
G-4434A		SV	1 VHF CONTROLLER
G-4436A		SV	1 TRANSPONDER CONTROL
G-4483-14		SV	1 COMM CTL
G-4483B		OH	1 COMM CTL
G-4484D		SV	1 ATC CONTROL PANEL
G4501A		SV	1 CONTROL
G-4518		SV	1 CONTROL
G456		SV	1 VACUUM PUMP
G4649		SV	1 COMM ATC CONTROL
G-4688		SV	1 AUDIO PANEL
G-4745A		SV	1 ATC CONTROL
G-4876A		SV	1 ATC/NAV CONTROL
G-4876C		SV	1 ATC/NAV CONTROL
G-5325A		SV	1 COMM 1-2, NAV 1-2 CONTROL
G-5515		SV	1 COCKPIT SPEAKER
G-5565		SV	1 MKR / ATC CONTROL
G5922-13		SV	1 CONTROL
G5934		SV	1 VHF/NAV CONTROL
G6119A	G6136	SV	1 ADF CONTROL
G6136B	G6240	SV	1 CONTROL RACK
G6240-4		OH	1 SEARCH LIGHT
G-6250		OH	1 SEARCH LIGHT
G-6325		SV	1 AUDIO MONITOR
G-6345		OH	1 AUDIO CONTROL
G6478-001-40		SV	1 CONTROL, COMPUTER
G6644-01		SV	1 ATC CONTROL
G6644C		SV	1 CONTROL
G6861-01		SV	1 CONTROL

G6930-03		SV	1 CONTROLLER
G6944-01		SV	1 ATC CONTROL
G6969-04		SV	1 TCAS CONTROL
G6969-05		SV	1 TCAS CONTROL
G7008-64		SV	1 CONTROL
G-708-1		AR	1 INTERPHONE AMP
G7275-04		FN	2 Cursor Control Device (CCD)
G7632-108		SV	3 NAV, VHF, CTL, CTL-32G
G7740A19-24	G8385	SV	1 LOWER ROTATING BEACON
G8385-7		NE	2 LANDING LIGHT
G8385-7		OH	1 LANDING LIGHT
G993-01-1A		OH	1 RATE OF CLIMB INDICATOR
G993-01-1B		OH	1 RATE OF CLIMB INDICATOR
G9950-1		OH	1 BEACON ASSY, UPPER
GA223280002-257		SV	1 PANEL
GA341200009-01		SV	3 PANEL
GA341200009-13		SV	5 FSU 1 FSU 2 PANEL
GA341200009-23		SV	5 FSU 1 FSU 2 PANEL
GA341200010-01		SV	3 PANEL
GA343700002-67		SV	1 FMS CONTROL PANEL
GC13422-4-1		SV	1 PRINTED CIRCUIT BOARD
GC1346142		SV	1 PRINTED CIRCUIT BOARD
GC514280073-01	4280073-01	AR	1 LAN SWITCHING UNIT
GC514280075-01	4280075-01	SV	2 WIRELESS ACCESS POINT
GC514740002		SV	1 BATTERY
GC543350007-7	720-7719D	SV	5 GULFSTREAM CONTROL WHEEL
GG301ED-A2	3001EDK	OH	1 GYRO, VERTICAL
GM11953		NE	6 LINEAR TRANSDUCER
GN565-26-160SW		NE	1 HANDLE
GNS430W	010-00412-01	NE	5 GNS430W WITH INSTALL KITS
GPX428001013-301		NE	1 BRACKET ASSY
GS-15-25-GG-K50146-400N		NE	1 GAS SPRING 400N
GT-900R7441000-TD		SV	1 TOOL
GV-620-16	GV-620-16-87	SV	1 PANEL
GV-620-17	GV-620-17-87	NE	1 PANEL
H140ABM1		OH	1 HORIZON GYRO
H140ABM2		OH	1 HORIZON GYRO
H140ACM1		OH	2 HORIZON GYRO
H140ACM2		OH	2 HORIZON GYRO
H140ADM1		OH	1 HORIZON GYRO
H140ADM2		OH	1 HORIZON GYRO
H140ALM1		OH	1 HORIZON GYRO
H140AMM1		OH	1 HORIZON GYRO
H140AMM2		OH	1 HORIZON GYRO

H140ARM2		OH	1 HORIZON GYRO
H140ASM1		OH	1 HORIZON GYRO
H140ASM2		OH	1 HORIZON GYRO
H140ATM1		OH	1 HORIZON GYRO
H140ATM2		OH	1 HORIZON GYRO
H140AUM1		OH	1 HORIZON GYRO
H140AUM2		OH	1 HORIZON GYRO
H140BHM		OH	2 HORIZONT
H140BHM1		OH	2 HORIZONT
H140BHM2		NE	4 HORIZON GYRO
H140BHM2		OH	2 HORIZONT
H140BLM		OH	1 HORIZON GYRO
H140CAM		OH	2 HORIZON GYRO
H140CAM1		OH	2 HORIZON GYRO
H140CJM		OH	2 HORIZON GYRO
H140CJM1		OH	2 HORIZON GYRO
H140CLM1		OH	2 HORIZON GYRO
H140CPM		OH	1 HORIZON GYRO
H140CPM1		OH	1 HORIZON GYRO
H140CSM1		OH	1 HORIZON GYRO
H140CWM		OH	2 HORIZON GYRO
H140JAM1		OH	1 HORIZON GYRO
H140JKM1		OH	1 HORIZON GYRO
H2301-9		NE	1 LATCH
H321ABM1		OH	1 ATTITUDE INDICATOR
H321AKM1		OH	1 ATTITUDE INDICATOR
H321ALM1		OH	1 GYRO
H321ASM1		OH	1 HORIZON GYRO
H321BHM1		OH	1 HORIZON GYRO
H321CMM		OH	1 HORIZON GYRO
H321CZM	704A47150120	OH	3 HORIZON GYRO
H321EGM		OH	2 HORIZON GYRO
H600S160A434		NE	1 LOCKING MECHANISM
H930-6		SV	1 INDICATOR
HAF118	704A35333053	NE	1 MOBILE ANTENNA
HAI-222-070-150		SV	1 INDICATOR
HAI-222-070-160		SV	1 INDICATOR
HAI-222-070-170	AES-0007-SCSH	SV	1 AES
HCA3		OH	1 ELECTRIC MOTOR
HD135-75-3000-1		NE	1 POCKET
HD365-15-6008-01		NS	1 BEARING
HD365-15-6053-01		NS	2 HANDLE
HD412-05-6004-01	HD412	NS	3 BRACKET
HD412-15-6039-03	HD412	NS	1 BRACKET

HD412-75-6018-10	HD900	NS	2 DOUBLER
HD900-62-3003-02	HDATD	NS	1 SUPPORT
HDATD-15-6096-21	HDS92	NS	4 BUSHING
HDSTD-04-6004-02	HDSTD	NS	1 AMP
HDSTD-15-6096-09	HDSTD	NS	2 PIN
HDSTD-15-6096-09		NE	2 PIN
HDSTD-15-6101-03		NS	2 TELESCOPING TUBE
HDSTD-98-6004-02	HDSTD	NS	2 SPRING
HDSTD-98-6004-2		NS	2 SPRING
HDSTD98-6011-02	HE641	NS	5 GRAPHITE HINGE
HE64100	HG202	SV	1 CONTROLLER
HG2021GB01	HG709	SV	1 SENSOR UNIT
HG7095A1		SV	1 RAD ALT RCVR
HGA-48		SV	2 ANTENNA
HI-400		SV	1 COMPASS
HL19PB5-7	HN4H4	NS	35 HI LOC
HLN6912B	XTL5000	SV	1 CONTROL HEAD
HMF-BG-135-115		NE	2 TW-SPRUEHSCHLAUCH GARDENA
HMF-BG-135-600		NE	1 DOWING BAR
HN4H41-1	HR-DR	NS	10 BUSHING
HR-DR-28	HS565	SV	1 STOBEL LIGHT
HS5659ME6PN	HS583	NS	4 CONNECTOR
HS5835-15	HSAA0	NS	13 DECAL
HSAA04549-001	HSAS0	FN	19 LIFE VEST KIT
HSAS00328-011	HSAS0	NE	1 CB SEGMENT, VHF-FM 5A
HSAS04534-001	HTE20	NE	1 PLACARD "MOBIL AERO HF" LARGE
HTE200016	HTE20	OH	1 ACTUATOR BALL VALVE
HTE200016	HTE90	AR	1 ACTUATOR BALL VALVE
HTE9061	HTE90	OH	1 VALVE ASSY
HTE9061	HUCAB	AR	1 VALVE ASSY
HTE920018		NE	3 ACTUATED BALL VALVE
HTE9482		SV	1 FIRE SHUTOFF VALVE
HUCAB2BP		SV	1 CONTROL-BRIEFER
HUCG-1-BPE		SV	1 CHECKLIST
HZ0000102770-R		NE	1 EXTERNAL HANDLE
HZ0000139480		NE	1 INTERIOR HANDLE
I-81-A		OH	1 INDICATOR
IC3100-(2)-01		SV	1 IC-AMPLIFIER
IC3100-2		SV	1 IC-AMPLIFIER
ICM11		SV	1 VHF TRANSCEIVER
ID-1103/ARN	5826-00-952-3709	OH	1 ID-1103/ARN INDICATOR
ID-1351B/A		OH	1 INDICATOR HEADING
ID-310A/ARN	5826-00-691-4893	OH	1 INDICATOR, RANGE
IN223A		SV	1 CONVERTER IND VOR/ILS

IN224A		SV	1 CONVERTER IND VOR/ILS
IPT20RT1-1000-80G		SV	1 PRESS- TRANSMITTER
IPT70RT1-1000-250G		SV	1 PRESS- TRANSDUCER
ISAT-100		AR	1 SATCOM TRANSCEIVER
JB37-405		NE	7 JUNCTION BOX, 5 STATION
JBS223-1		SV	1 COMPRESSOR ASSY
JBS880-3		NE	4 MIXING VALVE
JBS880-3		SV	3 MIXING VALVE
JBS880-3		AR	1 MIXING VALVE
J-D4N-300M		NS	1 LEACH RELAY
JE2-1978-0NG		SV	1 ELT
JG206D4	ID-1345/ARN-171(V)	SV	1 INDICATOR, ALTITUDE RADAR
JG873B1		SV	1 INDICATOR
J-J2A		NE	1 RELAY
JR28259		OH	1 AIR FLOW CONTROL
J-W4N-005		NS	1 LEACH RELAY
K00-00074-00		NE	1 ANTENNA KIT
K11695		NE	1 DAEMPFER HD18
K12054		NE	2 TAWS CONFIG KIT
K38490	K60AB	SV	2 CO2 CYLINDER
K402AC		NE	1 CHIP DETECTOR
K60ABM		SV	1 ACT POSITION DISPLAY
K9323030A000		FN	1 12" Display Unit (DU)
KDL569R		SV	1 TEST BOX
KHF950	KHF950SYSTEM	SV	3 HF SYSTEM
KHF990	KHF990SYSTEM	SV	3 HF SYSTEM
KIT:117-902051	117-902051	NE	1 RPM BOX
KIT:B793M5004051	B793M5004051	NE	1 FUZZ BURNER COMMON KIT
KIT:L332M3802051	L332M3802051	NE	1 BELT AND NO SMOKING SIGNS, INS
KIT:L334M6860101	L334M6860101	NE	1 SX-16 HAND CONTROL
KIT:L642M1806051		NE	3 FEN.GEARBOX COVER
KIT:L642M1806051	L642M1806051	NE	1 FEN. GEARBOX COVER
KS-502A		SV	1 POWER SUPPLY
KS5216H2	L108A	FN	1 CLAMP
KS5216H2		NE	1 CLAMP
L108AAM		SV	2 ARTIFICIAL FEEL UNIT
L110M1806288		NE	1 PLACARD ROTORBRAKE
L132M0009101		NE	1 SHORT
L133M6205205		NE	1 SUPPORTING SLEEVE
L133M6205205		NE	1 SUPPORTING SLEEVE
L133M6205206		NE	1 SUPPORTING SLEEVE
L133M6205206		NE	2 SUPPORING SLEEVE
L133M6205207		NE	2 THRUST PIECE
L20420-13	L209C	NS	2 LAMP ASSY

L209CCM2	L281M	SV	1 FEEL AND TRIM ACTUATOR
L210M1820114		NE	1 EVAPORATOR COCKPIT ASSY
L210M1831105		NE	1 COND MODULE ASSY
L2-117-93		NE	2 CONTROL BOX ASSY
L212M40X1001		NE	1 MIXING VALVE
L214M1038102		NE	1 BRACKET ASSY
L219M28X3001		NE	1 SLIM BLOWER
L221M75X3101		NE	1 TRIMACTUATOR
L251M2011205		NE	1 SEAT TRACK FENDER SERIES
L251M4002101		NE	1 MAP CASE RH ASSY
L258M2079101		NE	1 CARGO COMP.PANEL LH
L258M2839101		NE	1 CARGO COMPT WALL LH ASSY
L281M2008101		SV	3 FUEL SENSOR MAIN TANK
L281M2009101		NE	2 FUEL SENSOR MAIN TANK
L281M2011101		SV	3 FUEL PROBES SUPPLY TANK
L281M2011101		SV	1 FUEL SENSOR SUPPLY TANK
L281M2012101		SV	5 FUEL PROBES MAIN TANK
L281M2012101		SV	10 FUEL SENSOR MAIN
L281M20C1006		NE	1 FUEL MAIN TANK
L281M20C1006		SV	5 MAIN TANK
L281M20C1007		NE	1 SPLIT SUPPLY TANK
L281M20C1007		SV	1 SPLIT SUPPLY TANK
L281M20C1008	FT25084	SV	1 TANK
L281M20C1008	FT25084	NE	3 TANK
L281M20C1010		NE	1 TANK
L281M20C1026		SV	1 EC135 MAIN FUEL TANK
L282M20X1006		NE	1 HOSE DN08
L284M30C1001		SV	5 FUEL SENSOR MAIN TANK
L284M30C1002		SV	3 FUEL SENSOR SUPPLY TANK
L284M30C1002		SV	4 SUPPLY FUEL PROBE
L311M1009102		SV	4 SWI-PNL-20VE SMALL-NVG
L311M1009103		SV	5 SWI-UNIT-20VE SMALL-NVG
L311M1009150	L311M1009150D	SV	1 SWITCH UNIT 20VE SMALL-NVG
L311M1009881		NE	1 SWITCH UNIT
L311M1034101		SV	2 SWITCH UNIT 20VE
L311M1034101-001		SV	3 SWITCH UNIT 20VE/EMS
L311M1034102		SV	1 SWITCH UNIT 20VE
L311M1075101		NE	1 SWITCH UNIT 20VE SMALL NE
L311M1075102		NE	1 SWITCH UNIT 20VE 217
L311M1075102		SV	2 SWITCH UNIT 20VE 217
L311M1075155		SV	1 SWITCH UNIT 20VE 217
L311M1075155		NE	1 SWITCH UNIT 20VE 217
L311M1085103		NE	2 SWITCH PANEL
L311M1085103		SV	1 SWITCH PANEL 20VE TM ADAC

L311M1085106		SV	1 SWITCH UNIT
L311M1610168	L311M1610168A001	SV	45 MOUNTING PLATE
L311M1907210		NE	1 BLOCK
L315M5001881		SV	1 WARNING UNIT
L315M5001881	L315M5001881A002	NE	1 WARNING UNIT
L315M5001881		SV	1 WARNING UNIT
L315M5001881A001		SV	1 WARNING UNIT
L315M5002051		NE	1 WARNING UNIT ASSY (STAND. -97%
L315M5003101		SV	2 WARNING UNIT ASSY NVG
L315M50C1001	6300-00-00	SV	1 WARNING UNIT
L315M50C1011		SV	1 WARNING UNIT
L316M20C1001		SV	2 ENG/XMSN OIL T/P INDICATOR
L316M20C1002		SV	1 ENG/XMSN OIL T/P INDICATOR
L316M20C1002		NE	1 ENG/XMSN OIL T/P INDICAT
L316M20C1003	KM455-5	NE	2 ENG/XMSN OIL INDICAT
L316M20C1005		SV	1 ENG/XMSN OIL T/P INDICATOR
L316M20C1005	KM455-4	SV	1 ENG/XMSN OIL INDICAT
L321M1001205		NE	1 SKID SHOE ASSY
L321M1001250		NE	4 BOLT
L321M1001251		NE	5 BEARING SLEEVE
L321M1021230		SV	1 BRACKET FWD LOWER
L321M1021231		SV	1 BRACKET FWD UPPER
L321M1021236		SV	1 BRACKET REAR UPPER
L321M1025101		SV	1 HIGH SKID SHOE ASSY
L321M5823101		SV	1 BRACKET PRESS. TUBE COMPL.
L321M5827205		SV	1 BRACKET FWD
L321M5827206		SV	1 BRACKET FWD
L321M5827207		SV	1 BRACKET AFT
L321M5827208		SV	1 BRACKET AFT
L321P1011101		NE	4 YOKE ASSY
L331M4602101		NE	1 MODULE NVG LAMP
L331M5861101		NE	1 CHARTHOLDER NVG LH DET PART
L331M5862102		NE	1 CHARTHOLDER NVG RH DET PART
L331M5862103		NE	1 CHARTHOLDER NVG RH DET PART
L334C6002003		NE	1 SX-16 DETACH PART
L334C6802002		NE	1 SX-16 ADAPT KA
L334M3843101		NE	1 LANDING LIGHT
L341M10C1001	8000L-B709	OH	2 AIRSPEED
L341M10C1001	8000L	OH	2 AIRSPEED
L341M20C1001		NE	1 ALTIMETER
L341M20C1001		SV	2 ALTIMETER
L341M30C1001		SV	1 VSI
L344M3817101		NE	1 BRACKET ASSY RDR 1600
L521M1031105		NE	1 COVER PILOT DOOR LH

L521M1034105		NE	1 COVER PILOT DOOR RH
L521M3034101		NE	1 COVER
L521M3104101		NE	1 LOCK RH
L535A3501131		NE	1 INSERT, TUNNEL
L535A3501131		NE	1 INSERT, TUNNEL
L535A4201102		NE	1 STATOR ASSY
L535M2002051		NE	1 INST.FENESTRON-SHAFT MGB
L563M20X2003		NE	1 SLID.DO.PANE LH W.SLD.WDO
L563M20X3967		NE	2 SLIDING WINDOW LARGE LH
L621M1010056	EC135	AR	1 ROTOR BLADE ASSY
L623M2005103		NE	1 SWASHPLATE
L634M20C1001		NE	1 PRESS TRANSDUCER
L635M1021001		NE	1 CALIPER UNIT
L635M1025230		NE	1 ADAPTER
L635M1025230		NE	1 ADAPTER
L635M1025231		SV	1 MGB-FLANGE REWORKED
L652A2008201		NE	1 OUTPUT CASE
L652A2011202		SV	1 CONTROL BOX
L662C1024101		SV	1 HUBCAP STANDARD
L671M1003104		NE	1 CYCLIC STICK RH
L671M1809102		SV	1 CYCLIC STICK LH
L671M20V1005		NE	1 ROD END ASSY
L671M3011205		SV	1 LEVER
L671M5029101		NE	1 BELLOWS
L671M50C1004		NE	2 SWITCH UNIT
L671M50C1008		NE	2 SWITCH UNIT COLLECTIVE PIL
L671M50C1013		NE	1 SWITCH UNIT COLLECTIVE
L671M50C1026	G2-0055	NE	3 SWITCH UNIT COLLECTIVE PIL
L671M50C1030		NE	6 SWITCH UNIT COLL PIL
L671M50C2026		NE	2 SWITCH UNIT COLL PIL
L673M20A1012	S4-3000561	AR	1 MHA - COLLECTIV
L711M1065101		NE	1 ENG.COWLING LH
L713M1052101		SV	1 ENGINE FIX FIREWALLS TM RH
L713M2048101		SV	1 SHEET LOWER RH ASSY
L713M2048102		SV	1 SHEET LOWER RH ASSY
L713M2053101		SV	1 EJECTOR ASSY (P&W)
L713M2054102		SV	1 EJECTOR COMPL-PW RH
L713M2055102		SV	1 EJECTOR COMPL-TM LH
L713M2056102		SV	1 EJECTOR COMPL-TM RH
L713M2067102		NE	4 FIREWALL FRONT LH
L713M2068102		SV	1 FIREWALL FRONT RH
L713M2071101		SV	1 INLET CHANNEL LH
L713M2071101		NE	1 INLET CHANNEL LH
L713M2072101		SV	1 INLET CHANNEL RH

L713M2072104		SV	2 INLET CHANNEL RH
L713M2072105		SV	1 INLET CHANNEL RH
L771M10C1002		SV	1 N1-TACHO INDICATOR
L771M10C1003	DL458-121	NE	2 N1 TACHO INDICATOR
L771M20C1001	DT413-120-120	SV	1 DUAL TORQUE INDICATOR
L771M20C1003	DT413-121	SV	3 DUAL TORQUE INDICATOR
L771M20C1005	DT413-021	SV	1 DUAL TORQUE INDICATOR
L771M40C1004	DL457-300	NE	1 TRIPLE INDICATOR RRM (NVG)
L771M40C1004		SV	1 TRIPLE RPM INDICATOR
L771M40C1005		SV	1 TRIPLE TACHO INDICATOR
L771M40C1006		NE	2 TRIPLE INDICATOR RPM(NVG)
L771M40C1007	DL457-310	SV	1 TRIPLE TACHO INDICATOR
L771M40C1010	DL457-600	NE	1 TRIPLE RPM INDICATOR
L771M40C1012		SV	1 TRIPLE INDICATOR RRM
L771M40C1026		NE	1 TRIPLE INDICATOR RPM (NVIS)
L771M40C1028		NE	5 TRIPLE INDICATOR
L772M10C1002		NE	1 DUAL TOT INDICATOR
L772M10C1003	TM477-122	NE	1 DT INDICATOR
L792M3004235		NE	3 SHAFT WITH SPLINE
L853C1002103		NE	1 WIRE HARNESS
L853M2044101		NE	1 COVER CONN.BRACKET ASSY
L853M2932881	DSR-20P	NE	1 VCR DSR-20P MOD
L854M4807210		NE	1 RELAISHALTER SERIE M500
L882M1010106		NE	1 WIRE HARNESS 10VB
L882M1036101		NE	1 WIRING HARNESS
L882M1828115		NE	1 WIRE HARNESS
LC41-103011-01	103011-01	SV	1 SATCOM ADAPTER
LC41-306001-01	306001-01	SV	1 PHONE CONTROL UNIT
LC41496002-01		SV	1 BATTERY UNIT
LC42216045-23		SV	1 PANEL
LD12-002		SV	2 LAMP DIMMER
LD8016		SV	1 DME TEST PANEL
LDM-171		SV	1 LEADER DISTORTION METER
LDS50-50-20-55	LE-50	NS	24 VARISTOR
LED-40-15-HE-34387		NS	1 SWITCH ASSY
LED-40-17-HE-31351		NS	1 SWITCH ASSY
LED-40-18-BB-33599		NS	1 SWITCH ASSY
LED-40-18-BB-34384		NS	1 SWITCH ASSY
LED41-14BG32272		NE	2 2Y4, HF 3G4 FM
LG14C11		OH	1 TRANSDUCER PRESSURE RATIO
LH1PGFO0001		NE	1 LIFE HAMMER
LN29930-08X26	LN299	NS	1 SCREW
LN29952-0815M	LN943	NS	7 WASHER

LN9038-04024		NE	50 SCREW
LN9438M5X32	LN943	NS	30 SCREW
LN9439M5X32	LR600	NS	2 SCREW
LPG111		SV	1 LP GOVERNOR
LPG126		SV	1 LP GOVERNOR
LR6003		SV	1 CTL TEST PANEL
LS03-05001		AR	1 DC CONVERTER
LT-100		SV	1 LIGHT DIMMER SUPPLY
LT-25F		SV	3 AC TO DC POWER SUPPLY
LT-48B	222-375-012-101	SV	4 LIGHT DIMMER SUPPLY
LT48D		SV	1 LIGHT DIMMER PWR SUPPLY
LT48D		SV	1 LIGHT DIMMER SUPPLY
LT-52A		SV	1 LIGHT DIMMER SUPPLY
LT-70		NE	1 LIGHT DIMMER SUPPLY
LT-71		SV	1 DC TO DC CONVERTER
LT-71A		SV	1 DC TO DC CONVERTER
LT-71G		SV	1 DC TO DC CONVERTER
LV2024		SV	4 MKR/GS TEST PANEL
LZ30		NE	1 GUARD
M025277-300-08	3045802-01	OH	1 FUEL PUMP
M031-01S021-046		NE	1 SKID SHOE RH AFT
M1035E-3A		SV	1 SPARE UNIT
M1045-F356-HMD3		SV	2 AUDIO CONTROL SYSTEM
M1045-J762-ESC3	990-3342-028	SV	2 AUDIO CONTROL SYSTEM
M1045J762GNK3		SV	4 CABIN AUDIO
M1050-B324-01	990-1254-051	SV	4 AUDIO SYSTEM
M1050B-7F		SV	1 AUDIO AMP
M1050-C447-01		SV	1 AUDIO SYSTEM
M1050-G448-01	990-1254-008	SV	1 AUDIO SYSTEM
M1050-L358-02	L358-02	SV	1 AUDIO AMP
M1050S-1G		SV	1 AUDIO AMP
M1052		SV	1 AUDIO SYSTEM
M105-23301-2		NE	2 WINDOW ASSY RH
M1060-01501-07		SV	1 AUDIO SYSTEM
M1080B		SV	1 AUDIO AMP
M1082B		SV	1 AUDIO AMP
M1082D		SV	2 AUDIO AMP
M12883/40-01		NS	1 SOCKET,RELAY
M12883/44-01		NS	1 SOCKET,RELAY
M12883/53-001		NS	1 CONNECTOR,RCPT,ELECTRICAL
M2050K	M2620	SV	1 AMPLIFIER
M24251/6-1		NE	3 SHIELD
M24251/6-2		NE	3 SHIELD
M24308/2-2F		NS	1 CONNECTOR,RCPT,ELECTRICAL

M24308/2-3F		NS	1 CONNECTOR,RCPT,ELECTRICAL
M24308/2-4F		NS	1 CONNECTOR,RCPT,ELECTRICAL
M24308/4-1F		NS	1 CONNECTOR
M24308-2-1F		NS	1 CONNECTOR
M2620BJ		SV	1 MOTOR
M3088-11		SV	2 PANEL
M33GMC09C2AA	M3901	SV	1 RADIO VHF FM GM300
M39012-20-0504	M3902	NE	100 CONNECTOR
M39029/29-12-12	M4630	NS	188 INSERT
M463080/M503540		SV	2 RACK
M6241		SV	1 ANTI-ICE VALVE
M655		OH	1 OAT GUAGE
M7950-11	990-1769-005	SV	1 PAGING AMP
M81714/2-AB1		NS	2 TERMINAL JUNCTION BLOCK
M81714/2-DB1		NS	9 TERMINAL JUNCTION BLOCK
M81714/67-02		NS	1 TERMINAL JUNCTION BLOCK
M83536-2-024M		NE	4 RELAY
M83723/82K1212N		NS	2 CONNECTOR
M83723/86R1212N	X9234-115	NS	10 CONNECTOR W/ PINS AND EXT TOC
M83723/95R0803N		NS	1 CONNECTOR
M85049/49-2-12W		NS	2 CLAMP
M85049-52-1-20W		NS	1 STRAIN RELIEF
M85049-52-1-22N		NS	1 STRAIN RELIEF
M850-5V-G	1159SCAV409-2	SV	2 DIGITAL CLOCK
M-BK117-243021-4		NE	1 ASSY, CARGO DOOR WINDOW
MC235MH089		NE	3 INDICATOR
MC4741CP		NS	25 IC
MC700-4NVG		SV	5 MAGNETIC COMPASS
MC7014-1-00		SV	1 PRESSURE SWITCH LP
MD25-300		OH	1 STANDBY AIRSPEED INDICATOR
MD41-1308	MD41-13085V	AR	1 ANNUNCIATOR
MD41-1308		AR	1 TAWS ANNUNCIATION CTL
MD41-1448	MD41	AR	1 ANNUNCIATOR
MD41-1628	MD41-1628(5V)	SV	1 GPS ANNICIATION CTL UNIT
MD41-628	MD41	SV	1 ANNUNCIATOR
MFFA370-1		NS	2 FLITER ELEMENT
MI-585002	AVI-202	SV	1 RMI/CONVERTER
MI-585031	AVN-220	SV	1 VHF NAV SYSTEM
MI-585067	AVN-204	OH	1 AUTO VOR CONVERTER
MI-585072-3	MI-58	SV	2 NAV ILS40CH MKR RX
MI-585074-7	AVC-110A	SV	1 VHF COMM
MI-585084	FP-900	SV	1 ANTENNA RADAR
MI585297-3		SV	1 DATA NAV PANEL
MI-585297-3		SV	1 DATA NAV III CONTROL PANEL

MI-585300-4		SV	1 RADAR R/T
MI-585302		SV	2 RADAR ANTENNA
MI-585396-4	DNC-1001	SV	1 DATA NAV
MI-585397-5	DNC-1002	SV	1 DATA NAV
MI-585398-2	DNCP-1001	SV	1 DATA NAV CONTROL
MI-585399-1		SV	1 DATA NAV
MI-585399-2		SV	1 DATA NAV
MIL-G-6036B	AW-17/8-27-E5	SV	1 GAGE - HIGH PRESSURE OXYGEN
MJ10023	5961-01-176-5661	NE	1 TRANSISTOR
ML335	MP498	NS	10 LAMP
MP498-103	MP498	SV	1 YAW MAG-BRAKE
MP498-105	204-001-376-105	SV	1 YAW MAG-BRAKE
MPRD9639	MS166	SV	2 BARCO DISPLAY
MS16627-1125		NS	1 RINGS
MS17983-4	CB2125-28A	OH	1 COMPASS
MS17985C411	MS208	NS	10 PIN
MS1801		SV	1 MODULE
MS1803-3		SV	2 MICROTOUCH INTERFACE MODULE
MS1804		SV	1 MODULE
MS1805		SV	1 MODULE
MS1817		SV	1 MODULE
MS1826		SV	1 MODULE
MS1829-B		SV	1 MICTROTOUCH INTERFACE MODUL
MS1833		SV	1 MODULE
MS1858		SV	1 MODULE
MS1863		SV	1 MODULE
MS2012		AR	1 MICTROTOUCH INTERFACE MODUL
MS20825-8	MS210	NS	2 TEE FITTING
MS21048-3K	MS210	NS	36 NUTPLATE
MS21074-3K	MS220	NS	50 NUTPLATE
MS21075-3N		NE	100 NUTPLATE STEEL
MS21225-6		NE	3 NUT
MS22034-4	MS245	NS	1 JAW FITTING STUD
MS22073-10	7274-11-10	NS	1 CIRCUIT BREAKER
MS22073-15	7274-11-15	NS	1 CIRCUIT BREAKER
MS22073-2	7274-11-2	NS	3 CIRCUIT BREAKER
MS22073-3	7274-11-3	NS	7 CIRCUIT BREAKER
MS24183D1	24183D1	SV	1 RELAY SOLENOID
MS24390630BC4		SV	1 HYDRAULIC MOTOR
MS24576-2	18-1701	OH	1 OIL PRESSURE INDICATOR
MS24693BB52		NE	189 SCREW
MS24694C99		NE	39 SCREW
MS24694-S64		NE	150 SCREW
MS25056-1B		NE	1 SLEEVE ANTENNA WIRE

MS25056-1B	MS252	NS	1 SLEEVE/ANTENNA WIRE
MS25069-1495		NE	10 LAMP
MS26574-1	7274-70-1	NS	3 CIRCUIT BREAKER
MS27472T24B-2S	MS274	NS	1 CONNECTOR
MS27472T24B61P	MS277	NS	4 CONNECTOR
MS27473T14B18S		NE	2 CONNECTOR
MS27782-2F	MS280	NS	1 SWITCH
MS28041-2A	MS280	OH	1 TURN AND SLIP
MS28043-T2	273-7TN112	OH	1 GAGE UNIT - ENGINE
MS28075-1	RCS-60-1L	OH	1 IND, RATE OF CLIMB
MS28773-03		NE	20 RETAINER PACKING
MS28774-138	MS310	NS	7 RETAINER
MS28774-138		NE	7 RETAINER
MS3101A10SL-4P		NS	11 CONNECTOR
MS3106A18-11S		NS	1 CONNECTOR
MS3106A24-11P		NS	1 CONNECTOR
MS3106E14S-2S	MS310	NS	1 CONNECTOR
MS3106E28-16P	MS310	NS	2 CONNECTOR
MS3106F24-A24S		NS	3 CONNECTOR
MS3108F24-58P	MS347	NS	2 CONNECTOR
MS3116F10-6S		NE	1 CONNECTOR
MS3126F-16-23P		NS	10 CONNECTOR
MS3416-8EN		NS	31 BACKSHELL
MS3470L12-10P		NS	1 CONN KIT
MS3470L20-39PY		NS	4 CONNECTOR
MS3470L24-61PY		NS	1 CONNECTOR
MS3470W20-41SW	MS347	NS	1 CONNECTOR
MS3474W12-8P		NS	4 CONNECTOR
MS3476W20-39S		NS	5 CONNECTOR
MS35489-120	MS357	NS	8 GROMMET
MS35489-69		NE	25 GROMMET SYNTHETIC RUBBER
MS35769-20	MS361	NS	2 GASKET
MS3614-8EN	MS910	NS	36 BACKSHELL
MS9105-55	N000-	NS	2 PIN
MS91528-2N2B6		NE	1 KNOB
MS9575-09		NE	5 BOLT
MT1-1079-102		SV	1 ATC MOUNTING TRAY
N001-0001		SV	1 CONTROL DISPLAY UNIT
N200-151		NE	1 EMERGENCY ENG CONTROL
N300-005		SV	2 AUDIO CONTROL PANEL
N300-006		NE	1 CABIN CREW AUDIO PANEL
N303-10167-53-A	5985-01-297-5162	NE	5 RADIO FREQ SWITCH
N335-023		NE	2 AUDIO CONTROL PANEL
N3844-20		SV	1 ARRA ATTENUATOR

N48-1-2		SV	2 ANTENNA
NA135	NAS11	SV	1 AUDIO FREQ DECODER
NAS1149C0532B		NE	50 WASHER
NAS1330H08K161		NE	70 NUT PLAIN RIVET BLIND
NAS1333A3C10D		NE	3 QUICK RELEASE PIN
NAS1376A08SD018		NE	1 DUCT
NAS1738M5-6		SV	10 RIVIT
NAS1836-06-08		NE	1 INSERT
NAS1922-0400-1H		NE	6 CLAMPS
NAS557-8B	NAT35	NS	40 GROMMET
NAS561C4-9		NE	99 PIN SPRING
NAS6604D58		NE	5 BOLT
NAS77-4-012		NE	10 BUSHING
NAT352-001	NAT380-005	OH	2 AUDIO PANEL
NDN8595-03	704A47152004	OH	1 VERTICAL GYRO
NDN9768-03	NDN9768	SV	1 FLT PATH CTL COMPUTER
NT-30B-000W/R	NT30B-000	SV	1 FM TRANSCEIVER
NT450	CH250-020	OH	1 FM TRANSCEIVER
NT450	CH250-ONE	OH	1 FM TRANSCEIVER
NY-6MO-3	NY-6M0-3	NE	1 FITTING
O33203	BC407/332	OH	1 AMETEK ROTRON INVERTER
O50084	1250435	OH	1 BLOWER
O50084	1250435	AR	1 BLOWER
OB1303-003		SV	1 DZUS CONT (HORIZONTAL NON-NV
OBS-85A		OH	1 OMNIBEARING SELECTOR
P057634	P1208	SV	1 PRINTED CIRCUIT
P058312	704A46610010	SV	1 PRINTED CIRCUIT,Z200
P100-205A		NS	4 SCREW
P-10A		SV	1 INVERTER
P12064		NS	1 CONN KIT
P12248-002	AIRCELL	SV	1 AIRCELL HANDSET
P12339		SV	1 AIRCELL AXCESS II
P12347		SV	2 AIRCELL MODULE
P12861-001	P12861-003	NE	1 ASSY, TOP BASE STATION
P155-15A-E1A		SV	2 ADAS TRANSDUCER ASSY
P200100AFCAU	704A47134186	SV	3 BOX CONTROL
P3-03-0041-101		SV	1 SURVIVAL RESCUE BEACON
P356-5000		SV	1 ADAS TRANSDUCER ASSY
P600-14A	P6021	NS	1 CURRENT PROBE
P8304-1		SV	1 INVERTER
P94C16-601		AR	1 FUEL PUMP
PAI700		SV	1 COMPASS, BACKUP
PANL-2016-05-01		NE	2 SKYQUEST VCR REMOTE CONT
PC06E8-4S-SR		NS	11 CONNECTOR PLUG,ELECTRICAL

PC-125-123C		OH	2 STATIC INVERTER
PC12A		NE	1 CONVERTER 28/12 VDC
PC-12A		SV	1 STATIC INVERTER
PC-12A	PC-12	SV	1 CONVERTER
PC-12VR		OH	1 DC TO DC CONVERTER
PC16-3	PC-16-3	SV	1 STATIC INVERTER
PC17A	PC17A	SV	3 STATIC INVERTER
PC251		AR	1 STATIC INVERTER
PC-251-123E		SV	1 STATIC INVERTER
PC-251-123K	76550-23800-102	SV	1 STATIC INVERTER
PC-50		SV	2 STATIC INVERTER
PC820-101A		SV	2 SIGNAL CONDITIONING UNIT
PC900-1A0600PH1		SV	1 FUEL FLOW INDICATOR
PC900-1A0600PH1-1		SV	1 FUEL FLOW INDICATOR
PC-900-ECAP-0001		SV	1 INDICATOR CONDITIONER UNIT
PCC-15V	PF10-	NS	1 CURTAIN RACK
PF10-167		SV	1 ANTENNA
PH502-BKC		NE	1 PITOT TUBE
PO58312	704A46610010	SV	1 PRINTED CIRCUIT
PR-10		SV	1 CURRENT PROBE AMPLIFIER
PS1230		AR	1 BATTERY PACK
PS18125-1		SV	1 POWER SUPPLY, USB
PS7016006-202	PT06A	NS	2 O RING
PT00SE14-19S		NS	2 CONNECTOR,RCPT,ELECTRICAL
PT06A84SSR	PW206	NS	1 CONNECTOR
PT06CE8-2P(SR)		NS	16 CONNECTOR
PT06SE22-55PX		NS	1 CONNECTOR
PW-28D-13FL-4	222-375-065-101	SV	1 POWER SUPPLY
PW-28S-40CC-2		SV	11 POWER SUPPLY
PW727MVBUE7		OH	1 EGI INDICATOR
PYLB50487-1	R1467	OH	3 V/V ANTI-ICE/EAPS
R-1123A/ARC73		SV	1 RECEIVER, RADIO
R1467M20	214-001-347-101	OH	1 ACTUATOR
R-252220-00		AR	1 CAMERA UNIT, DOWN ZOOM
R460M15-11	204-001-376-3	OH	1 MAG BRAKE
R460M44-105	204-001-376-105	OH	2 MAGNETIC BRAKE HELICOPTER
R460M44-107	204-001-376-107	OH	2 MAGNETIC BRAKE HELICOPTER
R50U-15-N		NS	1 CONVERTER
RBE12-03	LMP027	SV	1 RPM WARNING SYS
RC-30-V-10-1	100-384054-1	SV	1 IVSI 0-3000 FPM
RC-30-VIL	212-070-239-001	OH	3 VSI
RC-60-10DE2	RC-60-10	OH	1 IVSI
RCA15B3		OH	1 INDICATOR GYRO DIR
RCA15BL1		OH	1 INDICATOR, DIR GYRO

RCA26BK-2	102-0054-03	OH	2 INDICATOR, GYRO ATT
RCA28W2D2S		OH	1 INDICATOR
RCA82A-2		OH	1 TURN COORDINATOR
RCD-021-402		SV	1 AI CD PLAYER
RCLD14-5-B2/28		SV	1 DISPLAY
RCLD14-7/28		SV	1 DISPLAY
RCM-10-3		OH	1 RATE OF CLIMB INDICATOR
RCM60ACL		OH	1 RATE OF CLIMB INDICATOR
RD25FJVL0		NS	1 CONNECTOR
RD29M00000		NS	3 CONNECTOR
RD29M10JV30		NS	1 29 PIN M DSUB KIT
RD50M10JVL0		NS	1 CONNECTOR
RD8180K	4440-00-780-1039	OH	1 DEHYDRATOR UNIT
RD9F10JVL0		NS	2 CONN KIT
RD9M10JV30		NS	1 CONN KIT
RD9S10GVLO		NE	1 CONNECTOR
RD-AV7052-1		SV	7 LCD MONITOR
RDR1400SYSTEM	RDR1400	SV	1 WEATHER RADAR SYSTEM
RECT1-B12-1A998000		SV	1 POTENTIOMETER
RG-15980-E		OH	1 FUEL PUMP
RG40		SV	1 DC TO DC CONVERTER
RGD-9-D-PS-R		SV	5 SHARP/ROSEN DISPLAY
RGD-9-R	6M-40U	NS	5 SHARP/ROSEN DISPLAY
RIA01-01-00		NE	1 RETRACTABLE INTERFACE ADAPTEF
RISR-28-12-6		SV	6 PWR CONV
RL5026		NE	18 READING LIGHT
RLB-35	2744	SV	1 ACR ELT
RLCD14-5-B2/28		SV	1 ROSEN DISPLAY
RM300CA-9W		SV	1 DIODE ASSY
RN-222AE		SV	1 NAV RCVR
RNVAP-2LL		NS	1 ROSEN CONNECTOR
RNVAP-5ULL-L-WO/28		SV	1 VIDEO MONITOR
RR54220	70307-23908-101	OH	1 PUMP DUMP FUEL SYSTEM
RS08-001		AR	4 AUDIO BOX
RS08-500		SV	1 AUDIO BOX
RS16-001		SV	1 RELAY UNIT
RS8031	RSLM-	SV	1 VOLTAGE CONVERTER
RSLM-5SB/28		SV	2 MONITOR BASE
RSLM-5SLA-L/28		SV	3 MONITOR DISPLAY
RT100M1E		SV	2 MEM- CARD READ/WRITE U-
RT100-PC-M1		AR	1 CARD READER
RT-1115C/APN209V	HG7209AB01	SV	2 RECEIVER TRANSMITTER
RT651/N-A	SRT651	NE	1 V/UHF TRANSCEIVER
RT8	XANTECH	SV	1 ADDRESSABLE INFRARED ROUTER

S15-005	706A31213061	SV	1 ECLAIRAGE PANNEAU CARB 3Q
S1609.1.118A		NE	3 LOAD HOOK
S1609.6		OH	1 SLING CARGO HOOK
S1820513-11		AR	1 ELT SWITCH
S1840501-01		AR	1 ELT
S212-850		SV	1 AC CURRENT LEVEL SENSOR
S-3008EC-6		OH	1 COMPRESSOR ASSY
S4000-4		SV	1 PASSENGER BRIEFING SYSTEM
S4-3402250		NE	1 MAGNET VENTIL
S6130-63049-000	S65-5	OH	1 DEFUEL/REFUEL VALVE
S65-5366-10L		SV	1 L-BAND ANTENNA DME/XPDR
S65-5366-850L		SV	1 ANTENNA RADIO PHONE
S65-8282-25		SV	1 ANTENNA
S65K-L7-30	S67-1	OH	1 AIRSPEED MAX ALLOW IND
S67-1575-20		SV	4 ACTIVE GPS ANTENNA
S67-1575-232		SV	10 ACTIVE GPS ANTENNA
S67-1575-39		SV	8 S
S67-2002-14		AR	1 ANTENNA
S72-1750-32L		AR	1 ANTENNA
SA106509	SA106	SV	1 TAPE CARTRIDGE ASSY
SA106572	SA-40	SV	1 HARVARD BI-PHASE CARD
SA40-1	8000T-B12	SV	1 AIRSPEED IND
SA-40-1	8000T-B12	OH	1 AIRSPEED 0- 200 MPH
SA-40-1RB	8000T	OH	1 AIRSPEED 0- 200 MPH
SAT-550		NS	1 GLOBALSTAR SATELLITE PHONE
SB093-1		NE	1 KIT F. AIR CONDIT.
SB-117-90-119-3.1		NE	1 RETROF CIP DET TAILR INTERM GEA
SB120		SV	1 POWER STATIC INVERTER
SB-135-33-004-2C1		NE	1 LED POS LIGHT
SB-135-34-034-2C1		NE	1 RET STBY HORIZON
SB-135-52-006-2C1		NE	1 JETTISON COCPIT DOOR
SB-135-53A-018-2C1		NE	1 CHANGE OF DRAIN HOSE
SB-135-85-030-2C1		NE	1 CONVERSION HELLAS
SC41-37002-01	SC41-	SV	1 PANEL
SC41-471001-01		SV	2 TELCOM TRANSFER UNIT
SC41-471002-01	471002-01	SV	1 SATCOM INTERFACE COMPUTER
SC41-472001-01		SV	1 HANDSET TRANS UNIT
SC44104048-537	59734/SC44104048-537	SV	1 PANEL
SC44104058-51		SV	1 PANEL
SC44453002-27		SV	1 PANEL
SC44468035-37		NS	1 EXT LTS/MASTER ETC PANEL
SD15F10JVL0		NS	1 CONNECTOR
SD167A		NE	1 CONTACTOR
SE13626	704A42713044	SV	2 HEATING MAT POWER UNIT

SE13651	704A42713045	SV	1 MPA POWER UNIT
SE-3130-D-73-71-905		OH	4 SERVO COMMANDE TYPE 4300
SEL0C19EL		OH	1 T5 INDICATOR
SEL-OC19AM	76450-01076-106	OH	1 TURB TEMP IND
SEL-OC19AP	76450-01076-107	OH	1 TURB TEMP IND
SEL-OC19EL		OH	1 T-5 INDIC
SEL-OC19EL1	SEL-OC19EL1	OH	2 T5 INDICATOR
SEL-OC29CB	76450-00903-101	OH	2 TRIPLE TACH
SEL-OC29F	76450-01076-101	OH	2 GAS GEN TACH IND
SETL-OC329A	76450-01076-103	OH	2 TRIPLE INDICATOR, TACH
SETL-OC329G	76450-00901-104	OH	2 TRIPLE TACH
SG1525AJ		NE	10 MICROCIRCUIT
SK106L106-581,4		NE	2 ROD TUBE
SK355-078-01	SKCP2	SV	2 WHEEL ASSY
SKCP2456-3	SL204	SV	1 DRIVE SHAFT
SKCP2456-3		NE	1 DRIVE SHAFT
SKCP2456-3		SV	1 DRIVE SHAFT
SL2049-1	SLZ76	NS	4 NUT
SLZ7600		OH	1 TRANSMITTER, STAT-429
SLZ9125A	6610-903-0714	OH	1 INDICATOR, VERTICAL VELOCITY
SLZ9155	D6H	SV	1 IVSI
SLZ9157	D6HL	OH	1 IVSI
SLZ9157-3	D6HL	SV	1 IVSI
SLZ9644		OH	1 TRANSMITTER, ANGLE OF ATTACK
SM15CXD20		SV	1 RELAY 60 AMP 1PDT
SM20ACD200A21		SV	2 CONTACTOR
SM20ACD300A21		SV	2 CONTACTOR
SM20CCD200B21		SV	2 CONTACTOR
SM600BA50A1		NS	1 CIRCUIT BREAKER
SM600BA75N1		NE	1 CIRCUIT BREAKER
SM-D-374989	5821-00-089-9207	NE	2 A1500 RF TUNER
SN3500-010N	SN3500	SV	1 EHSI NVS
SO-1055-8690		NS	1 RELAY SOCKET
SOC108		OH	1 HP FUEL COCK
SP401		SV	1 TELPAR PRINTER
SP67-9		SV	1 SMARTPACK
SPC-10(H)		NE	1 INVERTER
SPC-30B	SPC-6	SV	1 INVERTER
SPC-60A	SPH-1	SV	1 INVERTER
SPH-1006	SPH-1	SV	1 STATIC FREQ CHANGER
SPH-1606B-3	SPS-1	OH	1 STATIC FREQ CHANGER
SPR87378		NE	1 JACK 7T MODIFIED
SPR87378		NE	2 JACK 7T MODIFIED
SPS-1-1-331	SPS-1	NS	1 SWITCH

SPS-1607	SPS-1	OH	1 STATIC INVERTER
SPS-306B-3		SV	1 STATIC INVERTER
SRM8.TA		NS	2 BEARING
SS9013-2409	SSP23	NS	1 IDENT PLATE
SSD120-30A		SV	1 ATTITUDE ENCODER
SSP23-004B		NS	1 LABEL, MAR, VHF
SSP23-022-3		NS	1 INTERCOMM HARNESS RADIO
SSPD-113-39		NS	1 ANTENNA POWER DIVIDER
ST10107		NE	2 MOTOR-TACHOMETER GENERATOR
ST3400H-001		FN	10 TAWS-A & RMI
SX-16		OH	1 SEARCH LIGHT
SX7EJ3		SV	1 BATTERY CONTACTOR
SYLC52086-2	230-360-701-101	OH	1 ACTUATOR ELECTROMECHANICAL
SYLC-9548-1		SV	2 LINEAR ACTUATOR
SZ65-001-1		SV	1 MOTOR COMPRESSOR COND UNIT
T1B90A6C		AR	1 METAL PART
T2067		SV	1 FAN CONDENSOR
TA3F-94V0		NS	1 CONNECTOR
TBM150365	TE-17	SV	1 VIDEO POWER SUPPLY
TDH7050-2000		NE	2 RELAY
TE450		AR	1 LS AMPLIFIER
TE450BN846		AR	1 TRANSISTOR
TH250-2NN	TLNB-	SV	1 FM CONTROL
TJG120403		NS	1 TERMINAL JUNCTION
TK-7180		SV	1 VHF FM TRANSCEIVER
TLH451L115		NE	1 SLIDING PIECE
TLNB-10		NE	1 TERK DUAL LNB
TM105-2		SV	1 TEMP. SWITCH
TM105-2		NE	1 TEMP SWITCH
TM-105PSN	TM410	SV	1 TV
TM410-39		SV	1 TRIPLE OIL TEMP. INDICATOR
TM410-40		SV	1 TRIPLE OIL TEMP INDICATOR
TM410-53		SV	1 TRIPLE OIL TEMP- INDICATOR
TM410-54		OH	1 TRIPLE OIL TEMP- INDICATOR
TM427-39		SV	3 EXHAUST TEMP. INDICATOR
TM427-40		SV	3 TEMP INDICATOR
TM427-45		NE	2 TEMPERATURE INDICATOR
TM427-45		SV	1 TEMPERATURE INDICATOR
TM477-020-020		SV	1 DUAL TOT INDICATOR
TNC3844-20	N3844-20	SV	1 ADAPTER
TRAWID9-25		NE	1 BREAK OUT BOX
TRDU24A2	TSG42	SV	1 TIME DELAY RELAY
TS-642/U	AN/UPM-56	SV	2 TEST SET, RADAR
TS-807/ARM-10		SV	1 TEST SET, RADIO

TSG420-103	TWN-1	SV	1 STATIC INVERTER
TWN-12	UC-28	NS	2 TWIN PILLOW BLOCK
TWN-12-ADJ		NE	2 TWIN PILLOW BLOCK
TYE3007-3-18		NE	1 INSERT
TYP8124K		SV	1 AVIONICS FAN
UC-28-14	UCB16	SV	4 DC TO DC CONVERTER
UCB16530-02	UCB16530	SV	1 CONTROL UNIT
UT12-000		NE	1 TONE ENCODER
V084C-CA		AR	5 MONITOR
V5000-172	V694-	SV	2 SOLENOID VALVE
V6-328		NE	1 BELLOWS
V63A010-00-001-001	V63A010	SV	2 MULTI-FUNCTION DISPLAY
V694-6-1	V694-	SV	1 VOICE GENERATOR
V694-7-5	V8500	SV	1 VOICE GENERATOR
V694-7-7		SV	1 VOICE GENERATOR
VA 3660		NE	1 AXIAL FAN
VA 3660		SV	3 AXIAL FAN
VA1A300		SV	1 INDICATOR, DC VOLT AMP METER
VA400		SV	1 VIDEO SWITCH
VA-400-1	VCT15	SV	1 AIRSHOW VIDEO AMP
VCL16501-02		SV	1 TRIM ACTUATOR
VCP-014-01-2		SV	1 VIDEO PLAYER
VCP-015-01-1	30500056	SV	1 VIDEO PLAYER
VCT1518C	9560156790	AR	2 BLOWER
VCT1518C	9560156790	OH	1 BLOWER
VFS10-90-1		SV	2 ANTENNA, VHF
VFS10-90-2		AR	7 ANTENNA, VHF
VG204AB	76600-02113-103	OH	1 REMOTE GYRO
VG204V	76600-02113-102	OH	1 REMOTE GYRO
VLTL12-CV	VM-20	SV	1 DC TO DC CONVERTER
VM-202RRT	VM202	SV	1 PHASE ANGLE VOLTMETER
VP4805		SV	1 RF MOUSE
VR2011	VR300	SV	1 VOLTAGE REGULATOR
VR2011		SV	1 VOLTAGE REGULATOR
VR300-14-50		NS	1 VOLTAGE REGULATOR
VR-L11-0023.100		NE	1 COLD BONDING TOOL SET EC135
VT044		NE	20 ROD TUBE
VT426-39		NE	2 FUEL INDICATOR
VT426-40		SV	1 FUEL PRESSURE INDICATOR
VT426-41		SV	1 FUEL QTY IND (US GALS)
VT443-1		SV	1 FUEL QTY IND (US GALS)
VXAP-135		NE	1 VXP APPLICATION KIT T&B EC135
VXAP-135DS		NE	1 VXP APPLICATION KIT EC135 DRI

W0314		NE	2 LAP BELT
W21ADCQX-5	W33-7	NS	1 RELAY
W21ADCQX-5		NS	1 RELAY
W33-7510-10	98429-W33-7510-10	OH	1 CLOCK
W33-7510-10A		OH	1 CLOCK
W33-7510-10ET20	WL/51	OH	1 CLOCK
W671M50C1001		NE	1 SWITCH UNIT COLLECTIVE
WA1967		NE	1 SAFETY DISK
WA2014		NE	1 STELLMOTOR
WA4337		NE	1 GEAR ASSY
WA4339		NE	1 GEAR ASSY
WA4346		NE	1 RECORDING RING
WB4365		NE	1 PISTON
WB4366		NE	1 DRIVE CAM DISK
WE-3821-4		SV	1 HOIST ASSEMBLY
WEMACPP3510-10		SV	10 READING LIGHT
WGE-0090-00		SV	1 DIPLEXER
WL/519CUF/1	WL/519CLF/1	SV	1 ALTITUDE ALERTING UNIT
X00042-413		SV	1 STALL PROTECTION COMPUTER
X98545		SV	1 EMERGENCY VHF TRON AIR
XD4N		NS	2 LEACH RELAY
XE-90MKII		SV	2 STEREO GRAPHIC EQUALIZER
XL1327		SV	1 ANTENNA PLATE
XMC100-01		NS	1 XM RADIO CONTROLLER
XMD076-01	RS232	SV	1 XM DATA RCVR
XMR100-01		NS	1 XM RCVR UNIT
XW21160-M1		NE	3 MOTOR
XW23513-1	222-325-001-25	SV	1 MOTOR CONVERTER
Y1242-31-1		AR	1 MOTOR
Y-E4N-024		NS	1 LEACH RELAY
ZC-B3N		SV	1 RELAY
ZE3-276		SV	3 GUIDE ASSY
ZRB263-00		NE	3 PRESS TRANSDUCER

SANDFILTER)

